Manuals+

Q & A | Deep Search | Upload

manuals.plus /

- Surtime /
- > Surtime 42-Inch Palm Leaf Ceiling Fan User Manual

Surtime 6669

Surtime 42-Inch Palm Leaf Ceiling Fan User Manual

Model: 6669-Brown

1. Introduction

Thank you for choosing the Surtime 42-inch Palm Leaf Ceiling Fan. This tropical-style ceiling fan combines aesthetic appeal with powerful airflow, featuring a unique palm leaf design and advanced control options. It is suitable for both indoor and covered outdoor spaces, such as living rooms, bedrooms, kitchens, balconies, and corridors. This manual provides essential information for safe installation, operation, and maintenance of your new ceiling fan.



Figure 1: Surtime 42-inch Palm Leaf Ceiling Fan (Brown)

2. SAFETY INFORMATION

Please read all safety instructions carefully before installation and use to prevent personal injury and product damage. Keep this manual for future reference.

- Ensure the main power supply is turned off before installation, maintenance, or cleaning.
- All wiring must be in accordance with national and local electrical codes.
- The ceiling fan must be securely mounted to a structural support capable of holding the fan's weight.
- To avoid personal injury and damage, the fan blades should be installed with a minimum clearance of 7 feet (2.13 meters) from the floor and 18 inches (45.72 centimeters) from walls or other obstacles.
- Do not insert objects into the path of the rotating blades.
- This fan is suitable for indoor use and covered outdoor areas not affected by direct wind and rain. It is not waterproof.

3. PACKAGE CONTENTS

Verify that all components are present and undamaged before beginning installation:

- Ceiling Fan Kit (includes motor, blades, light kit, mounting hardware)
- · Instruction Manual
- Remote Control (batteries included)

4. SPECIFICATIONS

Feature	Detail	
Brand	Surtime	
Model Name	6669-Brown	
Size	42 inches	
Color	Brown-Palm Leaf	
Material	Acrylic	
Style	Modern	
Power Source	DC	
Voltage	110 Volts	
Wattage (Light)	21 watts	
Control Method	App, Remote	
Special Features	App Operable, Dimmable Light, Light Memory Function, Palm Leaf Design, Snap-in Fan Blades, Reversible DC Motor	
Product Dimensions	41.73 x 41.73 x 11.81 inches	
Item Weight	8.82 pounds	



Figure 2: Product Dimensions and Key Specifications

5. SETUP AND INSTALLATION

Installation of the Surtime ceiling fan is designed to be straightforward. Please follow these general steps. For detailed visual guidance, refer to the official installation video provided.

5.1 Pre-Installation Checklist

- 1. Ensure power is OFF at the circuit breaker.
- 2. Verify all package contents are present and undamaged.
- 3. Gather necessary tools (e.g., screwdriver, wire strippers, ladder).

5.2 Mounting the Fan

Attach the mounting bracket to the ceiling junction box. Ensure the junction box is securely fastened to the building structure and can support the fan's weight.

5.3 Wiring Connections

Connect the fan's electrical wires to your household wiring according to the provided wiring diagram in the separate installation guide. Always match wire colors (e.g., black to black, white to white, ground to ground).

5.4 Attaching Fan Blades

The fan features innovative snap-in blades, allowing for tool-free installation. Simply align the blade with its slot on the motor housing and push until it clicks securely into place.



Figure 3: Snap-in Fan Blade Installation

5.5 Light Kit Installation

Attach the LED light kit to the bottom of the fan motor assembly. Ensure all electrical connections are firm before securing the light cover.

6. OPERATING INSTRUCTIONS

Your Surtime ceiling fan can be controlled via the included remote control or a dedicated mobile application.

6.1 Remote Control Operation

The remote control provides full functionality for your fan and light. Ensure the remote has working batteries (2 x 12V batteries, included).

- Fan Speed: Adjust between 6 wind speeds.
- Light Control: Turn the light ON/OFF.

- Color Temperature: Cycle through three color temperatures: 3000K (Warm Light), 4500K (Natural Light), and 6000K (White Light).
- Brightness Adjustment: Dim the light from 10% to 100%.
- Timer: Set a 2-hour or 4-hour timer for automatic shutdown.
- Forward/Reverse: Change the direction of blade rotation for summer (downward airflow) or winter (upward airflow for air circulation).



Figure 4: Remote Control and App Interface Overview



Figure 5: Six Adjustable Fan Speeds



THREE COLOR CEILING FAN LIGHT

Three Color Light with Memory Function Meet Your Needs







Figure 6: Three Color Temperature Options (3000K, 4500K, 6000K)



Figure 7: Reversible Motor for Summer and Winter Modes

6.2 Mobile App Control

The fan can also be controlled via a mobile application. Scan the QR code in the video or refer to the separate app instructions for download and pairing.

Your browser does not support the video tag.

Video 1: APP Controls Connection Display (Model 6669)

This video demonstrates how to connect and control your Surtime ceiling fan using the mobile application, including language settings, device pairing, and basic fan/light operations.

- Smart Memory Function: The fan remembers your preferred brightness and color settings. Turn off the light for at least 10 seconds for settings to be saved. Turning on the light within 10 seconds will change the color temperature.
- Wall Switch Limitation: When using a wall switch, only light control can be performed. Full fan and light features require the remote or app.

7. MAINTENANCE

Regular maintenance ensures optimal performance and longevity of your ceiling fan.

- **Cleaning:** To clean the fan, wipe with a soft, damp cloth. Do not use abrasive cleaners or solvents, as they may damage the finish or electrical components.
- **Blade Care:** Periodically check the fan blades for dust accumulation. Clean gently to maintain balance and airflow.
- **Motor:** The fan features a copper motor designed for stable power and low noise, requiring minimal maintenance.

8. TROUBLESHOOTING

If you experience issues with your Surtime ceiling fan, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Fan does not operate	No power supply; Loose wiring; Remote control battery low/dead.	Check circuit breaker; Ensure all connections are secure; Replace remote control batteries.
Light does not turn on	Loose wiring; Light kit issue; Wall switch limitation.	Check wiring connections; Ensure light kit is properly installed; Remember wall switch only controls light, not fan.
Fan wobbles	Loose blades; Improper mounting; Unbalanced blades.	Ensure all blade screws are tight; Verify mounting bracket is secure; Use a balancing kit if necessary.
Remote/App not responding	Pairing issue; Obstruction; Battery issue.	Re-pair the remote/app (refer to section 6.2 and Video 1); Ensure no obstructions between remote/phone and fan; Check/replace batteries.

If the problem persists after attempting these solutions, please contact Surtime customer support for assistance.

9. WARRANTY AND SUPPORT

Surtime stands by the durability and performance of its products. Your ceiling fan comes with a worry-free 1-year warranty on quality-related issues.

For any questions, concerns, or technical support, please do not hesitate to contact Surtime customer service. You can often find contact information on the product packaging or by visiting the official Surtime store on Amazon.

For additional support and FAQs, you may also visit the Surtime Store on Amazon.

© 2025 Surtime. All rights reserved.



Surtime Fan Light Pro App Instructions and Control Guide

Learn how to connect and control your Surtime fan light using the Fan Light Pro mobile application. This guide covers app installation, device pairing, and feature operation.



Surtime Ceiling Fan Installation and Operation Guide

Comprehensive installation instructions and operational guide for the Surtime ceiling fan, including safety precautions, package contents, assembly steps, troubleshooting, and warranty information.



Ceiling Fan 6669-42" Owner's Manual and Installation Guide

Comprehensive owner's manual and installation guide for the 6669-42" Ceiling Fan, covering safety precautions, installation steps, maintenance, troubleshooting, and remote control operation.



Playmobil 6669 Water Park Building Instructions

Detailed assembly instructions for the Playmobil 6669 Water Park playset, including all parts and steps for construction.