



Manuals.plus /

› Olakids /

› OLAKIDS Licensed Maserati 3-in-1 Push Car Instruction Manual (Model TQ10324)

Olakids TQ10324

OLAKIDS Licensed Maserati 3-in-1 Push Car Instruction Manual

Model: TQ10324

INTRODUCTION

Thank you for choosing the OLAKIDS Licensed Maserati 3-in-1 Push Car. This versatile ride-on toy is designed to provide a fun and engaging experience for toddlers aged 18 months to 5 years, adapting to their developmental stages. It can be used as a push car, a walker, or a sliding car, offering multiple modes of play and support.



Image: The OLAKIDS Licensed Maserati 3-in-1 Push Car in pink, showcasing its sleek design.

SAFETY INFORMATION

- **Parental Supervision:** Always ensure children use the push car under direct adult supervision.
- **Age and Weight Limits:** Suitable for toddlers 1.5 to 5 years old, with a maximum loading capacity of 55 lbs.
- **Stability:** The anti-tipping device is designed to enhance stability and protect children during use.
- **Material Safety:** Made from premium PP material, free from BPA, PVC, Phthalates, Lead, Latex, and Formaldehyde. Complies with US CPSIA and ASTM requirements.
- **Environment:** Use on flat, clear surfaces, away from traffic, stairs, and steep inclines.
- **Batteries:** Music and lights require 2 x AA 1.5V batteries (not included). Ensure batteries are installed correctly and kept away from children.

PACKAGE CONTENTS

Please ensure all parts are present before beginning assembly:

- Main Car Body
- Steering Wheel

- Removable Parent Control Handle
- Safe Guardrails (2 pieces)
- Foot Pedal/Footrests (2 pieces)
- Universal Wheels (2 pieces, for parent control mode)
- Assembly Hardware (screws, pins)

ASSEMBLY INSTRUCTIONS

Follow these steps to assemble your OLAKIDS Push Car. For a visual guide, please refer to the installation video below.

Step-by-Step Guide:

1. **Attach Footrests:** Securely attach the footrests to the designated slots on both sides of the car body.
2. **Install Universal Wheels:** If using the parent control mode, attach the two universal wheels to the underside of the car, near the rear.
3. **Mount Steering Wheel:** Insert the steering wheel column into the opening on the car's dashboard. Secure it with the provided hardware.
4. **Attach Guardrails:** Connect the safe guardrails to the sides of the seat area. Ensure they click firmly into place.
5. **Insert Parent Control Handle:** Slide the removable parent control handle into the rear slot behind the seat. Adjust to the desired height and secure.
6. **Battery Installation:** Open the battery compartment (usually under the steering wheel or seat) and insert 2 x AA 1.5V batteries for music and horn functions. Close the compartment securely.

Installation Video:

Your browser does not support the video tag.

Video: A detailed guide on how to install the OLAKIDS 3-in-1 Licensed Maserati Ride on Push Car, demonstrating each assembly step.

OPERATING INSTRUCTIONS

3-in-1 Functionality:

- **Push Car Mode:** For younger toddlers, keep the parent control handle, guardrails, and footrests attached. Parents can steer and push the car. The universal wheels allow for easy maneuverability.
- **Walker Mode:** As your child grows and begins to walk, the parent control handle can be removed. The guardrails provide support, and the child can use their feet to propel the car forward.
- **Sliding Car Mode:** For independent riders, remove the parent control handle, guardrails, and footrests. The child can sit on the seat and use their feet to slide and steer the car.

3 in 1 Design

Grow up with Children



Image: Illustration showing the three convertible modes of the push car: stroller, walking car, and ride-on sliding.

Steering Control:

- **Parent Control:** The removable push handle allows parents to control the direction and movement of the car.
- **Child Control:** The steering wheel has a limited rotation range, allowing children to practice steering while maintaining safety.

2 Steering Modes



Parents Control Push

with detachable universal wheels

Kids Sliding

Image: Depiction of the two steering modes: parent-controlled pushing and child-controlled sliding.

Interactive Features:

- **Music and Horn:** Press the buttons on the steering wheel to activate the horn and built-in music. (Requires 2 x AA 1.5V batteries, not included).
- **Under-Seat Storage:** Lift the seat to access a convenient storage compartment for toys, snacks, or other small items.
- **Handle Hook:** The push handle includes a hook for hanging small bags or items, freeing parents' hands.

Fun Driving Sounds

2 AA batteries are required (not included)



Image: Close-up of the steering wheel, highlighting the music and horn buttons for interactive play.

Underseat Storage Space



Image: The under-seat storage compartment, shown open and filled with toys.

MAINTENANCE

- **Cleaning:** Wipe down the car body with a damp cloth and mild soap. Avoid harsh chemicals.
- **Storage:** Store the push car in a dry, cool place away from direct sunlight when not in use.
- **Battery Care:** Remove batteries if the toy will not be used for an extended period to prevent leakage.

TROUBLESHOOTING

- **No Sound/Lights:** Check if 2 x AA 1.5V batteries are installed correctly and are not depleted. Replace if necessary.
- **Difficulty Steering:** Ensure all wheel components are securely attached and free from obstructions.
- **Loose Parts:** Periodically check all screws and connections to ensure they are tight and secure.

SPECIFICATIONS

Product Dimensions	36.5 x 16.5 x 35 inches
Item Weight	8 pounds
Item Model Number	TQ10324
Manufacturer Recommended Age	18 months and up
Max Loading Capacity	55 lbs
Batteries Required	2 AA batteries (not included)
Material	Premium PP Plastic



Image: Detailed product size and weight capacity information for the push car.

WARRANTY AND SUPPORT

For warranty information or customer support, please refer to the contact details provided with your purchase or visit the official Olakids website. Keep your purchase receipt for any warranty claims.

