

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

> [THINK 30](#) /

> [THINK 30 Tall Bathroom Storage Cabinet WF312727AAE Instruction Manual](#)

THINK 30 WF312727AAE

THINK 30 Tall Bathroom Storage Cabinet

Model: WF312727AAE

Brand: THINK 30

IMPORTANT SAFETY INFORMATION

Please read all instructions carefully before assembly and use. Keep this manual for future reference.

- **Anti-toppling Device:** Always secure the cabinet to the wall using the provided anti-toppling device to prevent accidental tipping. This is crucial for safety, especially in households with children or pets.
- **Weight Distribution:** Distribute weight evenly across shelves and in the drawer. Do not overload the cabinet.
- **Placement:** Place the cabinet on a flat, stable, and level surface.
- **Assembly:** Ensure all parts are correctly assembled and fasteners are tightened securely before use. Periodically check and re-tighten fasteners as needed.
- **Children:** Do not allow children to climb on or play with the cabinet.

PRODUCT DIMENSIONS

Refer to the diagram below for detailed product dimensions.



Figure 1: Cabinet Dimensions (11"D x 22"W x 67.3"H)

PARTS LIST

Verify that all parts are present before beginning assembly. If any parts are missing or damaged, contact customer support.

1. Top Panel
2. Bottom Panel
3. Side Panels (2)
4. Back Panels (Upper & Lower)
5. Fixed Shelf (1)
6. Adjustable Shelves (2)
7. Drawer Front Panel
8. Drawer Side Panels (2)
9. Drawer Back Panel
10. Drawer Bottom Panel
11. Upper Cabinet Door (1)
12. Lower Cabinet Door (1)

HARDWARE LIST

Ensure all hardware components are included in the package.

1. Cam Locks and Pins
2. Wood Dowels
3. Various Screws (for panels, hinges, drawer slides, knobs)
4. Drawer Slide Rails (2 sets)
5. Door Hinges (4 sets)
6. Metal Knobs (2)
7. Magnetic Door Catches (2)
8. Anti-toppling Strap and Wall Anchors
9. Shelf Pins (for adjustable shelves)



Figure 2: Key Hardware Components

TOOLS REQUIRED (NOT INCLUDED)

- Phillips Head Screwdriver

- Hammer (optional, for dowels)
- Pencil
- Measuring Tape
- Drill (for wall anchors, if not pre-drilled)

ASSEMBLY INSTRUCTIONS

Follow these steps carefully for proper assembly. It is recommended to assemble the cabinet with two people.

1. **Prepare Panels:** Insert wood dowels and cam lock pins into the pre-drilled holes on the side panels, top panel, and bottom panel.
2. **Assemble Base Frame:** Connect the bottom panel to the side panels using cam locks. Ensure they are securely fastened.
3. **Install Fixed Shelf:** Attach the fixed shelf to the side panels, typically in the middle section, using cam locks.
4. **Assemble Top Frame:** Connect the top panel to the side panels using cam locks.
5. **Attach Back Panels:** Slide the back panels into the grooves on the rear of the cabinet frame. Secure them with small nails or screws if provided.
6. **Assemble Drawer:**
 - a. Attach the drawer side panels to the drawer back panel and drawer front panel.
 - b. Slide the drawer bottom panel into the grooves.
 - c. Install the drawer slide rails onto the drawer sides and the corresponding cabinet interior.
 - d. Attach the metal knob to the drawer front.



Figure 3: Drawer Assembly Detail

7. Install Cabinet Doors:

- a. Attach the door hinges to the cabinet doors.
- b. Mount the doors to the cabinet frame using the hinges. Adjust as necessary for proper alignment.
- c. Install the metal knobs onto the doors.
- d. Attach the magnetic door catches to the cabinet frame and doors to ensure they close securely.




Figure 4: Door Knob Detail

- 8. Install Adjustable Shelves:** Insert shelf pins into the desired pre-drilled holes inside the cabinet sections. Place the adjustable shelves on top of the pins.

9. **Attach Anti-toppling Device:** Position the cabinet in its desired location. Secure the anti-toppling strap to the top rear of the cabinet and then to a wall stud using the provided wall anchors and screws. This step is critical for safety.

AMPLE STORAGE SPACE



Towels / Shampoo / Soaps / Body Lotion / Tissue

Figure 5: Cabinet Interior with Adjustable Shelves

OPERATING INSTRUCTIONS

- **Opening/Closing Doors:** Gently pull the metal knobs to open the cabinet doors. Push the doors firmly to close them, allowing the magnetic catches to engage.
- **Using the Drawer:** Pull the metal knob on the drawer front to open. Push the drawer back in until it is fully closed. The slide rails ensure smooth operation.
- **Adjusting Shelves:** The adjustable shelves in the lower cabinet can be moved to three different heights. To adjust, remove items from the shelf, lift the shelf, remove the shelf pins, reinsert the pins into the desired holes, and then place the shelf back on the pins.

CARE AND MAINTENANCE

- **Cleaning:** Wipe the cabinet surfaces with a soft, damp cloth. Avoid using harsh chemicals or abrasive cleaners, as they may damage the painted finish.
- **Spills:** Promptly wipe up any spills to prevent water damage to the MDF board. The painted finish provides water resistance, but prolonged exposure to moisture should be avoided.

- **Inspection:** Periodically check all fasteners and connections to ensure they remain tight. Re-tighten if necessary.
- **Avoid Direct Sunlight:** Prolonged exposure to direct sunlight may cause fading or discoloration of the finish.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Cabinet wobbles or is unstable.	Uneven floor; loose fasteners; anti-toppling device not installed.	Ensure cabinet is on a level surface. Tighten all assembly fasteners. Install the anti-toppling device securely to the wall.
Drawer does not slide smoothly.	Drawer slides misaligned; debris in slides; overloaded drawer.	Check alignment of drawer slides and re-adjust if necessary. Clean any debris from the slide rails. Reduce the weight in the drawer.
Cabinet doors do not close properly.	Hinges misaligned; magnetic catches not engaging; obstruction.	Adjust door hinges for proper alignment. Ensure magnetic catches are correctly positioned and functioning. Remove any obstructions.

PRODUCT SPECIFICATIONS

Brand	THINK 30
Model Name	Cabinet (WF312727AAE)
Color	Grey
Material	Engineered Wood (MDF boards)
Finish Type	Painted
Product Dimensions	11"D x 22"W x 67.3"H
Item Weight	62 Pounds
Mounting Type	Floor Mount (Freestanding)
Number of Shelves	3 (including 2 adjustable)
Special Feature	Scratch Resistant, Water-proof Surface, Adjustable Shelves, Anti-toppling Device
Assembly Required	Yes

WARRANTY AND SUPPORT

For warranty information or assistance with your THINK 30 Tall Bathroom Storage Cabinet, please refer to the documentation included with your purchase or contact the retailer where the product was purchased. For general inquiries or support, you may also visit the THINK 30 brand store online.

Please retain your proof of purchase for any warranty claims.

