

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [MSI](#) /

› [MSI Thin 15 Gaming Laptop User Manual - Model Thin 15](#)

MSI Thin 15

MSI Thin 15 Gaming Laptop User Manual

Model: Thin 15

INTRODUCTION

This manual provides essential information for setting up, operating, maintaining, and troubleshooting your MSI Thin 15 Gaming Laptop. Please read this guide thoroughly to ensure optimal performance and longevity of your device.

WHAT'S IN THE BOX

Upon unboxing, verify that all components are present:

- MSI Thin 15 Gaming Laptop
- Power Adapter and Cable
- HDMI Cable (Accessory)
- iCarp Type-C to HDTV 3-in-1 Adapter (Accessory, if included with your specific package)
- Quick Start Guide (if applicable)
- Warranty Card (if applicable)



Image: The MSI Thin 15 Gaming Laptop, showcasing its design and included accessories like the iCarp adapter.



Image: The iCarp Type-C to HDTV 3-in-1 Adapter, an included accessory for display connectivity.

SETUP

1. **Connect Power:** Plug the power adapter into the laptop's power input port and then into a wall outlet.

2. **Initial Boot:** Open the laptop lid and press the power button. The system will guide you through the Windows 11 initial setup process. Follow the on-screen instructions to configure your operating system, network, and user account.
3. **Driver Installation:** After Windows setup, it is recommended to install or update the latest drivers and utilities from the official MSI website or through the pre-installed MSI software (e.g., MSI Center) to ensure optimal performance, especially for the NVIDIA GeForce RTX 4050 graphics card.
4. **Connect Peripherals:** Connect any external devices such as a mouse, keyboard, or external display using the available ports.



Image: Side view of the MSI Thin 15 laptop, highlighting the various input/output ports for connecting power and peripherals.

OPERATING INSTRUCTIONS

Keyboard and Touchpad

- **Backlit Keyboard:** Adjust keyboard backlight settings through the MSI Center software or dedicated function keys (Fn + F key combination, refer to your specific model's keyboard layout).
- **Touchpad Gestures:** Utilize Windows precision touchpad gestures for navigation and multi-touch functions.

Display and Graphics

Your laptop features a 15.6" FHD (1920x1080) IPS 144Hz display. Ensure the 144Hz refresh rate is enabled in Windows display settings for the smoothest visual experience, especially during gaming.

- To adjust refresh rate: Right-click on the desktop > Display settings > Advanced display settings > Choose refresh rate.
- The NVIDIA GeForce RTX 4050 graphics card is dedicated for high-performance tasks and gaming. Ensure NVIDIA drivers are up-to-date for optimal performance.

TYPE-C TO HDTV 3 in 1 Adapter

HDTV+USB 3.0+Type-c(PD)

iCarp



HDTV
4K

3.0
USB

iCarp

Connect your USB-C computer
to an HDTV-equipped display

Image: The MSI Thin 15 laptop displaying a high-fidelity game scene, demonstrating its gaming capabilities.



Image: The MSI Thin 15 laptop showcasing the Xbox PC Game Pass interface, indicating its readiness for gaming.

Audio

The laptop supports Hi-Res Audio. Adjust sound settings via Windows Sound settings or the pre-installed audio management software.

Connectivity

- **USB Ports:** Utilize the 3 x USB-A 3.2 and 1 x USB-C 3.2 ports for connecting various USB devices.
- **HDMI:** Connect to an external monitor or TV using the HDMI port (supports 4K @ 30Hz).
- **Ethernet:** For a stable wired internet connection, use the RJ45 Ethernet port.
- **Wireless:** Connect to Wi-Fi networks and Bluetooth devices (Bluetooth 5.2) through Windows settings.

MAINTENANCE

Cleaning

- **Screen:** Use a soft, lint-free cloth lightly dampened with water or a screen cleaner. Avoid harsh chemicals.
- **Chassis:** Wipe the exterior with a soft, dry cloth. For stubborn marks, use a slightly damp cloth.
- **Vents:** Regularly clean the cooling vents with compressed air to prevent dust buildup, which can impede airflow and lead to overheating.



Image: The underside of the MSI Thin 15 laptop, showing the cooling vents that require regular cleaning for optimal thermal performance.

Battery Care

- Avoid fully discharging the battery frequently.
- If storing the laptop for an extended period, ensure the battery is charged to around 50-60%.
- Use the original power adapter for charging.

Software Updates

- **Windows Updates:** Regularly check for and install Windows updates to ensure system stability and security.
- **Driver Updates:** Keep your graphics drivers (NVIDIA) and other system drivers updated. Use MSI Center or visit the MSI support website.

TROUBLESHOOTING

If you encounter issues, try the following basic troubleshooting steps:

- **No Power:** Ensure the power adapter is securely connected to both the laptop and a working power outlet. Try a different outlet.
- **Display Issues:** If the screen is blank, try connecting an external monitor to check if the laptop is outputting video. Update graphics drivers.
- **Performance Slowdown:** Check for background applications consuming resources. Ensure cooling vents are clear. Consider using a cooling pad.
- **Network Connectivity:** Verify Wi-Fi or Ethernet cable connections. Restart your router/modem. Update network drivers.
- **System Restore:** Windows 11 offers system restore points that can revert your system to a previous working state

without affecting personal files.

For more advanced issues or persistent problems, please refer to the official MSI support website or contact their customer service.

SPECIFICATIONS

Feature	Detail
Model Name	MSI Thin 15
Processor	13th Gen Intel Octa-core i5-13420H (2.1 GHz)
RAM	64GB DDR4
Storage	2TB SSD
Graphics	Dedicated NVIDIA GeForce RTX 4050 6GB
Display	15.6" FHD (1920x1080) IPS 144Hz
Operating System	Microsoft Windows 11 Home
Ports	3 x USB-A 3.2, 1 x USB-C 3.2, 1 x HDMI (supports 4K @ 30Hz), 1 x RJ45 Ethernet
Wireless Connectivity	Bluetooth 5.2
Keyboard	Backlit Keyboard
Audio	Hi-Res Audio
Webcam	Yes (720p HD)
Battery	3-cell 52.4Wh
Dimensions (LxWxH)	9.99" x 14.13" x 0.85"
Weight	4.1 lbs

WARRANTY AND SUPPORT

For detailed warranty information, please refer to the warranty card included with your product or visit the official MSI support website. MSI provides technical support and resources for their products.

MSI Support Website: <https://www.msi.com/support>

It is recommended to register your product on the MSI website to receive updates and support.

