

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

> [Shark](#) /

> [Shark Anti Hair Wrap Plus Upright Corded Pet Vacuum NZ780UKT User Manual](#)

## Shark NZ780UKT

# Shark Anti Hair Wrap Plus Upright Corded Pet Vacuum User Manual

Model: NZ780UKT

## INTRODUCTION

---

This manual provides essential information for the safe and efficient operation, maintenance, and troubleshooting of your Shark Anti Hair Wrap Plus Upright Corded Pet Vacuum, Model NZ780UKT. Please read this manual thoroughly before first use and retain it for future reference.

The Shark NZ780UKT is designed for comprehensive home cleaning, featuring an XL 2.5L dustcup, Anti-Allergen Complete Seal, and Anti-Odour Technology. Its Powered Lift-Away feature allows for versatile cleaning across various surfaces, including hard floors and carpets, and is specifically engineered for homes with pets.

## IMPORTANT SAFETY INSTRUCTIONS

---

When using an electrical appliance, basic precautions should always be observed, including the following:

- Read all instructions before using your vacuum cleaner.
- Do not use outdoors or on wet surfaces.
- Unplug from electrical outlet when not in use and before servicing.
- Do not allow to be used as a toy. Close attention is necessary when used by or near children.
- Use only as described in this manual. Use only manufacturer's recommended attachments.
- Do not use with damaged cord or plug. If appliance is not working as it should, has been dropped, damaged, left outdoors, or dropped into water, return it to SharkNinja Operating LLC for examination, repair, or adjustment.
- Do not pull or carry by cord, use cord as a handle, close a door on cord, or pull cord around sharp edges or corners. Do not run appliance over cord. Keep cord away from heated surfaces.
- Do not unplug by pulling on cord. To unplug, grasp the plug, not the cord.
- Do not handle plug or vacuum cleaner with wet hands.
- Do not put any object into openings. Do not use with any opening blocked; keep free of dust, lint, hair, and anything that may reduce airflow.
- Keep hair, loose clothing, fingers, and all parts of body away from openings and moving parts.

- Turn off all controls before unplugging.
- Use extra care when cleaning on stairs.
- Do not use to pick up flammable or combustible liquids, such as gasoline, or use in areas where they may be present.
- Do not pick up anything that is burning or smoking, such as cigarettes, matches, or hot ashes.
- Do not use without dust cup and/or filters in place.

## SETUP AND ASSEMBLY

---

Your Shark NZ780UKT vacuum cleaner comes with several components that easily click together for quick assembly.

1. Insert the wand into the floor nozzle until it clicks securely into place.
2. Slide the handle onto the top of the wand until it clicks.
3. Attach the hose to the back of the vacuum pod by pushing it in until it clicks.
4. Store the included accessories (Crevice Tool, Multi-Surface Tool, Pet Power Brush) on the onboard storage posts.





*Image: The fully assembled Shark NZ780UKT upright vacuum cleaner, ready for use.*



## INCLUDED ACCESSORIES

Crevice Tool, Multi Surface Tool, Pet Power Brush.

*Image: The Shark NZ780UKT vacuum cleaner alongside its included accessories: Crevice Tool, Multi-Surface Tool, and Pet Power Brush.*

## OPERATING INSTRUCTIONS

---

### Powering On and Floor Settings

Plug the power cord into a suitable electrical outlet. The vacuum features an 8-meter cord for extended reach. Press the power button to turn on the vacuum. You can switch between two cleaning modes: Hard Floor and Carpet, using the selector on the handle.



## 2 FLOOR SETTINGS

Effectively clean hard floors, carpet and rugs

*Image: The Shark NZ780UKT vacuum cleaner being used on a hard floor, demonstrating its versatility for different floor types.*



## 8M POWER CORD

Easily move between rooms

*Image: A person using the Shark NZ780UKT vacuum, highlighting the convenience of its long 8-meter power cord for cleaning multiple rooms.*

### **Lift-Away Mode**

To clean hard-to-reach areas, simply press the Lift-Away button to detach the main pod from the floor nozzle. This transforms the upright vacuum into a portable canister vacuum, ideal for cleaning stairs, upholstery, and high-up areas with the wand or hose.



## LIFT-AWAY

Go portable to easily clean stairs, sofas & under furniture

*Image: A person demonstrating the Lift-Away feature, using the portable pod to clean stairs and reaching high shelves with the wand.*

### Anti Hair Wrap Plus Technology

The Anti Hair Wrap Plus brushroll actively removes hair from itself as you clean, preventing tangles and maintaining optimal performance. This feature is particularly beneficial for homes with pets.



**ANTI  
HAIR WRAP  
PLUS**

## REMOVES HAIR FROM THE BRUSHROLL AS YOU CLEAN

Specially engineered bristles for powerful hair removal  
and anti hair wrap

*Image: The Shark NZ780UKT vacuum on a carpet, illustrating the Anti Hair Wrap Plus technology effectively picking up debris without tangling hair on the brushroll.*

### **Anti-Odour Technology**

The integrated Anti-Odour Technology helps to guard against bad odours inside the vacuum, ensuring a fresher-smelling home. This is especially useful for pet owners.



## ANTI-ODOUR TECHNOLOGY

Guards against bad odours in your vacuum to help freshen your home.

*Image: A person and child in a living room with the Shark NZ780UKT, highlighting the Anti-Odour Technology feature for a fresher home environment.*

### Anti-Allergen Complete Seal

The Anti-Allergen Complete Seal system traps 99.9% of dust and allergens inside the vacuum, preventing them from being released back into the air. This provides a cleaner environment for allergy sufferers.



\*Based on IEC62885-2 (5.14) at 0.3 - 10 microns

*Image: A visual representation of the Anti-Allergen Complete Seal technology within the Shark vacuum, illustrating how it captures and traps 99.9% of dust and allergens.*

## MAINTENANCE

---

### Emptying the Dust Cup

The XL 2.5L dust cup should be emptied regularly, ideally after each use or when debris reaches the MAX FILL line. To empty, press the dust cup release latch and lift the dust cup off the vacuum pod. Hold the dust cup over a waste bin and press the bottom release latch to open the bottom flap and empty contents. Close the flap securely before reattaching.



## EXTRA LARGE 2.5L CAPACITY

Allows you to clean your whole home with fewer trips to the waste bin to empty debris.

*Image: A person and child in a living room with a dog, illustrating the large 2.5L dust cup capacity of the Shark NZ780UKT vacuum, allowing for fewer emptying trips.*

### Cleaning Filters

Regularly clean the pre-motor and post-motor filters to maintain optimal suction. Rinse filters with cold water only. Allow filters to air-dry completely for at least 24 hours before reinstalling them to prevent damage to electronic components.

- **Pre-Motor Filters (Foam & Felt):** Clean every 3 months. Remove the dust cup, then pull out the foam and felt filters. Tap off loose dirt, then rinse thoroughly.
- **Post-Motor HEPA Filter:** Clean once a year. Located at the bottom of the vacuum. Remove the filter cover, then pull out the HEPA filter. Tap off loose dirt, then rinse thoroughly.

### Brushroll Maintenance

While the Anti Hair Wrap Plus brushroll is designed to be self-cleaning, occasionally check for any debris or hair that may have become wrapped around it. If necessary, use scissors to carefully cut away any stubborn tangles. Ensure the vacuum is unplugged before performing any maintenance on the brushroll.

## TROUBLESHOOTING

Problem	Possible Cause	Solution
Vacuum not picking up debris or no suction.	Dust cup is full. Filters need cleaning. Hose or nozzle is clogged. Brushroll is obstructed.	Empty the dust cup. Clean and dry all filters. Check hose, wand, and nozzle for blockages. Remove any obstructions from the brushroll.
Vacuum turns off on its own.	Overheating due to blockage or dirty filters.	Turn off and unplug the vacuum. Empty dust cup, clean filters, and check for blockages. Allow the vacuum to cool for at least 45 minutes before restarting.
Brushroll not spinning.	Brushroll is jammed. Vacuum is in Hard Floor mode.	Clear any obstructions from the brushroll. Ensure the vacuum is in Carpet mode for brushroll activation.

## SPECIFICATIONS


Feature	Detail
Brand	Shark
Model Number	NZ780UKT
Colour	Smoky Grey
Product Dimensions (H x D x W)	118 x 26 x 33 cm
Item Weight	6.5 kg
Dust Cup Capacity	2.5 litres (XL)
Power / Wattage	700 watts
Voltage	240 Volts
Cord Length	8 meters
Special Features	Anti Hair Wrap Plus, Anti-Odour Technology, Anti-Allergen Complete Seal, Powered Lift-Away, Pet Power Brush
Included Tools	Crevice Tool, Multi-Surface Tool, Pet Power Brush

Feature	Detail
---------	--------

## WARRANTY AND SUPPORT

---

Your Shark NZ780UKT vacuum cleaner comes with a **5-year guarantee** upon registration with Shark (UK & ROI only). To register your product and for full terms and conditions, please visit the official Shark website or refer to the registration card included in your product packaging.



*Image: A badge indicating a 5-year guarantee, available upon product registration with Shark.*

For customer support, replacement parts, or further assistance, please contact Shark customer service through their official website or the contact information provided in your product documentation.