

[Manuals.plus](#) /

› [LUXOAK](#) /

› LUXOAK Full LED Bed Frame with Bookcase Headboard and Storage Drawers - Instruction Manual

LUXOAK BPB007

LUXOAK Full LED Bed Frame with Bookcase Headboard and Storage Drawers

Model: BPB007

Brand: LUXOAK

INTRODUCTION

This manual provides detailed instructions for the assembly, operation, and maintenance of your LUXOAK Full LED Bed Frame. This bed frame features a multi-functional bookcase headboard with integrated LED lighting and a charging station, along with four under-bed storage drawers. Please read this manual thoroughly before beginning assembly or use to ensure proper setup and safe operation.

IMPORTANT SAFETY INFORMATION

- **Weight Capacity:** Do not exceed a total weight of 800 pounds on the bed frame.
- **Assembly Caution:** Be cautious of sharp edges, especially when assembling. Follow assembly instructions carefully to prevent instability.
- **Charging Station:** Use the charging station with caution to avoid fire hazards. Ensure all devices are compatible and cables are in good condition.
- **General Safety:** Keep small parts away from children. Ensure all connections are secure before use.

PACKAGE CONTENTS

Before assembly, verify that all components listed below are present. If any parts are missing or damaged, please contact customer support.

- Headboard (with integrated bookcase and charging station)
- Bed Frame Side Rails
- Metal Slats
- Under-bed Storage Drawers (x4)
- Assembly Hardware (screws, bolts, tools if included)

- LED Light Strip and Remote Control
- Instruction Manual

Note: The bed frame may be delivered in multiple packages on different days.



Image: Overview of the bed frame with key dimensions and 800 lbs weight capacity indicated.

SETUP AND ASSEMBLY

Assembly is required for this bed frame. It is recommended that two adults perform the assembly. Follow the provided assembly instructions carefully, step-by-step, to ensure structural integrity and stability.

1. **Prepare the Area:** Clear a spacious area for assembly. Lay out all parts and hardware.
2. **Assemble the Headboard:** Attach the bookcase sections to the main headboard frame. Ensure the charging station is correctly positioned.
3. **Connect Side Panels:** Securely attach the side rails to the headboard and footboard.
4. **Install Slats:** Place the metal slats into the designated slots on the side rails. The slats are designed for easy installation and noise-free support.
5. **Assemble Drawers:** Construct the four under-bed storage drawers. These drawers are designed to roll freely under the bed and feature double latches for secure closure.
6. **Install LED Lights:** Affix the LED light strip to the designated area on the headboard. Connect it to the power source.

Tip: Some users find it easier to assemble the upholstered headboard sections while the headboard is upright, rather than laying it flat.

FULL

L×W×H
85"X55.2"X51.2"

Weight Capacity
800LBS






Image: Exploded view of the bed frame components and assembly steps.

Easy Assembly



No Box Spring Needed



Noise Free

Image: Detail showing the easy installation and noise-free design of the metal slats.

LED Lights

The integrated LED lights in the bookcase headboard offer customizable lighting options to enhance your bedroom ambiance.

- **Control:** Use the provided remote control or a compatible smartphone application (if available) to operate the LED lights.
- **Color Options:** Choose from over 60,000 colors to match your mood or decor.
- **Brightness Adjustment:** Adjust the brightness level to your preference.
- **Dynamic Modes:** Select from various dynamic lighting modes for different effects.
- **Music Mode:** Some models may feature a music synchronization mode.
- **Timer Function:** Set a timer for the lights to automatically turn off.



Image: The bed frame showcasing LED lights with remote and app control features.

Charging Station

The built-in charging station provides convenient access to power for your electronic devices.

- **Outlets:** Equipped with 2 AC outlets (125V/12A).
- **USB Ports:** Includes 1 USB port and 1 Type-C port (5V/2A) for charging phones, tablets, and other compatible devices.
- **Power Cord:** Features a 4.7-foot power cord for connection to a wall outlet.



Image: Detail of the integrated charging station with AC outlets and USB ports.

Storage Features

Maximize your bedroom space with the bed frame's versatile storage options.

- **Bookcase Headboard:** Features 5 open storage spaces for books, decor, and personal items.
- **Hidden Storage:** Two hidden large spaces behind the upholstered panels of the headboard provide discreet storage. These panels open independently.

- **Under-bed Drawers:** Four rolling drawers beneath the bed offer additional storage for clothing, linens, or other belongings. These drawers are not attached to the frame and roll on the floor.



Image: The bookcase headboard with open shelves and hidden storage behind the upholstered panels.



4 Storage Lockable Drawers

Image: The four under-bed storage drawers, demonstrating their capacity.

MAINTENANCE

Proper care will extend the life and appearance of your bed frame.

- **Cleaning:** Wipe engineered wood surfaces with a soft, damp cloth. Avoid harsh chemicals. For linen upholstered parts, spot clean with a mild fabric cleaner as needed.
- **Hardware:** Periodically check all bolts and screws to ensure they remain tight. Re-tighten if necessary.
- **LED Lights:** If LED lights malfunction, check the power connection and remote control batteries.
- **Drawers:** Keep the drawer wheels free of debris to ensure smooth operation.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Bed frame feels unstable or wobbly.	Loose hardware. Incorrect assembly.	Ensure all bolts and screws are securely tightened. Review assembly instructions to confirm all steps were followed correctly.
LED lights are not working.	Power connection issue. Remote control battery low. Faulty LED strip.	Check if the LED strip is properly plugged into the power source. Replace remote control batteries. If issues persist, contact customer support.
Charging station is not providing power.	Power cord not plugged in. Outlet issue. Device incompatibility.	Verify the bed frame's power cord is securely plugged into a working wall outlet. Test the outlet with another device. Ensure your device is compatible with the charging station's output.
Drawers do not roll smoothly.	Debris on wheels. Uneven floor surface. Overloaded drawer.	Clean any debris from the drawer wheels. Ensure the bed is on a level surface. Reduce the weight in the drawer if it is overloaded.

SPECIFICATIONS

Feature	Detail
Model Number	BPB007
Size	Full (Compatible with Full, Queen, King mattresses)
Product Dimensions (L x W x H)	85"L x 55.2"W x 51.2"H
Material	Engineered Wood, Metal, Linen Upholstery
Color	Distressed White
Weight Capacity	800 Pounds
Special Features	LED Lights, Charging Station (2 AC, 1 USB, 1 Type-C), Bookcase Headboard, 4 Under-bed Drawers, No Box Spring Needed
Assembly Required	Yes
Item Weight	125 Pounds



Image: Mattress recommendations for the bed frame, indicating suitable mattress thickness.

OFFICIAL PRODUCT VIDEO

Watch the official product video for a visual guide on the features and functionality of your LUXOAK bed frame.

Your browser does not support the video tag.

Video: "Farmhouse Bed Frame with Bookcase Headboard" by boliyangnet. This video demonstrates the storage features, charging station, and overall design of the bed frame.

CUSTOMER SUPPORT

For further assistance, missing parts, or warranty inquiries, please contact LUXOAK customer support. Refer to your purchase documentation for specific contact details.

Online resources and FAQs may also be available on the official LUXOAK website: [LUXOAK Store](#)

© 2023 LUXOAK. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0DLWYTNKH>

More documents and user manuals: <https://manuals.plus/>