

Edifier e25HD

Edifier e25HD PC Speakers User Manual

Model: e25HD

Brand: Edifier

1. INTRODUCTION

Thank you for purchasing the Edifier e25HD PC Speakers. This manual provides essential information for setting up, operating, and maintaining your speakers to ensure optimal performance and longevity. The e25HD speakers are designed to deliver high-resolution audio with versatile connectivity options, including Bluetooth 5.3 with LDAC, 3.5mm Aux, and Optical input.

End-to-end High Resolution Audio Process

The end-to-end audio process flow supports high resolution audio up to 24bit/96kHz.

The dual TI Class-D digital audio amplifiers provide the precise two-way active crossover, magnify high frequency signals and mid-low frequency signals separately, and manage DRC effectively.




Image: Edifier e25HD speakers positioned on a desktop, demonstrating their compact and modern aesthetic.

2. PACKAGE CONTENTS

Please verify that all items listed below are included in your package. If any items are missing or damaged, please contact Edifier customer support.




Image: A visual representation of the Edifier e25HD speaker package contents, including speakers, cables, remote, and documentation.

- Active Speaker (1)
- Passive Speaker (1)
- Remote Control (1)
- Power Adapter & Power Cable (1 set)
- 3.5mm to RCA Audio Cable (1)
- 3.5mm to 3.5mm Audio Cable (1)
- Fiber Optic Audio Cable (1)
- Speaker Connecting Cable (1)
- Cleaning Cloth (1)
- Quick Start Guide (1)
- Important Safety Instructions (1)

3. SETUP

3.1 Speaker Placement

Place the active speaker (with controls and input ports) on the right side and the passive speaker on the left side of your listening area. Ensure they are positioned at an optimal angle for sound projection. The speakers are designed with an upward tilt for optimal near-field listening.

3.2 Connecting the Speakers

Connect the active speaker to the passive speaker using the provided speaker connecting cable. Ensure a secure connection to both units.

3.3 Power Connection

Connect the power adapter to the active speaker's power input port, then plug the power cable into a wall outlet. The power indicator on the active speaker will illuminate.

Bass Radiators



1" Silk dome tweeters | 3" PP cone mid-low
3" Passive bass radiators x 2



74W RMS
Output power



AUX/Optical
Input



Bluetooth 5.3
Input

Image: The back panel of the active speaker, detailing the AUX/Optical input, power adapter port, and connection to the passive speaker.

4. OPERATING INSTRUCTIONS

4.1 Power On/Off

Press the power button on the active speaker or the remote control to turn the speakers on or off.

4.2 Volume Control

Adjust the volume using the '+' and '-' buttons on the active speaker or the volume controls on the remote. You can also control volume via the Edifier ConneX App.

4.3 Input Selection

Cycle through input modes (Bluetooth, AUX, Optical) by pressing the input selection button on the active speaker or the remote control. The LED indicator will change color to reflect the active input mode.

5. CONNECTIVITY

The Edifier e25HD speakers offer multiple connectivity options:

- **Bluetooth 5.3 with LDAC:** For high-resolution wireless audio streaming from compatible devices.
- **3.5mm AUX Input:** For connecting devices with a standard 3.5mm audio jack.
- **Optical Input:** For connecting to TVs, gaming consoles, or other devices with an optical audio output.

5.1 Bluetooth Pairing

1. Switch the speaker input mode to Bluetooth. The LED indicator will flash blue.
2. On your device (smartphone, tablet, PC), enable Bluetooth and search for 'EDIFIER e25HD'.
3. Select 'EDIFIER e25HD' to pair. Once connected, the LED indicator will glow solid blue.

5.2 Wired Connections

Use the appropriate cable (3.5mm to 3.5mm, 3.5mm to RCA, or Optical) to connect your audio source to the corresponding input port on the active speaker. Select the correct input mode on the speakers.



Image: A diagram showing how to connect the speakers to different devices using AUX, Optical, and Bluetooth inputs.

6. CONTROLS

The e25HD speakers offer multiple ways to control playback and settings:

- **Touch Controls:** Integrated touch-sensitive buttons on the active speaker for power, volume, and input selection.
- **Remote Control:** A dedicated remote for convenient control of volume, playback, connection mode, and power.

- **Edifier ConneX App:** A mobile application for advanced control and audio customization, including EQ settings.



Image: Overview of control methods: touch controls on the speaker, the included remote, and the Edifier ConneX mobile application.

7. AUDIO CUSTOMIZATION

The Edifier e25HD speakers allow for personalized audio experiences:

- **EQ Equalizer:** Use the Edifier ConneX App to custom tune the equalizer settings to your preference.
- **Preset Sound Effects:** Choose from three preset sound effects: Game, Music, and Movie, optimized for different content types.

8. MAINTENANCE

To ensure the longevity and optimal performance of your Edifier e25HD speakers, follow these maintenance guidelines:

- **Cleaning:** Use the provided cleaning cloth or a soft, dry cloth to wipe the speaker surfaces. Avoid using abrasive cleaners, waxes, or solvents.
- **Environment:** Keep the speakers away from direct sunlight, heat sources, and excessive moisture. Ensure adequate ventilation around the speakers.
- **Handling:** Handle the speakers with care. Avoid dropping them or subjecting them to strong impacts.

9. TROUBLESHOOTING

If you encounter any issues with your Edifier e25HD speakers, refer to the following common solutions:

Problem	Possible Cause	Solution
No sound	Power not connected; incorrect input selected; volume too low; cables loose.	Check power connection; select correct input mode; increase volume; ensure all cables are securely connected.

Problem	Possible Cause	Solution
Bluetooth connection fails	Speakers not in pairing mode; device Bluetooth off; interference.	Ensure speakers are in Bluetooth pairing mode (flashing blue LED); enable Bluetooth on your device; move closer to speakers; try re-pairing.
Distorted audio	Volume too high; poor audio source quality; loose cable connection.	Reduce volume; try a different audio source; check cable connections.
Remote control not working	Battery depleted; obstruction between remote and speaker.	Replace remote battery; ensure clear line of sight to the active speaker.

If the problem persists, please contact Edifier customer support for further assistance.

10. SPECIFICATIONS

Detailed technical specifications for the Edifier e25HD PC Speakers:

- **Model Name:** e25HD
- **Speaker Type:** Satellite, Near Field Powered Bookshelf Speakers
- **Speaker Maximum Output Power:** 74 Watts RMS
- **Frequency Response:** 50Hz-40kHz
- **Signal-to-Noise Ratio:** 85 dB
- **Tweeter Diameter:** 1 Inch Silk Dome
- **Woofers Diameter:** 3 Inch Full Range Driver
- **Passive Bass Radiators:** Dual 3 Inch
- **Connectivity Technology:** Bluetooth 5.3 (LDAC), Auxiliary (3.5mm), Optical
- **Bluetooth Range:** 10 Meters (33 feet)
- **Audio Output Mode:** Stereo (2.0 Surround Sound Channel Configuration)
- **Control Method:** App, Remote, Touch
- **Product Dimensions:** 8.4"D x 4.5"W x 8.8"H (per speaker)
- **Item Weight:** 7.3 pounds (total)
- **Material:** Aluminum, Metal, Plastic, Polyvinyl Chloride (PVC), Wood
- **Input Voltage:** 20 Volts
- **Indoor/Outdoor Usage:** Indoor

11. PRODUCT VIDEOS

Watch these official videos for a visual guide to the Edifier e25HD speakers.

Edifier e25HD Hi-Res Speakers with Passive Bass Radiators

Your browser does not support the video tag.

Video: This video provides an overview of the Edifier e25HD speakers, showcasing their design, color options, and highlighting key features like passive bass radiators and internal components.

Edifier e25HD Hi-Res Near Field Powered Speakers (74W)

Your browser does not support the video tag.

Video: A detailed video demonstrating the Edifier e25HD Hi-Res Near Field Powered Speakers, emphasizing their 74W output and high-fidelity audio capabilities.

12. WARRANTY AND SUPPORT

The Edifier e25HD PC Speakers come with a limited warranty. For specific warranty terms and conditions, please refer to the warranty card included in your package or visit the official Edifier website.

For technical support, troubleshooting assistance, or service inquiries, please contact Edifier customer support through their official website or the contact information provided in your product documentation.