

EUHOMY IF-1336TCL

EUHOMY 36 Inch Electric Fireplace

MODEL: IF-1336TCL USER MANUAL

[Safety](#)

[Contents](#)

[Features](#)

[Installation](#)

[Operation](#)

[Maintenance](#)

[Troubleshooting](#)

[Specifications](#)

[Warrant](#)

1. Important Safety Instructions

Please read all instructions before installing or using this electric fireplace. Failure to follow these instructions may result in electric shock, fire, or personal injury.

- **Electrical Safety:** Ensure the fireplace is connected to a properly grounded outlet. Do not overload circuits. Do not use with damaged cords or plugs.
- **Placement:** Maintain adequate clearance from combustible materials. Do not block air vents. Avoid placing near water sources.
- **Operation:** Do not operate if the unit is damaged. Keep children and pets away from the hot surface. Never leave the fireplace unattended while operating.
- **Maintenance:** Disconnect power before cleaning or performing any maintenance. Refer to the maintenance section for proper cleaning procedures.
- **Overheat Protection:** This fireplace is equipped with an automatic heat-off safety feature to prevent overheating. If the unit overheats, it will automatically shut off. Unplug the unit, wait 10-15 minutes, and then plug it back in.

2. Package Contents

Upon unpacking, please verify that all components listed below are present and undamaged:

- 1 x EUHOMY 36 Inch Electric Fireplace Unit
- 1 x Carbon Log Set
- 1 x Pack of Crystal Stones
- 1 x Remote Control
- 1 x Installation Manual
- Hardware Accessories for Installation

If any items are missing or damaged, please contact EUHOMY customer support immediately.

3. Product Features

The EUHOMY 36 Inch Electric Fireplace offers a blend of aesthetic appeal and functional design:

- **Multiple Installation Options:** Designed for both full recessing into a wall or wall-mounting, adapting to various home decor styles.
- **Adjustable Flame & Fuel Bed Colors:** Features 12 flame colors and 12 LED fuel bed colors, allowing for 144 color combinations.

- **Adjustable Flame Brightness:** Five independently adjustable flame brightness levels for customized ambiance.
- **Dual Heating Modes:** Energy-saving 750W mode and efficient 1500W heating mode.
- **Adjustable Thermostat:** Temperature range from 62°F to 82°F (17°C to 27°C).
- **Timer Control:** Programmable timer from 1 to 8 hours for automatic shut-off.
- **Dual Control Options:** Operate via the included remote control or the integrated touchscreen panel.
- **Quiet Operation:** Operates at a low noise level of approximately 45 decibels.
- **Safety Certified:** ETL Certificate Approved, includes automatic heat-off safety feature.
- **Realistic Flame Visuals:** High-intensity LED lights create dynamic and realistic flame effects.



Image: The EUHOMY 36 Inch Electric Fireplace, showcasing its sleek design and realistic flame effect in a contemporary setting.

4. Installation

The EUHOMY electric fireplace can be installed in two ways: fully recessed into a wall or wall-mounted. Choose the method that best suits your space and preferences.

4.1 Preparation

- Ensure the installation area is clean, dry, and free from obstructions.
- Verify that the electrical outlet is within reach of the power cord and meets the required specifications (120V, 60Hz, 15A circuit).
- Gather necessary tools: screwdriver, level, measuring tape, drill (if recessing).

4.2 Recessed Installation

For recessed installation, a wall opening with specific dimensions is required. Refer to the diagram below for precise measurements.

- **Required Hole Size:** Approximately 32.77 inches (width) x 16.54 inches (height) x 7.90 inches (depth).
- Carefully cut the opening in the wall according to the specified dimensions.
- Ensure there is a reserved plug length for easy connection.
- Slide the fireplace unit into the prepared opening and secure it using the provided hardware.

4.3 Wall-Mounted Installation

For wall-mounted installation, use the provided mounting bracket and hardware.

- Locate suitable wall studs for secure mounting.
- Attach the mounting bracket to the wall using the appropriate hardware.
- Carefully lift the fireplace unit and hang it onto the mounting bracket.
- Ensure the unit is level and securely fastened.



Image: Detailed dimensions and visual guide for both recessed and wall-mounted installation methods.

4.4 Fuel Bed Setup

After installation, place the carbon log set and crystal stones onto the fuel bed according to your preference.



Product Details



Image: Components of the fireplace including the crystal and log fuel bed, air vents, touchscreen, and power plug.

Your browser does not support the video tag.

Video: An official product video from EuhomyDirect demonstrating the features and appearance of the electric fireplace.

Your browser does not support the video tag.

Video: An official product video from EuhomyDirect illustrating the recessed and wall-mounted installation options for the electric fireplace.

5. Operating Instructions

The fireplace can be controlled using the touchscreen panel on the unit or the included remote control.

5.1 Control Panel & Remote Functions



Image: The fireplace's touchscreen control panel and remote control, highlighting key functions.

- **Power (On/Off):** Press the power button to turn the unit on or off.
- **Flame Color:** Cycle through 12 different flame colors.
- **Fuel Bed Color:** Cycle through 12 different LED fuel bed colors.
- **Dimmer/Brightness:** Adjust the flame brightness through 5 levels.
- **Heater:** Toggle between 750W (LL) and 1500W (HH) heating modes.
- **Temperature:** Adjust the thermostat from 62°F to 82°F.
- **Timer:** Set the automatic shut-off timer from 1 to 8 hours.

Dynamic 3D Flame

12 Colors Crystal 



12 Colors Log




Image: Visual representation of the 12 dynamic flame colors available for both crystal and log fuel beds.

Flexible Operation

Enjoy seamless control with dual options: touchscreen & remote



Image: Demonstrates the dual control options: touchscreen and infrared remote control.

Whisper-Quiet Operation

Maintains a low noise level of

45-50 dB



Heating Mode

Dual Heating Mode :
1500w/750w



**Flame
Brightness**

5 Flame Brightness



Secure

Overheating
Protection

Image: Illustrates the quiet operation, dual heating modes, flame brightness options, and secure overheating protection.



EWHOMY
Live the good life

05

**Personalized Timer
Control**

Less than 50 decibels,
8-hour timer for a restful
night's sleep

Image: Highlights the personalized timer control feature, allowing for up to 8 hours of operation.

6. Maintenance

Regular maintenance ensures the longevity and optimal performance of your electric fireplace.

- **Cleaning:** Always disconnect power before cleaning. Use a soft, damp cloth to wipe the exterior surfaces. Do not use abrasive cleaners or sprays.

- **Glass Panel:** Clean the glass panel with a soft cloth and a non-abrasive glass cleaner.
- **Air Vents:** Periodically check and clean the air inlet and outlet vents to ensure proper airflow and prevent dust buildup.
- **Storage:** If storing the fireplace for an extended period, ensure it is clean, dry, and stored in a safe location.

7. Troubleshooting

If you encounter any issues with your fireplace, refer to the following common troubleshooting steps:

Problem	Possible Cause	Solution
Fireplace does not turn on.	No power, power cord not fully plugged in, circuit breaker tripped.	Check power outlet, ensure cord is securely plugged in, reset circuit breaker.
No heat output.	Heater function not activated, thermostat set too low, overheat protection activated.	Activate heater function, increase thermostat setting, unplug unit for 10-15 minutes to reset overheat protection.
Flame effect not working.	Flame effect function not activated, LED lights malfunction.	Activate flame effect function. If issue persists, contact customer support.
Remote control not working.	Batteries dead, remote out of range, obstruction between remote and unit.	Replace batteries, ensure remote is within range and pointed at the unit, remove any obstructions.

For issues not covered here, please contact EUHOMY customer support.

8. Specifications

Feature	Detail
Brand	EUHOMY
Model Name	IF-1336TCL
Product Dimensions	4"D x 36"W x 17"H
Material	Tempered Glass
Finish Type	Polished
Installation Type	Wall Mount, Recessed
Power Source	Corded Electric
Power Consumption	750W / 1500W
Heat Output	5000 BTU per Hour
Heating Coverage	Up to 400 sq ft
Special Features	Adjustable Flame, Adjustable Thermostat, Overheat Protection, Timer
Flame Colors	12 options
Fuel Bed Colors	12 options
Flame Brightness	5 levels
Timer	1-8 hours
Noise Level	Approximately 45 decibels
Certifications	ETL Approved

Feature	Detail
Item Weight	34.4 pounds
UPC	850070202015

9. Warranty and Support

The EUHOMY 36 Inch Electric Fireplace comes with **2 years of technical support**

For warranty claims, technical assistance, or any questions regarding your product, please contact EUHOMY customer service:

- **Website:** [Visit the EUHOMY Store on Amazon](#)
- **Email:** [Insert Customer Service Email Here]
- **Phone:** [Insert Customer Service Phone Number Here]

Please have your model number (IF-1336TCL) and purchase date available when contacting support.