

[Manuals.plus](#) /

> [VASAGLE](#) /

> VASAGLE ULSB164B01 Storage Chest Instruction Manual

VASAGLE ULSB164B01

VASAGLE ULSB164B01 Storage Chest Instruction Manual

Model: ULSB164B01 | Brand: VASAGLE

1. INTRODUCTION

Thank you for choosing the VASAGLE ULSB164B01 Storage Chest. This versatile piece of furniture, designed in a modern charcoal gray style, offers ample storage and serves as a functional bench. Please read this manual carefully before assembly and use to ensure safe and correct operation.



Image: The VASAGLE ULSB164B01 Storage Chest in a living room, showcasing its modern design and functionality as both storage and seating.

2. SAFETY INFORMATION

- **Weight Limit:** Do not exceed the maximum weight capacity of 300 lb (135 kg) on the bench top. The internal compartment can hold up to 132 lb (60 kg).
- **Safety Hinges:** The storage chest is equipped with two safety hinges designed to keep the lid open at various angles and ensure a gentle, safe closing to prevent accidental slamming.
- **Assembly:** Follow all assembly instructions carefully. Ensure all parts are securely fastened before use.
- **Placement:** Place the storage chest on a flat, stable surface to prevent tipping.

3. SETUP AND ASSEMBLY

The VASAGLE ULSB164B01 Storage Chest is designed for straightforward assembly. All necessary components and clear, illustrated instructions are included in the package.

1. **Unpack:** Carefully unpack all components and verify against the parts list provided in the instruction manual.
2. **Tools:** Ensure you have any required tools as specified in the manual (typically a screwdriver).
3. **Follow Instructions:** Adhere strictly to the step-by-step illustrated instructions. Do not overtighten screws.
4. **Secure Hinges:** Pay close attention to the installation of the safety hinges to ensure proper function.

Safe Lid

Securely stay open at any angle to avoid accidental slamming




Image: A detailed view of the storage chest's lid, highlighting the safety hinges and product dimensions (15.7"D x 39.4"W x 18.3"H).

4. OPERATING INSTRUCTIONS

4.1. Opening and Closing the Lid

- To open, gently lift the lid. The safety hinges will hold it open at your desired angle.
- To close, gently push the lid downwards. The hinges will ensure a slow and controlled descent, preventing sudden drops.

4.2. Utilizing Storage Space

The spacious interior of the chest is ideal for organizing various items, helping to maintain a tidy living space.

- Store blankets, pillows, books, toys, or other household essentials.
- Ensure items are placed neatly to maximize space and prevent damage to the lid mechanism.



Ample Storage Space
Helps create a neatly organized living space

Image: The interior of the storage chest, demonstrating its ample capacity for storing items like blankets and books.

4.3. Using as a Bench

The sturdy top surface allows the chest to function as a comfortable bench.

- Use it as a shoe bench in the entryway or extra seating in a bedroom or living room.
- Always ensure the lid is fully closed before sitting on the bench.
- Do not exceed the 300 lb (135 kg) weight limit.

300 lb (135 kg)

Weight Capacity
Sit at ease while
changing shoes



Ours



Boasts Higher Weight Capacity

Others



Compromises on Strength

Image: A person sitting on the storage chest, illustrating its robust construction and suitability as a seating option.

5. MAINTENANCE

- **Cleaning:** Wipe the surface with a soft, damp cloth. Avoid harsh chemicals or abrasive cleaners.
- **Inspection:** Periodically check all screws and fasteners to ensure they remain tight. Retighten if necessary.
- **Avoid Moisture:** Keep the chest away from excessive moisture or direct sunlight to prevent warping or discoloration.
- **Moving:** Use the convenient side handles when relocating the chest to prevent damage.



Image: A close-up of the ergonomically designed cut-out handle on the side of the storage chest, facilitating easy movement.

6. TROUBLESHOOTING

Problem	Possible Cause	Solution
Lid does not stay open or closes too quickly.	Hinges not installed correctly or loose.	Check hinge installation as per manual. Ensure screws are tight.
Chest feels wobbly.	Loose fasteners or uneven surface.	Tighten all assembly screws. Ensure the chest is on a flat, level surface.
Difficulty moving the chest.	Overloaded or improper lifting technique.	Remove some contents if overloaded. Use the side handles for lifting and moving.

7. SPECIFICATIONS

Product Dimensions: 15.7"D x 39.4"W x 18.3"H

Material: Engineered Wood

Frame Material: Engineered Wood

Color: Charcoal Gray

Style: Modern

Brand Name: VASAGLE

Model Number: ULSB164B01

UPC: 194343292403

Maximum Weight Recommendation (Top): 300 Pounds (135 kg)

Maximum Weight Recommendation (Interior): 132 Pounds (60 kg)

Item Weight: 33.5 Pounds (15.2 kg)

Required Assembly: Yes

Included Components: 1 x Storage Bench, 1 x Accessory Kit, 1 x Instructions

8. WARRANTY AND SUPPORT

For any questions regarding assembly, missing parts, or product defects, please contact VASAGLE customer

support. Refer to your purchase documentation for specific warranty details and contact information.