

[Manuals.plus](#) /

› [GarveeHome](#) /

› GarveeHome PHO_334 Power Lift Recliner Chair User Manual

GarveeHome PHO_334

GarveeHome PHO_334 Power Lift Recliner Chair User Manual

Model: PHO_334 | Brand: GarveeHome

1. INTRODUCTION

Thank you for choosing the GarveeHome PHO_334 Power Lift Recliner Chair. This electric lift chair is designed to provide comfort and support, especially for the elderly and individuals with mobility impairments. It features power lift and recline functions, along with integrated heat and massage capabilities for enhanced relaxation. Please read this manual thoroughly before assembly and operation to ensure safe and correct use of your new recliner.



Image 1.1: The GarveeHome PHO_334 Power Lift Recliner Chair in a living room setting.

2. SAFETY INFORMATION

Important Safety Instructions:

- Ensure the chair is used by individuals within the **400 lbs (181 kg) weight limit**. Exceeding this limit may cause damage to the chair or injury to the user.
- Regularly check all electrical components and upholstery for any signs of wear or damage. Discontinue use immediately if any damage is found and contact customer support.
- When using the electric lift function, follow the instructions provided in this user manual to ensure safe operation. Keep the area around the chair clear to prevent obstructions during movement.

- Keep children and pets away from the chair's moving parts.
- Do not allow liquids to spill on the electrical components or remote control.
- Unplug the chair from the power outlet before cleaning or if it will not be used for an extended period.

3. PACKAGE CONTENTS

Before assembly, please ensure all components are present and undamaged. If any parts are missing or damaged, contact GarveeHome customer service.

- Chair Base
- Backrest
- Arm Pads (Left and Right)
- Remote Control
- Power Adapter and Cable
- User Manual (this document)

4. ASSEMBLY INSTRUCTIONS

Assembly is required for this product. It is recommended to have two people for easier and safer assembly. Please follow these general steps:

1. **Unpack Components:** Carefully remove all parts from the packaging and lay them out on a clean, soft surface to prevent scratches.
2. **Attach Backrest:** Slide the backrest onto the metal posts on the chair base until it clicks securely into place. Ensure it is fully seated and stable.
3. **Connect Electrical Wires:** Locate the electrical wires extending from the backrest and the base. Connect the corresponding wires, ensuring a snug fit. These connections power the lift, recline, heat, and massage functions.
4. **Attach Armrests:** If the armrests are separate, slide them onto the designated slots on the sides of the chair base. Ensure they are firmly attached.
5. **Connect Power Adapter:** Plug the power adapter into the chair's power input, then plug the other end into a standard wall outlet.
6. **Test Functions:** Before sitting, test all functions (lift, recline, heat, massage) using the remote control to ensure proper operation.



Image 4.1: View of the chair's motor and electrical connections under the base.

5. OPERATING INSTRUCTIONS

The GarveeHome PHO_334 recliner is operated using the included remote control. Familiarize yourself with the remote's buttons before use.

5.1 Power Lift Function

To use the power lift function, press and hold the designated lift button on the remote control. The chair will slowly tilt forward and lift, assisting you in standing up from a seated position. Release the button to stop at your desired height.




Image 5.1: The recliner in its elevated, lift-assist position.

5.2 Recline Function

To recline the chair, press and hold the recline button on the remote. The backrest will lean back, and the footrest

will extend. Release the button when you reach your preferred reclining angle. The chair offers multiple reclining positions for optimal comfort.

5.3 Heat Function

Activate the heat function by pressing the heat button on the remote. The chair features **2 heat lumbar parts** to provide soothing warmth to your lower back. Press the button again to cycle through heat settings or turn off the function.

5.4 Massage Function

The massage function offers relaxation through vibration. Use the massage button on the remote to select from **5 massage modes** and activate **8 vibration points** located throughout the chair. A timing function may also be available to set the duration of the massage. Refer to the remote's specific markings for detailed control.



6. PRODUCT FEATURES AND DETAILS

6.1 Unmatched Comfort

Experience ultimate relaxation with armrests and soft cushions filled with high-density sponge. This design provides exceptional support and cushioning for your neck, back, and lumbar region. The extendable footrest allows you to fully stretch and unwind.

6.2 Premium Quality Materials

Crafted from high-quality faux PU leather, this recliner is both wear-resistant and waterproof, ensuring long-lasting durability and easy maintenance. The robust metal frame provides a solid foundation, guaranteeing safety and stability for daily use.



Image 6.1: Detail of the faux PU leather material and high-density sponge filling.

6.3 Convenient Side Pocket

The chair includes a practical side pocket, perfect for storing the remote control, magazines, or other small items within easy reach.



Image 6.2: The convenient side pocket for storage.

7. CARE AND MAINTENANCE

To maintain the appearance and longevity of your GarveeHome Power Lift Recliner Chair, follow these care instructions:

- **Cleaning:** The faux PU leather upholstery can be easily cleaned by wiping with a damp cloth. For tougher stains, use a mild soap solution and wipe dry immediately. Avoid harsh chemicals or abrasive cleaners.
- **Spills:** Blot spills immediately with a clean, dry cloth.
- **Inspection:** Periodically inspect all connections, wires, and moving parts for any signs of wear, loosening, or damage. Tighten any loose fasteners.
- **Placement:** Avoid placing the chair in direct sunlight or near heat sources, as this can cause the material to fade or crack over time.

8. TROUBLESHOOTING

If you encounter any issues with your recliner, please refer to the following common troubleshooting tips:

- **Chair Not Responding:**
 - Ensure the power cord is securely plugged into both the chair and a working wall outlet.
 - Check if the power adapter is properly connected to the chair's input.
 - Verify that the wall outlet is functional by plugging in another appliance.
- **Lift/Recline Not Working Smoothly:**
 - Check for any obstructions around the chair's moving parts (e.g., objects under the footrest or behind the backrest).
 - Ensure all assembly connections are secure.
- **Heat/Massage Not Functioning:**
 - Confirm the chair is powered on and the remote control is working.
 - Ensure the specific heat/massage buttons on the remote are pressed correctly.
- **Unusual Noises:**
 - Inspect the chair's mechanism for any loose parts or foreign objects. If the noise persists, discontinue use and contact customer support.

If these steps do not resolve the issue, please contact GarveeHome customer support for further assistance.

9. SPECIFICATIONS

Feature	Detail
---------	--------

Brand	GarveeHome
Model Name	PHO_334
Color	Retro Brown
Material	Faux PU Leather (Upholstery), Metal (Frame), Foam (Fill)
Product Dimensions (Overall)	38.6"D x 37.4"W x 40.6"H (95 x 95 x 103 cm)
Seat Width	21.3 inches
Maximum Weight Recommendation	400 LBS (181 kg)
Reclining Position Count	Multiple (2 specified)
Heat Function	2 Lumbar Heat Parts
Massage Function	5 Modes, 8 Vibration Points, Timing Function
Control Type	Remote Control
Assembly Required	Yes
Product Care Instructions	Wipe Clean

Product Dimension



Ideal Height
5.2' - 6.1'



Max Load
Capacity



400
LBS



Image 9.1: Detailed product dimensions for the recliner chair.

10. WARRANTY AND SUPPORT

GarveeHome is committed to customer satisfaction. While specific warranty details are not provided in this manual, please retain your proof of purchase for any warranty claims.

If you have any questions, require clarification, or need assistance with your GarveeHome PHO_334 Power Lift Recliner Chair, please do not hesitate to contact our customer support team. Our team is available to help you with any product-related inquiries or issues.

Customer Service Contact: Refer to the contact information provided at the point of purchase or on the GarveeHome official website.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question