Portronics POR-2152

Portronics Toad 8 Transparent Wireless Bluetooth Mouse User Manual

Model: POR-2152

INTRODUCTION

Thank you for choosing the Portronics Toad 8 Transparent Wireless Bluetooth Mouse. This manual provides detailed instructions for setting up, operating, and maintaining your new wireless mouse. Please read this manual thoroughly before use to ensure optimal performance and longevity of your device.

PACKAGE CONTENTS

Verify that all items are present in your package:

- Portronics Toad 8 Wireless Mouse (1N)
- USB Receiver (1N)
- Charging Cable (1N)
- User Documentation (1N)

PRODUCT OVERVIEW

The Portronics Toad 8 mouse features a transparent design, dual wireless connectivity (Bluetooth 5.3 and 2.4 GHz), a rechargeable battery, and adjustable DPI settings for versatile use.

Image: Top view of the Portronics Toad 8 mouse, highlighting its transparent casing and internal layout, including the USB receiver storage slot.

Image: An exploded view illustrating the detachable magnetic top cover of the mouse, revealing the internal components.

SETUP

1. Charging the Mouse

The Toad 8 mouse is equipped with a built-in rechargeable battery. Before first use, it is recommended to fully charge the mouse.

- Locate the Type-C charging port on the front of the mouse.
- Connect the provided USB Type-C charging cable to the mouse and a power source (e.g., computer USB port, USB wall adapter).
- The charging indicator light will illuminate during charging and turn off when fully charged.

Image: The Portronics Toad 8 mouse being charged via its Type-C port, showing the charging cable connected.

2. Connecting via 2.4 GHz Wireless

For a stable and fast wireless connection, use the included 2.4 GHz USB receiver.

1. Remove the USB receiver from its storage slot inside the mouse (under the magnetic top cover).
2. Plug the USB receiver into an available USB port on your computer or device.
3. Turn on the mouse using the power switch located on the bottom.
4. The mouse should automatically connect to your device.

Image: The Portronics Toad 8 mouse demonstrating 2.4 GHz wireless connectivity with its USB receiver inserted into a laptop.

3. Connecting via Bluetooth 5.3

The mouse supports Bluetooth 5.3 for wireless connection to compatible devices.

1. Ensure the mouse is powered on.
2. Press the mode switch button on the bottom of the mouse to select Bluetooth mode. The indicator light will flash, indicating pairing mode.
3. On your device (computer, tablet, smartphone), go to Bluetooth settings and search for new devices.
4. Select "Portronics Toad 8" from the list of available devices to pair.
5. Once paired, the indicator light on the mouse will stop flashing.

Image: The Portronics Toad 8 mouse illustrating multi-device pairing capabilities, connecting to a laptop, tablet, and smartphone.

OPERATING INSTRUCTIONS

1. Adjusting DPI Sensitivity

The mouse offers adjustable DPI (Dots Per Inch) settings to control cursor speed and precision. You can cycle through different DPI levels (1000, 1200, 1600 DPI).

- Press the DPI button, usually located near the scroll wheel, to change the sensitivity.
- Each press will cycle to the next DPI setting.

Image: A visual representation of the adjustable optical sensitivity settings (1000, 1200, 1600 DPI) available on the mouse.

2. Show/Hide Desktop Button

The mouse includes a dedicated button for quickly showing or hiding your desktop, enhancing multitasking efficiency.

- Press the designated "Show/Hide Desktop" button (refer to product diagram for exact location) to instantly minimize all open windows and display your desktop, or restore them.

3. Multi-Device Switching

Seamlessly switch between up to three paired devices (two Bluetooth, one 2.4 GHz) without re-pairing.

- Use the mode switch button on the bottom of the mouse to toggle between the 2.4 GHz connection and the two Bluetooth connections.

4. Silent Clicking

The Portronics Toad 8 mouse features silent click functionality, reducing noise in quiet environments.

Image: A hand interacting with the mouse, illustrating the silent clicking feature for a distraction-free operation.

MAINTENANCE

- **Cleaning:** Use a soft, dry cloth to clean the mouse. Avoid using harsh chemicals or abrasive materials.
- **Storage:** When not in use for extended periods, turn off the mouse to conserve battery life. Store in a cool, dry place.
- **Battery Care:** Avoid fully discharging the battery frequently. Charge the mouse regularly to maintain battery health.

TROUBLESHOOTING

Problem	Solution

Problem	Solution
Mouse not responding	- Ensure the mouse is powered on. - Check battery level and charge if necessary. - For 2.4 GHz: Ensure the USB receiver is securely plugged in. Try a different USB port. - For Bluetooth: Ensure Bluetooth is enabled on your device and the mouse is paired. Try re-pairing.
Cursor movement is erratic or slow	- Clean the optical sensor on the bottom of the mouse. - Ensure you are using the mouse on a suitable surface (non-reflective, opaque). - Adjust DPI sensitivity to a higher setting.
Cannot connect via Bluetooth	- Ensure the mouse is in Bluetooth pairing mode (indicator light flashing). - Remove "Portronics Toad 8" from your device's Bluetooth list and attempt to re-pair. - Ensure your device's Bluetooth is enabled and discoverable.

SPECIFICATIONS

Feature	Detail
Brand	Portronics
Model Number	POR-2152
Series	Toad 8
Connectivity Technology	Bluetooth 5.3, 2.4 GHz Wireless
Movement Detection Technology	Optical
DPI Sensitivity	Adjustable (1000, 1200, 1600 DPI)
Battery Type	1 Lithium Polymer (included)
Battery Energy Content	400 mAh
Charging Port	Type-C
Product Dimensions (LxWxH)	12 x 8.1 x 0.1 cm
Item Weight	110 g
Operating System Compatibility	Android, Linux, Windows, macOS
Included Components	Wireless Mouse, USB Receiver, Charging Cable, User Documentation

Feature	Detail
Country of Origin	China

WARRANTY AND SUPPORT

For warranty information and customer support, please contact Portronics directly.

- **Email:** help@portronics.com
- **Phone:** +91 9555-245-245
- **Manufacturer:** Portronics Digital Pvt. Ltd.
- **Address:** First Floor Property No D 8 Upper Basement Sector 8 Noida Uttar Pradesh 201301

SAFETY INFORMATION

- Do not expose the mouse to extreme temperatures or humidity.
- Avoid dropping or subjecting the mouse to strong impacts.
- Do not attempt to disassemble or repair the mouse yourself. This will void the warranty.
- Keep out of reach of children.
- Dispose of the battery according to local regulations.