

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [Wisdomlit](#) /

› [Wisdomlit 3-in-1 Bubble Fog Machine User Manual](#)

Wisdomlit QB-807

Wisdomlit 3-in-1 Bubble Fog Machine User Manual

Model: QB-807

1. PRODUCT OVERVIEW

The Wisdomlit 3-in-1 Bubble Fog Machine is designed to create various atmospheric effects, including colorful bubbles, fog bubbles, and continuous fog. This 400W machine features a durable metal housing and is controlled via a wireless remote with timer settings, making it suitable for various events and celebrations.



Image: The Wisdomlit 3-in-1 Bubble Fog Machine in operation, generating both fog and numerous bubbles.



Image: A banner showcasing key features of the Bubble Fog Machine, including its 3-in-1 effects, wireless remote control, timer settings, large liquid tanks, durable metal housing, and ease of use.

2. SAFETY INFORMATION

Please read all safety instructions carefully before operating the machine.

- **Electrical Safety:** Ensure the power supply matches the machine's requirements. Do not operate with damaged cords or plugs. Keep away from water.
- **Fluid Handling:** Use only recommended fog and bubble fluids. Do not ingest fluids. Avoid contact with eyes and skin. In case of contact, rinse thoroughly with water.
- **Placement:** Place the machine on a stable, level surface. Ensure adequate ventilation around the unit. Keep away from flammable materials and heat sources.
- **Operation:** Do not block the fog or bubble output. Keep children and pets away from the machine during operation.
- **Maintenance:** Disconnect from power before cleaning or servicing. Allow the machine to cool down completely before handling.

3. WHAT'S IN THE BOX

Verify that all components are present upon unpacking:

WHAT'S IN THE BOX?



1 x Bubble Fog Machine



1 x Gift Box

1 x Replacement Fuse
(125V/5A)



1 x Remote Control
(CR2032 Button Cell Battery)



1 x Measuring Cup
(16.9 Fl Oz / 500 ml)



2-Pack
Bubble Solution Concentrate
(2.7 fl oz/pack)

NOTE: Please dilute concentrated bubble solution with water before use



1-Pack
Fog Fluid Concentrate
(3.38 fl oz/pack)

NOTE: Please dilute concentrated fog fluid with water before use



1 x User Manual



Image: A visual representation of the items included in the product packaging: 1x Bubble Fog Machine, 1x Gift Box, 1x Replacement Fuse (125V/5A), 1x Remote Control (CR2032 Button Cell Battery included), 1x Measuring Cup (16.9 Fl Oz / 500 ml), 2-Pack Bubble Solution Concentrate (2.7 fl oz/pack), 1-Pack Fog Fluid Concentrate (3.38 fl oz/pack), and 1x User Manual.

- 1 x Bubble Fog Machine
- 1 x Gift Box
- 1 x Replacement Fuse (125V/5A)
- 1 x Remote Control (CR2032 Button Cell Battery included)
- 1 x Measuring Cup (16.9 Fl Oz / 500 ml)
- 2-Pack Bubble Solution Concentrate (2.7 fl oz/pack)
- 1-Pack Fog Fluid Concentrate (3.38 fl oz/pack)
- 1 x User Manual

4. SETUP INSTRUCTIONS

Follow these steps to prepare your machine for operation:

1. **Fill Fog Liquid Tank:** Open the cap of the fog liquid tank. Carefully pour fog juice (not included, 10.5 Fl Oz / 310 ml capacity) into the tank. Ensure not to overfill.
2. **Fill Bubble Solution Tank:** Open the cap of the bubble liquid tank. Pour bubble solution (not included, 18.6 Fl Oz / 550 ml capacity) into the tank.
3. **Power Connection:** Plug the machine into a standard power outlet. Ensure the power switch on the machine is in the 'OFF' position before plugging in.
4. **Power On and Warm-up:** Turn the power switch to the 'ON' position. The red indicator light will illuminate, indicating the machine is heating up. The warm-up time is approximately 3-5 minutes. The red indicator light will turn off when the machine is fully heated and ready for use.



Image: A step-by-step guide illustrating the setup and cleaning process. Steps 1-3 show filling the fog liquid tank, pouring bubble

solution, and plugging in the power. Step 4 shows the warm-up indicator. Step 5 shows activating functions. Step 6 shows discharging liquid for cleaning.



1. Fill fog liquid tank with fog juice.
(Not Included, 10.5 Fl Oz / 310 ml)



2. Pour bubble solution into bubble liquid tank.
(Not Included, 18.6 Fl Oz / 550 ml)



3. Plug in the power outlet and
turn on the power switch.



4. Warm-up time is 3 - 5 minutes,
red indicator will be off when fully heated.



5. Push the function buttons or remote
control to activate bubble fogger.



6. Discharge all the liquid,
clean their tanks when not in use.

Image: An illustration detailing the machine's dimensions (13.54 inches width, 7.59 inches depth, 9.09 inches height) and liquid tank capacities: 18.6 fl oz / 550 ml for bubble liquid (up to 1 hour use) and 10.5 fl oz / 310 ml for fog liquid (up to 2 hours use).

5. OPERATING INSTRUCTIONS

Once the machine has warmed up (red light off), you can operate it using the wireless remote control.

LARGER & METAL HOUSING

Create the Exceptional Party with Magical Fog Bubbles



18.6 fl oz / 550 ml
Bubble Liquid Tank Capacity
= Use Time Up To **1 Hour**



10.5 fl oz / 310 ml
Fog Liquid Tank Capacity
= Use Time Up To **2 Hours**



Only Bubbles



Colorful Bubbles



Fog Bubbles



Continuous Fog



Only Fog

Image: The wireless remote control for the machine, displaying buttons for ON/OFF, Timer Off, and three effect modes: Bubble, Fog Bubble, and Fog. It also shows duration settings (30s, 60s, 180s, 300s) and interval settings (10s, 30s, 60s, 90s).

5.1 Remote Control Functions

- **ON/OFF Button:** Press to turn the machine on or off.
- **Timer Off Button:** Deactivates any active timer settings.
- **Bubble Button:** Activates only bubble output.
- **Fog Bubble Button:** Activates both fog and bubble output simultaneously.
- **Fog Button:** Activates only fog output.

5.2 Timer Settings

The remote allows you to set duration and interval for the effects:

- **Duration:** Choose from 30, 60, 180, or 300 seconds of continuous effect.
- **Interval:** Choose from 10, 30, 60, or 90 seconds between effect bursts.

To use, select your desired effect (Bubble, Fog Bubble, or Fog), then press the corresponding duration and/or interval buttons. The machine will operate according to the set parameters.

6. MAINTENANCE AND CLEANING

Regular maintenance ensures optimal performance and longevity of your machine.

- Fluid Discharge:** After each use, or when storing the machine, discharge all remaining fog and bubble liquid from their respective tanks. This prevents residue buildup.
- Tank Cleaning:** Rinse the liquid tanks with clean water. For thorough cleaning, a diluted cleaning solution specifically designed for fog/bubble machines can be used. Ensure tanks are completely dry before refilling or storing.
- Exterior Cleaning:** Wipe the exterior of the machine with a soft, dry cloth. Do not use abrasive cleaners or allow water to enter internal components.
- Nozzle Cleaning:** Periodically check the fog and bubble nozzles for any blockages. Use a small brush or compressed air to clear any debris.
- Storage:** Store the machine in a cool, dry place away from direct sunlight and extreme temperatures.

7. TROUBLESHOOTING

If you encounter issues, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
No fog/bubbles produced	<ul style="list-style-type: none">Machine not plugged in or powered onNo fluid in tanksMachine not warmed upNozzle blockageRemote control battery low/dead	<ul style="list-style-type: none">Check power connection and switchRefill tanks with appropriate fluidWait for red indicator light to turn offClean nozzlesReplace remote control battery
Weak fog/bubble output	<ul style="list-style-type: none">Low fluid levelIncorrect fluid typePartial nozzle blockage	<ul style="list-style-type: none">Refill tanksEnsure correct fog/bubble fluid is usedClean nozzles thoroughly

Problem	Possible Cause	Solution
Remote control not working	<ul style="list-style-type: none"> Battery low/dead Out of range Obstruction between remote and machine 	<ul style="list-style-type: none"> Replace CR2032 battery Move closer to the machine Remove any obstructions
Machine overheating	<ul style="list-style-type: none"> Insufficient ventilation Prolonged continuous use 	<ul style="list-style-type: none"> Ensure adequate space around the machine Allow machine to cool down before resuming operation

If the problem persists after attempting these solutions, please contact customer support.

8. SPECIFICATIONS

Feature	Specification
Model Number	QB-807
Power	400W
Item Weight	8.71 pounds
Product Dimensions	13 x 7 x 9 inches (33 x 17.8 x 22.9 cm)
Bubble Liquid Tank Capacity	18.6 fl oz / 550 ml (Approx. 1 hour use time)
Fog Liquid Tank Capacity	10.5 fl oz / 310 ml (Approx. 2 hours use time)
Warm-up Time	3-5 minutes
Control Method	Wireless Remote Control

9. WARRANTY AND SUPPORT

9.1 Warranty Information

This Wisdomlit product comes with a limited manufacturer's warranty. Please refer to the warranty card included in your product packaging or visit the official Wisdomlit website for detailed terms and conditions regarding warranty coverage, duration, and claims process.

9.2 Customer Support

For technical assistance, troubleshooting not covered in this manual, or inquiries regarding parts and service, please contact Wisdomlit customer support. Contact information can typically be found on the product packaging, the official Wisdomlit website, or through your retailer.