



Manuals.plus /

› AX WABER /

› Universal Floor TV Stand Instruction Manual

## AX WABER AX2006TB

# Universal Floor TV Stand Instruction Manual

Model: AX2006TB | Brand: AX WABER

## INTRODUCTION

---

This instruction manual provides detailed guidance for the assembly, operation, and maintenance of your AX WABER Universal Floor TV Stand. Designed for most 27 to 65 inch LCD, LED, and OLED TVs, this stand offers a space-saving solution with adjustable height and swivel capabilities. Please read this manual thoroughly before beginning assembly to ensure safe and correct installation.

## SAFETY INFORMATION

---

**WARNING:** Failure to read and follow these instructions can result in serious personal injury, property damage, or voiding of your warranty.

- Do not exceed the maximum weight capacity of 77 lbs (35 kg).
- Ensure the TV stand is placed on a stable, level surface.
- Keep children and pets away during assembly. Small parts can be a choking hazard.
- Always use the provided hardware. If any parts are missing or damaged, contact customer support.
- Do not attempt to modify the TV stand.
- Periodically check all screws and connections to ensure they remain tight and secure.

## PACKAGE CONTENTS

---

Before assembly, verify that all components listed below are present and undamaged. Refer to the detailed parts list in your included assembly manual for specific part numbers.

- Tempered Glass Base
- Main Support Pillar
- TV Mounting Brackets (2)
- Adjustable Media Shelf
- Hardware Kit (screws, washers, spacers, cable clips)
- Assembly Tools (e.g., Allen wrench)
- Instruction Manual

## SETUP AND ASSEMBLY

---

Assembly typically takes about 15 minutes. Follow these steps carefully:

### 1. **Step 1: Attach the Main Support Pillar to the Base**

Carefully attach the main support pillar to the tempered glass base using the provided screws. Ensure the pillar is securely fastened and upright.





Image: Fully assembled TV stand with a television, demonstrating its overall appearance and stability.

## 2. **Step 2: Install the TV Mounting Brackets**

Attach the two TV mounting brackets to the back of your television. Select the appropriate screws and spacers from the hardware kit that fit your TV's VESA pattern (compatible with 100x100mm up to 400x400mm). Ensure the brackets are level and securely tightened.




Image: Visual guide for VESA compatibility and supported TV sizes (27-65 inches).

### 3. Step 3: Mount the Television onto the Stand

Carefully lift your television and hook the mounted brackets onto the main support pillar. Secure the TV to the stand using the safety screws or locking mechanism to prevent accidental dislodgement. This stand features a sturdy security TV lock.

## **Sturdy security TV lock**

*Conceals cords and prevents falling.*



## **Cable Management**

*Hide The Wires,streamlined look.*

## **Tempered Glass**

*Made of 8mm glass, it is stable & ensures safety.*



Image: Details of the TV lock mechanism, cable management, and tempered glass base.

### **4. Step 4: Adjust Height and Attach Media Shelf**

Adjust the TV height to your preferred viewing level. The stand offers 9 levels of height adjustment. Then, attach the media shelf to the main pillar at your desired height. The shelf is also adjustable.

## 9 LEVELS HEIGHT ADJUSTMENT



*Assemble with 3-Level Height Adjustment  
3-Level Height Adjustment Available Post-Installation*

Image: Illustration of the TV stand's height adjustment capabilities.

## OPERATING INSTRUCTIONS

### **Height Adjustment:**

The TV stand features 9 levels of height adjustment for optimal viewing. To adjust the height, loosen the securing bolts on the main pillar, slide the TV mount to the desired position, and re-tighten the bolts securely. The media shelf can also be adjusted independently.

### **Swivel Function:**

The TV mount allows for a -35 to +35 degree swivel. Gently rotate the television to achieve your preferred viewing angle. This feature is ideal for adjusting the screen from different seating positions within a room.



Image: Demonstration of the TV stand's swivel feature.

### **Cable Management:**

Utilize the integrated wire clips along the main support pillar to organize and conceal messy cables, contributing to a clean and streamlined look for your entertainment area.

## **MAINTENANCE**

- **Cleaning:** Use a soft, damp cloth to wipe down the metal and glass surfaces. Avoid abrasive cleaners or solvents that could damage the finish.
- **Inspection:** Periodically inspect all bolts and connections to ensure they are tight. Re-tighten if necessary.
- **Glass Care:** The tempered glass base is durable, but avoid dropping heavy objects on it or subjecting it to sharp impacts.

## TROUBLESHOOTING

Problem	Possible Cause	Solution
Stand is wobbly/unstable.	Loose connections; uneven floor.	Ensure all bolts are securely tightened. Move the stand to a level surface.
TV does not fit the mount.	Incorrect VESA pattern or TV size.	Verify your TV's VESA pattern is between 100x100mm and 400x400mm, and its size is between 27-65 inches.
Difficulty adjusting height or swivel.	Securing bolts too tight; mechanism obstruction.	Loosen height adjustment bolts before attempting to slide. Check for any obstructions around the swivel mechanism.

## SPECIFICATIONS

**Brand:** AX WABER

**Model Number:** AX2006TB

**Mounting Type:** Floor Mount

**Movement Type:** Swivel (-35 to +35 degrees)

**Material:** Alloy Steel, Tempered Glass

**Color:** Black

**Compatible TV Sizes:** 27 to 65 Inches

**VESA Compatibility:** 100x100mm to 400x400mm

**Weight Capacity:** Up to 77 lbs (35 kg)

**Height Adjustment:** 9 levels

**Item Weight:** 20.7 pounds

**Package Dimensions:** 29 x 16.6 x 2.8 inches

## WARRANTY AND SUPPORT

AX WABER products are manufactured with quality and durability in mind. For warranty information, technical support, or to order replacement parts, please contact our customer service team. Keep your purchase receipt as proof of purchase.

**Customer Service:** Please refer to the contact information provided on the product packaging or the official AX WABER website.

