

[Manuals.plus](#) /

› [OMOTON](#) /

› OMOTON Keyboard for Microsoft Surface Pro User Manual

OMOTON B0DM1VS7SG

OMOTON Wireless Bluetooth Keyboard User Manual

For Microsoft Surface Pro 7/7+/6/5/4/3

1. PRODUCT OVERVIEW

The OMOTON Wireless Bluetooth Keyboard is designed to enhance the functionality of your Microsoft Surface Pro device, providing a comfortable typing experience with a responsive touchpad and customizable backlighting. This ultra-slim and lightweight keyboard connects wirelessly via Bluetooth and features a built-in rechargeable battery.



Image: Front view of the OMOTON keyboard with purple backlighting, along with two side profiles showing the keyboard attached to a Surface Pro at different angles.

2. COMPATIBILITY

This keyboard is specifically designed for Microsoft Surface Pro models with a **12.3-inch screen**. Please verify your device model before use.

- **Compatible Models:** Surface Pro 7, Surface Pro 7+, Surface Pro 6, Surface Pro 5, Surface Pro 4, Surface Pro 3 (all 12.3 inch models).
- **NOT Compatible With:** Surface Pro 11/10/9/8/X (13 inch), Surface Go 4/3/2, Surface Go 1, Surface Book, and other models.


To confirm your device's model, navigate to *Settings > System > About* on your Surface Pro.

Bluetooth Connected Keyboard


Follow these steps to connect your keyboard



1 Press **Fn+C** more than 3 seconds



2 Turn Bluetooth on in "Setting" on your device



3 Select "Bluetooth Keyboard"

Image: A visual guide indicating compatibility with 12.3-inch Surface Pro models (Pro 7/7+/6/5/4/3) and explicitly stating non-compatibility with 13-inch, 10.5-inch, and 10-inch Surface devices.

3. SETUP AND CONNECTION

3.1 Bluetooth Connection

Follow these steps to connect your OMOTON keyboard to your Surface Pro via Bluetooth:

- 1. Activate Keyboard Bluetooth:** Press the **Fn + C** keys simultaneously for 1-3 seconds to turn on the keyboard's Bluetooth. The Bluetooth indicator light on the keyboard will begin to flash, indicating it is in pairing mode.
- 2. Open Surface Settings:** On your Surface Pro, open the "Settings" application.
- 3. Navigate to Bluetooth & Devices:** In Settings, select "Bluetooth & devices".
- 4. Enable Bluetooth:** Ensure the Bluetooth toggle is set to "ON".
- 5. Add a Device:** Click on "Add a device".
- 6. Select Bluetooth:** Choose "Bluetooth" from the options.
- 7. Select "Bluetooth Keyboard":** From the list of available devices, select "Bluetooth Keyboard".
- 8. Confirm Connection:** Once connected, the indicator light on the keyboard will stop flashing, and your Surface Pro will show the keyboard as paired. Click "Done" to complete the process.



Image: A step-by-step visual representation of the Bluetooth connection process, from activating the keyboard's Bluetooth to pairing it with the Surface Pro.

3.2 Magnetic Attachment

The keyboard features a magnetic strip designed to securely attach to your Surface Pro, allowing for two adjustable typing angles. This magnetic connection is solely for physical stability and angle adjustment; **it does not charge or connect the keyboard to the tablet electrically.**

Two Typing Angle Adjustments

!!! ATTENTION: The Magnet Strip is **only** used to fix the keyboard and the tablet, which can better adjust the typing angle. (**It Cannot Charge or Connect to the Tablet**)



Two Typing Angles for Your Choice



Image: Illustration of the two typing angles achievable by attaching the keyboard to the Surface Pro using its magnetic strip.

4. OPERATING INSTRUCTIONS

4.1 Backlight Control

The keyboard features 7 colors of backlighting and 3 brightness levels for comfortable typing in various lighting conditions.

- **Change Backlight Color:** Press **Fn + ⌘** (the key with the lightbulb icon) to cycle through the 7 available backlight colors.
- **Adjust Brightness:** Press **Fn + F7** to adjust the brightness levels. There are three levels of brightness to choose from.

Built-in 750mAh Battery




Image: Visual instructions for changing backlight colors and adjusting brightness levels on the keyboard.

4.2 Touchpad Usage

The integrated multi-touch trackpad supports various gestures for quick and efficient operations, providing a comfortable typing experience with responsive feedback.

- **Left Click:** Single tap with one finger.
- **Right Click:** Tap with two fingers.
- **Move Cursor:** Slide one finger across the touchpad.
- **Scroll:** Move two fingers vertically or horizontally.
- **Zoom In/Out:** Point two fingers outward/inward.
- **Open Activity Center:** Four-finger tap.
- **Search:** Three-finger tap.
- **Open All Task Windows:** Three fingers moving up.
- **Back to Desktop:** Three fingers down.
- **Toggle Active Windows:** Swipe left/right with three fingers.

Freedom from the constraints of the mouse, multi-finger gesture operation more flexible



 One finger slide Move cursor	 One finger slide Move cursor	 Quick double-click with one finger without releasing, move again Click on the target and drag
 Two fingers tapping Right-click like on a mouse	 Move your two fingers vertically/horizontally The mouse wheel scrolls vertically/horizontally	
 Four-finger tap Open the activity center	 Three-finger tap Search	 Three fingers moving up Open all task Windows
 Three fingers down Back to desktop	 Swipe left/right with three fingers The active window toggles left/right	 Point two fingers outward/inward Zoom in/out

Image: A comprehensive guide to multi-finger gestures supported by the touchpad, including actions like moving the cursor, scrolling, zooming, and opening system functions.

5. CHARGING AND BATTERY

The keyboard is equipped with a built-in 750mAh rechargeable battery.

- **Charging Time:** Approximately 2-3 hours for a full charge.
- **Continuous Work Time:** Up to 50 hours of uninterrupted use on a single charge.
- **Charging Cable:** A Type-C charging cable is included for convenient charging.

Connect the provided Type-C cable to the charging port on the keyboard and a suitable USB power source.

Ultra-Slim and Lightweight



Image: Details on the keyboard's battery capacity, charging duration, and operational time, along with an illustration of the Type-C charging port.

6. MAINTENANCE

To ensure the longevity and optimal performance of your OMOTON keyboard, follow these maintenance guidelines:

- **Cleaning:** Use a soft, dry, lint-free cloth to wipe the surface of the keyboard. For stubborn dirt, slightly dampen the cloth with water or a mild, non-abrasive cleaner. Avoid excessive moisture.
- **Storage:** Store the keyboard in a cool, dry place away from direct sunlight and extreme temperatures.
- **Avoid Liquids:** Do not expose the keyboard to liquids. In case of spills, immediately disconnect it and allow it to dry completely before reuse.
- **Handle with Care:** Avoid dropping the keyboard or subjecting it to strong impacts.

7. TROUBLESHOOTING

If you encounter issues with your OMOTON keyboard, refer to the following common solutions:

- **Keyboard Not Connecting/Lagging:**

- Ensure the keyboard is charged. Low battery can affect Bluetooth performance.
- Re-pair the keyboard: Go to your Surface Pro's Bluetooth settings, forget the "Bluetooth Keyboard" device, and then follow the connection steps in Section 3.1.
- Ensure Bluetooth is enabled on your Surface Pro.
- Restart both your Surface Pro and the keyboard.
- Ensure no other Bluetooth devices are causing interference.

- **Keys Not Responding:**

- Check battery level.
- Ensure the keyboard is properly connected via Bluetooth.
- Clean around the affected keys to remove any debris.

- **Backlight Not Working:**

- Ensure the keyboard is charged.
- Try pressing **Fn + ⌘** and **Fn + F7** to cycle through colors and brightness levels.

8. SPECIFICATIONS

Feature	Detail
Product Dimensions	11.57 x 8.54 x 0.26 inches
Item Weight	1.15 pounds
Manufacturer	OMOTON
Batteries	1 Lithium Polymer battery (included)
Compatible Devices	Surface Pro 7/Pro 7+ /Pro 6 /Pro 5 /Pro 4 /Pro 3 (12.3 inch)
Connectivity Technology	Bluetooth
Keyboard Description	Touchpad, Multimedia
Special Feature	7 Colors Backlit, Trackpad
Color	Grey
Keyboard Backlighting Color Support	RGB
Material	Polycarbonate



7 Colors LED Backlights Keyboard




Image: A visual representation of the keyboard's dimensions, highlighting its ultra-slim and lightweight profile.

9. WHAT'S IN THE BOX

Upon unboxing your OMOTON Keyboard, you should find the following items:

- 1 x OMOTON Wireless Bluetooth Keyboard
- 1 x Type-C Charging Cable
- 1 x User Manual (this document)

10. WARRANTY AND SUPPORT

For warranty information, technical support, or any inquiries regarding your OMOTON product, please refer to the official OMOTON website or contact their customer service directly. You can also visit the [OMOTON Store on Amazon](#) for more information and support resources.

