



[Manuals.plus](#) /

› [WLIVE](#) /

› WLIVE Farmhouse Dresser Instruction Manual

WLIVE ASNG115BL

WLIVE Farmhouse Dresser Instruction Manual

Model: ASNG115BL | Brand: WLIVE

1. INTRODUCTION

Thank you for choosing the WLIVE Farmhouse Dresser. This versatile and stylish storage solution is designed to enhance your living space with its rustic charm and practical functionality. Ideal for bedrooms, living rooms, or hallways, this dresser provides ample storage for various items and can also serve as a sturdy TV stand. This manual provides comprehensive instructions for assembly, usage, maintenance, and troubleshooting to ensure a smooth and satisfying experience with your new furniture.



Figure 1.1: WLIVE Farmhouse Dresser (Black, 9-Drawer)

2. SAFETY INFORMATION

Your safety is our top priority. Please read and follow all safety instructions carefully before assembly and use.

- **Anti-Tipping Device:** An anti-tipping device is included to prevent accidental tip-overs. It is crucial to install this device securely to a wall stud as per the assembly instructions. Failure to do so may result in serious injury.
- **Weight Limits:** The wood tabletop can support up to 130 lbs (59 kg). Each wood drawer can hold up to 30 lbs (13.6 kg). Do not exceed these weight limits to ensure stability and prevent damage.
- **Drawer Usage:** For safety, avoid opening more than one drawer at a time, especially the top drawers, as this can shift the dresser's center of gravity and increase the risk of tipping.
- **Placement:** Place the dresser on a flat, level surface. Avoid placing it near heat sources, direct sunlight, or in areas with high humidity.
- **Children Safety:** Keep small children away from the assembly area. Do not allow children to climb on or play with the dresser.



Figure 2.1: Anti-Tip Lock Details and Safety Warning

3. PACKAGE CONTENTS

Before beginning assembly, verify that all parts and hardware are present and undamaged. Refer to the included parts list and diagrams in your physical manual for exact identification. If any parts are missing or damaged, please contact customer support.

Typical Components Include:

- Wood Panels (Top, Side, Bottom, Back)
- Drawer Fronts, Sides, and Backs
- Drawer Bottoms
- Metal Drawer Slides (Ball Bearing)
- Square Handles and Screws
- Assembly Hardware (Screws, Dowels, Cam Locks, etc.)
- Anti-Tipping Hardware (Strap, Screws, Wall Anchors)
- Assembly Tools (Basic wrench/screwdriver may be included)

4. ASSEMBLY INSTRUCTIONS

Assembly is designed to be straightforward with detailed, coded instructions. It is recommended to have a second person for certain steps, especially when handling larger panels. A cordless drill can expedite the process, but manual tools are sufficient.

1. **Unpack and Organize:** Carefully unpack all components. Lay them out on a clean, soft surface (e.g., a blanket or cardboard) to prevent scratches. Identify each part using the labels and the parts list.
2. **Assemble the Main Frame:** Follow the step-by-step diagrams in your manual to connect the side panels, top, and bottom panels using the provided hardware. Ensure all connections are tight and secure.
3. **Install Drawer Slides:** Attach the metal drawer slides to the inner sides of the dresser frame and to the drawer boxes as indicated in the instructions. Ensure they are level and aligned for smooth operation.
4. **Assemble Drawers:** Construct each drawer by attaching the front, back, and side panels. Insert the drawer bottom into the grooves. Secure the square handles to the drawer fronts.
5. **Insert Drawers:** Carefully slide each assembled drawer into its designated slot on the dresser frame. Test each drawer for smooth opening and closing.
6. **Attach Anti-Tipping Device:** Position the dresser in its final location. Secure the anti-tipping strap to the back of the dresser and then to a wall stud using the provided screws and anchors. This step is critical for safety.



Figure 4.1: Drawer Features: Handle, Smooth Sliding Rail, and Stable Support

SUPPORT PLATES

STRONGER LOAD CAPACITY



Figure 4.2: Drawer Support Plates for Enhanced Load Capacity

5. USAGE

The WLIVE Farmhouse Dresser is designed for versatile use in various rooms.

- **Storage:** Utilize the nine drawers to organize clothing, accessories, linens, or other household items. The varied drawer sizes accommodate different storage needs.
- **TV Stand:** The sturdy wood top surface is suitable for placing a TV up to 70 inches. Ensure the TV's base fits within the dresser's dimensions and does not exceed the weight capacity.
- **Decorative Display:** The spacious top also provides an excellent area for displaying decorative items, lamps, or personal belongings.



LARGE DRAWER OFFER

MORE STORAGE PLANS



100+
Clothes



40+
Toys



150+
Socks



90+
Hats



100+
Underwear



60+
Tissue



100+
Snacks



80+
Books

Figure 5.1: Large Drawer Storage Capacity



Figure 5.2: Suitable for TV Sizes Up to 70 Inches

6. MAINTENANCE

Proper care will extend the life and appearance of your dresser.

- **Cleaning:** Wipe surfaces with a soft, damp cloth. Avoid using harsh chemicals, abrasive cleaners, or polishes that may damage the finish.
- **Spills:** Immediately wipe up any spills to prevent staining or water damage.
- **Hardware:** Periodically check all screws and fasteners to ensure they remain tight. Tighten if necessary.
- **Drawer Slides:** If drawers become stiff, a small amount of silicone lubricant can be applied to the metal slides.

7. TROUBLESHOOTING

If you encounter any issues with your dresser, refer to the common problems and solutions below.

Problem	Possible Cause	Solution
Drawers do not slide smoothly.	Misaligned slides, loose screws, debris in tracks.	Check slide alignment, tighten screws, clean tracks. Apply silicone lubricant if needed.
Dresser feels wobbly or unstable.	Loose assembly hardware, uneven floor, anti-tip not installed.	Tighten all assembly screws. Ensure dresser is on a level surface. Install or re-secure the anti-tipping device.
Gaps between drawers or panels.	Incorrect assembly, loose cam locks.	Review assembly steps, especially cam lock and dowel connections. Disassemble and reassemble affected sections if necessary.

8. SPECIFICATIONS

- **Brand:** WLIVE
- **Model Name:** ASNG115 Wood dresser/BL
- **Item Model Number:** ASNG115BL
- **Product Dimensions:** 15.67"D x 62.2"W x 31.5"H (39.8 cm D x 158 cm W x 80 cm H)
- **Color:** Black
- **Mounting Type:** Floor Mount
- **Room Type:** Closet, Bedroom, Living Room, Hallway, Home Office
- **Special Features:** Space Saving, Scratch Resistant
- **Assembly Required:** Yes
- **Item Weight:** 111.3 pounds (50.5 kg)
- **Material:** Durable Engineered Wood
- **Tabletop Weight Capacity:** Up to 130 lbs (59 kg)
- **Drawer Weight Capacity:** Up to 30 lbs (13.6 kg) per drawer
- **Country of Origin:** China
- **Date First Available:** June 23, 2025

Product Size



Figure 8.1: Product Dimensions and Capacities

9. WARRANTY AND SUPPORT

WLIVE is committed to providing high-quality products and excellent customer service. This storage drawer unit comes with detailed installation instructions, and all parts and accessories are coded for precise and faster installation.

If you encounter any problems during assembly or use, or if you have questions about your product, please do not hesitate to contact WLIVE customer support. Our team is ready to assist you with solutions.

For support, please refer to the contact information provided with your purchase or visit the official WLIVE store on Amazon:

[WLIVE Store](#)