

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

Manuals.plus /

› [Pxolerig](#) /

› Pxolerig 24 Pack Stackable Shoe Boxes User Manual

Pxolerig shoe storage cabinet

Pxolerig 24 Pack Stackable Shoe Boxes User Manual

Model: shoe storage cabinet

1. INTRODUCTION

Thank you for choosing the Pxolerig 24 Pack Stackable Shoe Boxes. This product is designed to help you organize and protect your footwear efficiently. Featuring a stackable design and clear flip lids, these shoe boxes offer a practical and aesthetically pleasing storage solution for various types of shoes, fitting up to size 13 for flat shoes and size 10.5 (US) for sports shoes.

Please read this manual thoroughly before assembly and use to ensure proper setup and longevity of your shoe boxes.



Figure 1.1: Overview of the Pxolerig 24 Pack Stackable Shoe Boxes, showcasing their design and capacity.

2. SAFETY INFORMATION

- Ensure all components are securely assembled before placing items inside or stacking boxes.
- Do not overload the shoe boxes. Refer to the specifications for maximum weight capacity per box (implied by shoe size limits).
- Keep small parts away from children during assembly to prevent choking hazards.
- Place stacked boxes on a stable, level surface to prevent tipping.
- Avoid exposing the boxes to extreme temperatures or direct sunlight for prolonged periods, as this may affect material integrity.

3. PACKAGE CONTENTS

Upon opening the package, verify that all components are present and undamaged. The package should contain:

- 24 x Shoe Box Components (each box typically consists of a front frame with lid, back panel, two side panels, and top/bottom panels)

- 1 x English Manual (this document)

If any parts are missing or damaged, please contact customer support immediately.

4. SETUP AND ASSEMBLY INSTRUCTIONS

The Pxolerig shoe boxes require simple assembly. Follow these steps to construct each box:

1. **Unpack Components:** Carefully remove all components for one shoe box from the packaging. You should have one front frame with the clear flip lid attached, one back panel, two side panels, and two main body panels (top/bottom).
2. **Attach Side Panels:** Identify the side panels. Align the tabs on the side panels with the corresponding slots on the main body panels (top/bottom). Gently push until they click into place, forming the basic rectangular shape.
3. **Insert Back Panel:** Slide the back panel into the grooves at the rear of the assembled side and main body panels. Ensure it fits snugly.
4. **Attach Front Frame:** Take the front frame with the clear flip lid. Align its tabs with the remaining slots on the front edge of the main body panels. Press firmly until it locks into position. Ensure the flip lid opens and closes smoothly.
5. **Repeat for all Boxes:** Repeat steps 1-4 for all 24 shoe boxes.
6. **Stacking (Optional):** Once individual boxes are assembled, you can stack them vertically or horizontally using the interlocking design features on the top and bottom of each box. Ensure they are stable before placing shoes inside.



Figure 4.1: Assembled shoe boxes ready for use or stacking.



Figure 4.2: Detail of the clear flip lid mechanism.

5. OPERATING INSTRUCTIONS

Using your Pxolerig shoe boxes is straightforward:

- **Opening the Lid:** To access your shoes, gently pull the clear flip lid outwards from the circular hole. The lid will pivot downwards, providing easy access to the contents.
- **Storing Shoes:** Place one pair of shoes per box. Ensure the shoes fit comfortably without forcing the lid closed. The clear lid allows for quick identification of the shoes inside.
- **Closing the Lid:** Push the flip lid upwards until it clicks securely into its closed position. This helps protect your shoes from dust and keeps them neatly stored.
- **Stacking:** The boxes are designed to interlock for stable stacking. Align the grooves on the top of one box with the corresponding ridges on the bottom of another. You can stack them vertically to save floor space or arrange them horizontally to fit various storage areas.



Figure 5.1: Example of stacked shoe boxes in a home environment.

6. MAINTENANCE AND CARE

To ensure the longevity and appearance of your Pxlerig shoe boxes, follow these simple care guidelines:

- **Cleaning:** Wipe the boxes with a soft, damp cloth. For stubborn marks, a mild soap solution can be used. Avoid abrasive cleaners or harsh chemicals, as these may damage the material.
- **Drying:** Allow the boxes to air dry completely before closing the lids or storing shoes, especially if they have been cleaned with water.
- **Dusting:** Regularly dust the exterior of the boxes to maintain their clear appearance and prevent dust accumulation inside.
- **Storage Environment:** Store the boxes in a cool, dry place away from direct sunlight and excessive humidity to prevent material degradation.

7. TROUBLESHOOTING

Here are some common issues and their solutions:

- **Boxes are unstable when stacked:**
 - Ensure all boxes are fully assembled and all panels are securely clicked into place.
 - Verify that the stacking grooves and ridges are properly aligned between boxes.
 - Place the stacked unit on a flat, level surface.
- **Flip lid does not close properly:**
 - Check if any part of the shoe inside is obstructing the lid's path.
 - Ensure the lid is correctly attached to the front frame and not bent or damaged.
- **Difficulty assembling panels:**
 - Ensure you are using the correct panels for each side. Refer to the assembly steps.
 - Apply firm, even pressure when clicking components together. Do not force them if they don't align.

If you encounter issues not listed here or if the problem persists, please contact customer support.

8. SPECIFICATIONS

Brand	Pxolerig
Model	shoe storage cabinet
Color	Black
Material	PP, HIPS (Polypropylene, High Impact Polystyrene)
Mount Type	Free Standing
Assembly Required	Yes
Product Dimensions (each box)	33 cm (L) x 23 cm (W) x 14 cm (H) / 12.99 in (L) x 9.06 in (W) x 5.51 in (H)
Applicable Shoe Size	Flat Shoes: Up to Chinese Size 44 (approx. US Men's 10.5 / US Women's 12) Sports Shoes: Up to Chinese Size 37 (approx. US Men's 5 / US Women's 6.5)
Net Weight (total)	4.5 kg / 9.92 lbs
Gross Weight (total)	4.9 kg / 10.8 lbs
Closure Type	Flip Top
Number of Items	24

24PCS




Figure 8.1: Dimensions of a single Pxolerig shoe box.

9. WARRANTY AND SUPPORT

Pxolerig is committed to providing high-quality products and excellent customer service. While specific warranty details are not provided in this manual, we encourage you to contact the seller or manufacturer directly for any questions regarding product defects, missing parts, or assembly assistance.

Please retain your purchase receipt as proof of purchase. For support, refer to the contact information provided by your retailer or on the product packaging.