

## XO-X26

# Generic XO-X26 Portable Wireless Earphones User Manual

Model: XO-X26

## 1. INTRODUCTION

This manual provides detailed instructions for the safe and efficient use of your Generic XO-X26 Portable Wireless Earphones. Please read this manual thoroughly before using the product and retain it for future reference. The XO-X26 earphones are designed to provide a convenient and high-quality audio experience through Bluetooth connectivity.

## 2. PACKAGE CONTENTS

Please check the package for the following items:

- XO-X26 Wireless Earbuds (Left and Right)
- Charging Case
- USB Charging Cable
- User Manual



Image: Retail packaging for the XO-X26 Wireless Earphones, showing the earbuds and charging case.

### 3. PRODUCT OVERVIEW

---

Familiarize yourself with the components of your XO-X26 earphones.



Image: The XO-X26 wireless earbuds placed inside their black charging case, which features a textured surface and an attached black lanyard.




Image: The XO-X26 wireless earbuds in their charging case, positioned on a reflective surface with a blue water background, illustrating their water resistance.



Image: The XO-X26 wireless earbuds in their charging case, resting on a clear glass desk in an indoor setting, highlighting their compact design.



Image: The XO-X26 wireless earbuds in a white charging case, with a green indicator light visible, showing the earbuds ready for use.

## 4. SETUP

### 4.1 Charging the Earphones and Case

Before first use, fully charge the earphones and the charging case.

1. Place the earbuds into the charging case. Ensure they are correctly seated.
2. Connect the USB charging cable to the charging port on the case and to a USB power source (e.g., computer, wall adapter).
3. The indicator light on the charging case will illuminate to show charging status.
4. Once fully charged, disconnect the charging cable.

The charging case provides additional charges for the earbuds, extending their usage time.

### 4.2 Pairing with a Bluetooth Device

To connect your XO-X26 earphones to your smartphone or other Bluetooth-enabled device:

1. Ensure the earbuds are charged.
2. Open the charging case. The earbuds will automatically enter pairing mode, and an indicator light on the earbuds or case will flash.
3. On your device, go to Bluetooth settings and turn Bluetooth on.
4. Search for available devices. Select "XO-X26" from the list.
5. Once connected, a confirmation sound or indicator light change will occur.
6. The earphones will automatically reconnect to the last paired device when taken out of the case, if

Bluetooth is enabled on the device.

## 5. OPERATING THE EARPHONES

The XO-X26 earphones feature intuitive touch controls.

### 5.1 Basic Controls

- **Play/Pause:** Single tap on either earbud.
- **Next Track:** Double tap on the right earbud.
- **Previous Track:** Double tap on the left earbud.
- **Volume Up:** Triple tap on the right earbud.
- **Volume Down:** Triple tap on the left earbud.

### 5.2 Call Management

- **Answer/End Call:** Single tap on either earbud.
- **Reject Call:** Press and hold either earbud for 2 seconds.

### 5.3 Voice Assistant

- **Activate Voice Assistant (Siri/Google Assistant):** Press and hold either earbud for 3 seconds.

## 6. MAINTENANCE

Proper maintenance ensures the longevity and optimal performance of your XO-X26 earphones.

- **Cleaning:** Use a soft, dry, lint-free cloth to clean the earbuds and charging case. Do not use abrasive cleaners or solvents.
- **Water Resistance:** The earphones are IPX4 water-resistant, meaning they are protected against splashing water from any direction. They are not designed for submersion in water. Do not expose them to heavy rain or immerse them.
- **Storage:** When not in use, store the earphones in their charging case to protect them from dust and damage. Store in a cool, dry place.
- **Battery Care:** To preserve battery life, charge the earphones regularly, even if not used frequently. Avoid fully discharging the battery for extended periods.

## 7. TROUBLESHOOTING

If you encounter issues with your XO-X26 earphones, refer to the following common solutions:

Problem	Solution
Earbuds not pairing	<ul style="list-style-type: none"><li>• Ensure both earbuds are charged.</li><li>• Turn off and on your device's Bluetooth.</li><li>• Forget "XO-X26" in your device's Bluetooth settings and try pairing again.</li><li>• Place earbuds back in the case, close, then reopen to re-enter pairing mode.</li></ul>

Problem	Solution
No sound from one earbud	<ul style="list-style-type: none"> <li>Ensure both earbuds are charged.</li> <li>Try resetting the earbuds (refer to specific reset instructions if available, otherwise try re-pairing).</li> <li>Clean the charging contacts on both the earbuds and the case.</li> </ul>
Charging case not charging	<ul style="list-style-type: none"> <li>Ensure the charging cable is securely connected.</li> <li>Try a different USB power source or charging cable.</li> </ul>
Poor audio quality	<ul style="list-style-type: none"> <li>Ensure the earbuds are properly seated in your ears.</li> <li>Move closer to your connected device to avoid interference.</li> <li>Check your device's audio settings.</li> </ul>

## 8. SPECIFICATIONS

<b>Model Name:</b>	XO-X26
<b>Brand:</b>	Generic
<b>Connectivity:</b>	Wireless (Bluetooth)
<b>Form Factor:</b>	In Ear
<b>Color:</b>	Black
<b>Water Resistance:</b>	IPX4
<b>Included Components:</b>	Charging Cable, Charging Case, Earbuds, User Manual

## 9. WARRANTY AND SUPPORT

The Generic XO-X26 Portable Wireless Earphones come with a manufacturer's warranty of **6 months** from the date of purchase.

This warranty covers defects in materials and workmanship under normal use. It does not cover damage caused by misuse, accidents, unauthorized modifications, or normal wear and tear.

For warranty claims or technical support, please contact your retailer or the point of purchase. Please retain your proof of purchase for warranty validation.

### Related Documents - XO-X26

	<p><a href="#"><u>YUZINO X26 Projector User Manual: Setup, Operation, and Features</u></a></p> <p>Comprehensive user manual for the YUZINO X26 projector, covering safety instructions, basic parameters, connection methods (HDMI, USB, Wi-Fi, Bluetooth), screen mirroring, menu settings, installation, and FCC compliance.</p>
	<p><a href="#"><u>LED Lighted Medicine Cabinet Installation and Operating Manual</u></a></p> <p>This manual provides detailed installation and operating instructions for the LED Lighted Medicine Cabinet. It covers model specifications, safety guidelines, and step-by-step procedures for surface and embedded mounting, along with operational features like lighting, defogging, and clock settings.</p>
	<p><a href="#"><u>CMACEWHEEL Electric Bicycle User Manual</u></a></p> <p>Comprehensive user manual for CMACEWHEEL electric bicycles, covering operation, battery and charger information, troubleshooting, warranty, and product descriptions for various models.</p>
	<p><a href="#"><u>VEVOR X26 Bladeless Table Fan User Manual</u></a></p> <p>User manual for the VEVOR X26 Bladeless Table Fan, providing detailed instructions on operation, safety precautions, product features, specifications, and maintenance.</p>
	<p><a href="#"><u>MODELCOM SC X26 Wireless Speaker User Manual</u></a></p> <p>User manual for the MODELCOM SC X26 wireless speaker, detailing features, specifications, and usage instructions.</p>
	<p><a href="#"><u>VEVOR Bladeless Table Fan Model X26 User Manual</u></a></p> <p>User manual for the VEVOR Bladeless Table Fan, Model X26. Learn about its features, safe operation, and maintenance for optimal performance. Includes bladeless technology and spray function.</p>