

Respekta AB141-26

Respekta AB 141-26 Built-in Oven User Manual

Model: AB 141-26

1. INTRODUCTION

Thank you for choosing the Respekta AB 141-26 Built-in Oven. This manual provides essential information for the safe and efficient use, installation, and maintenance of your new appliance. Please read these instructions carefully before operating the oven and keep them for future reference.

2. SAFETY INFORMATION

General Safety:

- This appliance is intended for household use only.
- Ensure the oven is properly installed and grounded by a qualified person before use.
- Do not touch hot surfaces. Always use oven mitts or gloves when handling hot items.
- Keep children and pets away from the appliance during operation, as surfaces can become very hot.
- Never use water to extinguish oil or grease fires. Smother the flames with a lid or fire blanket.
- Disconnect the appliance from the power supply before cleaning or maintenance.

Electrical Safety:

- Ensure the voltage and frequency of your power supply match the specifications on the rating plate.
- Do not use extension cords or multiple adapters.
- If the power cord is damaged, it must be replaced by the manufacturer, its service agent, or similarly qualified persons to avoid a hazard.

3. PRODUCT OVERVIEW

The Respekta AB 141-26 is a built-in electric oven designed for efficient and versatile cooking. It features a 72-liter capacity and 10 heating modes.



Front view of the Respekta AB 141-26 built-in oven, showcasing its sleek design with a stainless steel control panel and black glass door.

Control Panel



Close-up of the oven's control panel, featuring two rotary knobs for function and temperature selection, and a central digital display for timer and settings.

Oven Interior



View inside the oven cavity, showing the rear fan for air circulation and multiple rack positions.

Included Components

The following items are included with your Respekta AB 141-26 oven:

- Respekta AB 141-26 Built-in Oven
- Enameled Baking Tray
- Grill Rack
- Mounting Kit
- Instruction Manual

4. INSTALLATION

The Respekta AB 141-26 is designed as a built-in oven. For proper installation, ensure adequate ventilation around the appliance. The oven comes with a 1.5-meter power cable and a safety plug, allowing for direct connection to a suitable power outlet without requiring a separate electrician for initial wiring (Plug & Bake feature).



The Respekta AB 141-26 oven seamlessly integrated into a modern kitchen cabinet, demonstrating its built-in design.

Installation Steps:

1. Prepare the cabinet opening according to the specified dimensions (refer to the mounting kit instructions).
2. Carefully slide the oven into the prepared opening.
3. Secure the oven to the cabinet using the provided mounting kit.
4. Plug the power cable into a grounded electrical outlet.
5. Ensure the oven is level and stable before first use.

5. OPERATING INSTRUCTIONS

Your Respekta AB 141-26 oven offers a variety of heating modes and precise temperature control for diverse

cooking needs.

Heating Modes

The oven features 10 distinct heating modes, selected via the function knob:

- **Defrost:** Gentle thawing of frozen foods.
- **Top and Bottom Heat:** Traditional cooking for baking and roasting.
- **Bottom Heat with Air Circulation:** Ideal for crisping bases or slow cooking.
- **Top and Bottom Heat with Air Circulation:** Even cooking and browning for a wide range of dishes.
- **Hot Air (Convection):** For multi-level cooking and faster, more even results.
- **Grill:** For grilling and browning smaller items.
- **Steam Cleaning:** For easy cleaning of the oven interior (refer to Maintenance section).
- Additional combinations for specialized cooking.

Temperature Control


The oven allows temperature settings from 60°C to 250°C. Use the temperature knob to select the desired heat.



Close-up of the temperature control knob, showing markings from 60°C to 250°C and a maximum setting.

LED Timer

The integrated LED timer allows you to set cooking durations and monitor the cooking process. Refer to the digital display for time settings and indicators.



Detailed view of the oven's digital LED display, showing time and various function indicators.

6. MAINTENANCE AND CLEANING

Regular cleaning and maintenance will ensure the longevity and optimal performance of your oven.

Steam Cleaning Function:

- Pour a small amount of water into the bottom of the oven cavity.
- Select the 'Steam Cleaning' heating mode.
- The steam generated will help loosen food residues, making them easier to wipe away.
- After the cycle, allow the oven to cool, then wipe the interior with a soft cloth.

General Cleaning:

- Always ensure the oven is cool and disconnected from the power supply before cleaning.
- Clean the exterior surfaces with a soft, damp cloth and mild detergent. Avoid abrasive cleaners.
- For the interior, use oven-safe cleaning products as directed by the manufacturer, or a solution of warm water and mild soap.
- Remove and clean the baking tray and grill rack separately.

7. TROUBLESHOOTING

If you encounter issues with your oven, please refer to the following common troubleshooting tips before contacting customer service.

- **Oven not heating:** Check if the oven is properly plugged in and if the circuit breaker has tripped. Ensure the correct heating mode and temperature are selected.

- **Display not working:** Verify power supply. If the issue persists, a power cycle (unplugging and replugging) might resolve it.
- **Uneven cooking:** Ensure food is placed centrally and that the correct heating mode for the dish is selected. Avoid overcrowding the oven.

For persistent problems, please contact Respekta customer support.

8. SPECIFICATIONS

Feature	Specification
Brand	Respekta
Model Number	AB141-26
Type	Built-in Electric Oven
Capacity	72 Liters
Energy Efficiency Class	A
Power	3400 Watts
Voltage	230 Volts
Heating Modes	10 (including Defrost, Top/Bottom Heat, Convection, Grill, Steam Cleaning)
Temperature Range	60°C to 250°C
Product Dimensions (D x W x H)	52.1 x 59.4 x 59.5 cm
Weight	30.5 Kilograms
Material	Stainless Steel, Aluminum, Glass
Cable Length	1.5 meters

9. WARRANTY AND SUPPORT

For warranty information, please refer to the documentation provided at the time of purchase. If you require technical assistance or have questions regarding your Respekta AB 141-26 oven, please contact Respekta customer support.

Spare parts availability: Information unavailable.

Please have your model number (AB 141-26) and purchase date ready when contacting support.

