

Techwood TAN-8006R

Techwood TAN-8006R Rechargeable Cleaner/Stain Remover User Manual

Model: TAN-8006R

1. INTRODUCTION

Thank you for choosing the Techwood TAN-8006R Rechargeable Cleaner/Stain Remover. This device is designed for efficient removal of everyday stains from various surfaces. Please read this manual carefully before first use to ensure proper operation, maintenance, and to maximize the lifespan of your product. Keep this manual for future reference.

2. SAFETY INSTRUCTIONS

Always follow basic safety precautions when using electrical appliances to reduce the risk of fire, electric shock, or injury.

- Read all instructions before use.
- Do not immerse the appliance, battery, or charger in water or other liquids.
- Keep the appliance away from children and pets.
- Use only the charger supplied with the appliance.
- Do not use the appliance if the power cord or plug is damaged.
- Do not use the appliance to pick up flammable or combustible liquids, or anything that is burning or smoking.
- Ensure the clean water tank is filled with appropriate cleaning solution and water, and never use harsh chemicals.
- Empty and clean the dirty water tank after each use to prevent odor and bacterial growth.
- Store the appliance in a dry place when not in use.

3. PRODUCT OVERVIEW

The Techwood TAN-8006R is a versatile, cordless stain remover featuring two separate tanks for clean and dirty water, two operating speeds, and a powerful lithium battery for extended use.



Figure 3.1: Main unit with clearly marked clean (1.5 L) and dirty (0.85 L) water tanks, and the extra-large brush attachment.

Key Features:

- **Rechargeable and Cordless:** Provides freedom of movement for cleaning various areas.
- **Dual Tank System:** Separate tanks for clean water (1.5 L) and dirty water (0.85 L) ensure effective cleaning without cross-contamination.
- **Two Speeds:** Allows adjustment for different cleaning needs and stain types.
- **Long Battery Life:** Up to 40 minutes of autonomy on a single charge.
- **Quick Charging:** Fully charges in 4-5 hours.
- **Versatile Attachments:** Includes a 2-in-1 nozzle and a crevice nozzle for targeted cleaning.



Figure 3.2: Battery and charging information, along with the crevice nozzle accessory.

4. SETUP

4.1 Charging the Battery

1. Before first use, fully charge the appliance.
2. Connect the charger to the charging port on the appliance.
3. Plug the charger into a suitable power outlet.
4. The charging indicator light will illuminate. A full charge takes approximately 4-5 hours.
5. Once fully charged, disconnect the charger.

4.2 Filling the Clean Water Tank

1. Remove the clean water tank (1.5 L capacity) from the main unit.
2. Open the tank cap.
3. Fill the tank with clean water and an appropriate, low-foaming cleaning solution (if desired) according to the solution's instructions. Do not exceed the 'MAX' fill line.

4. Close the tank cap securely and reattach the tank to the main unit.

4.3 Attaching Accessories

1. Select the desired nozzle (2-in-1 nozzle or crevice nozzle) for your cleaning task.
2. Align the nozzle with the suction port on the hose and push firmly until it clicks into place.
3. Ensure the attachment is securely fastened before operation.

5. OPERATING INSTRUCTIONS

The Techwood TAN-8006R is suitable for cleaning various surfaces including carpets, cushions, vehicle interiors, and stairs.



Figure 5.1: Examples of multi-surface cleaning applications.

5.1 General Operation

1. Ensure the battery is charged and the clean water tank is filled.
2. Press the power button to turn on the appliance.

3. Select the desired speed (low or high) using the speed control button.
4. Position the nozzle over the stained area.
5. Press the spray trigger to dispense cleaning solution onto the stain.
6. Move the nozzle slowly over the stain, applying gentle pressure, to scrub and extract the dirty liquid. The 2-in-1 nozzle is designed to spray, scrub, and extract.
7. Repeat the process until the stain is removed or the dirty water tank is full.
8. Turn off the appliance by pressing the power button.



Figure 5.2: The 2-in-1 nozzle in action, demonstrating its spray, scrub, and extract functions.

5.2 Emptying the Dirty Water Tank

1. When the dirty water tank (0.85 L capacity) reaches its 'MAX' fill line, or after each use, it must be emptied.
2. Remove the dirty water tank from the main unit.
3. Carefully open the tank cap and pour out the dirty water into a drain.
4. Rinse the tank thoroughly with clean water.
5. Close the tank cap securely and reattach the tank to the main unit.

6. MAINTENANCE

Regular maintenance ensures optimal performance and extends the life of your Techwood TAN-8006R.

6.1 Cleaning the Tanks and Nozzles

- After each use, empty and rinse both the clean and dirty water tanks with fresh water. Allow them to air dry completely before reassembling.
- Remove any attached nozzles and rinse them under running water to clear any debris or residue.
- Use a soft brush if necessary to clean stubborn dirt from the nozzles.

6.2 Cleaning the Main Unit

- Wipe the exterior of the main unit with a damp cloth. Do not use abrasive cleaners or immerse the unit in water.
- Check the suction port for any blockages and clear them if necessary.

6.3 Storage

- Ensure the appliance is clean and dry before storing.
- Store the appliance and its accessories in a cool, dry place, away from direct sunlight and extreme temperatures.

7. TROUBLESHOOTING

If you encounter any issues with your Techwood TAN-8006R, please refer to the following troubleshooting guide:

Problem	Possible Cause	Solution
Appliance does not turn on	Battery is not charged.	Charge the battery for 4-5 hours.
Low suction power	Dirty water tank is full. Nozzle is blocked. Hose is blocked.	Empty the dirty water tank. Clean the nozzle. Check and clear any blockages in the hose.
No spray from nozzle	Clean water tank is empty. Spray nozzle is blocked.	Refill the clean water tank. Clean the spray nozzle opening.
Leaking from unit	Tanks are not properly seated. Tank caps are not securely closed.	Ensure both clean and dirty water tanks are correctly installed. Check that all tank caps are tightly closed.

8. SPECIFICATIONS

Feature	Specification
---------	---------------

Feature	Specification
Brand	Techwood
Model Number	TAN-8006R
Color	Black
Dimensions (L x W x H)	35 x 28.5 x 36.8 cm
Weight	4.3 Kilograms
Clean Water Tank Capacity	1.5 Liters
Dirty Water Tank Capacity	0.850 Liters
Battery Type	Lithium-ion (2200 mAh)
Battery Autonomy	Up to 40 minutes
Charge Time	4-5 hours
Power Source	Battery Powered
Spare Parts Availability (EU)	5 Years
Manufacturing Year	2024

9. WARRANTY AND SUPPORT

Techwood provides a commitment to spare parts availability for 5 years within the EU for the TAN-8006R model. For specific warranty terms, service, or support inquiries, please refer to the warranty card included with your product or contact Techwood customer service directly. Contact information can typically be found on the manufacturer's official website or on the product packaging.