

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [GAOMON](#) /

› [GAOMON Rattan Shoe Cabinet Instruction Manual](#)

GAOMON Rattan Shoe Cabinet

GAOMON Rattan Shoe Cabinet Instruction Manual

Model: Rattan Shoe Cabinet

SAFETY INFORMATION

Please read and understand all safety instructions before assembly and use. Failure to follow these instructions may result in injury or product damage.

- Always secure the anti-tip device to the wall to prevent tipping. This is crucial for safety, especially in households with children or pets.
- Be cautious during assembly to avoid injury. Wear appropriate safety gear if necessary.
- This product is designed for long-term use and should be handled accordingly. Avoid overloading shelves.
- Keep small parts and packaging materials away from children.

Prevent Tip-over Incidents Ensuring your family's Safety




Image: Illustration of the anti-tip device installation. The top diagram shows the cabinet secured to the wall (green checkmark), while the bottom diagram shows an unsecured cabinet tipping over (red cross), emphasizing the importance of securing the furniture.

PRODUCT OVERVIEW

The GAOMON Rattan Shoe Cabinet is a freestanding storage organizer designed for entryways, hallways, living rooms, or closets. It features three rattan doors and adjustable shelves to accommodate various shoe types and sizes.



Image: A full view of the GAOMON Rattan Shoe Cabinet, showcasing its three doors with natural rattan inserts and the interior filled with different types of footwear, from sneakers to high heels and boots. The cabinet is placed in a well-lit entryway.

Key Features:

- **Versatile Style:** Enhances aesthetics in various spaces like entry halls, dorm rooms, or small apartments.
- **Large Storage Space:** Measures 46.10"L x 13.9"W x 28.7"H, storing 24-28 pairs of shoes.
- **Adjustable Shelves:** The right side of the cabinet features an adjustable shelf for ankle boots, high heels, or taller items.
- **Chic Design:** Modern style with rattan doors protects shoes from dust, pets, and insects.
- **Sturdy Structure:** Constructed from high-quality MDF engineered wood with a thickened waterproof desktop for durability and stability.
- **Anti-Tip Device:** Includes a device to securely attach the cabinet to the wall for safety.

Shoe Storage Cabinet for Entryway



Flip-Flops



Boots



Loafer



High-Heeled Shoes



High-Top Shoes



Long boots

Image: An illustration demonstrating the storage capacity and versatility of the shoe cabinet. It shows different types of footwear, such as flip-flops, boots, loafers, high-heeled shoes, high-top shoes, and long boots, indicating that the cabinet can accommodate a wide range of shoe styles and sizes.

PACKAGE CONTENTS

Before beginning assembly, ensure all parts listed below are present and undamaged. If any parts are missing or damaged, please contact customer support.

- Cabinet Panels (Top, Bottom, Side, Back)
- Rattan Doors (3 units)
- Adjustable Shelves
- Fixed Shelves
- Hardware Kit (screws, dowels, hinges, handles, anti-tip device)
- Metal Legs

ASSEMBLY INSTRUCTIONS

Assembly is straightforward with clear step-by-step instructions provided in the included manual. All screws

and parts are labeled for easy identification. It is recommended to assemble the cabinet on a soft, clean surface to prevent scratches.

1. **Unpack and Identify:** Carefully unpack all components and lay them out. Refer to the parts list to ensure everything is present.
2. **Assemble the Frame:** Connect the side panels to the bottom and top panels using the provided hardware. Ensure all connections are secure.
3. **Install Back Panel:** Attach the back panel to the assembled frame.
4. **Attach Doors:** Mount the three rattan doors using the hinges. Adjust hinges as needed to ensure proper door alignment and smooth opening/closing.
5. **Insert Shelves:** Place the fixed shelves into their designated slots. Install the adjustable shelves at your desired height.
6. **Attach Metal Legs:** Secure the metal legs to the bottom of the cabinet.
7. **Secure Anti-Tip Device:** Follow the instructions in the Safety Information section to securely attach the anti-tip device to a wall stud.



Natural Rattan

Hand-woven, it is not just a piece of furniture, but also a fabulous decor

Heavy-duty Metal

Ensuring it's sturdy and durable, provides excellent stability

Image: A detailed view highlighting the natural rattan material used in the door panels and the robust heavy-duty metal legs that provide stability to the cabinet. This image illustrates key structural components.




Image: An interior shot of the shoe cabinet, demonstrating the adjustable shelves. This view emphasizes the flexibility in configuring the storage space to accommodate different shoe heights and sizes.

OPERATION

Using your GAOMON Rattan Shoe Cabinet is simple and designed for convenience.

- **Opening and Closing Doors:** Gently pull the handles to open the rattan doors. Push them firmly to close. Avoid slamming the doors to prevent damage to hinges and rattan inserts.
- **Adjusting Shelves:** The right compartment features adjustable shelves. To adjust, remove all items from the shelf, lift the shelf, and reposition the shelf pegs into the desired holes. Ensure the shelf is level and securely seated before placing items back.
- **Shoe Placement:** Organize shoes by type or frequency of use. Utilize the adjustable shelves for taller footwear like boots or high heels.



Before

Only 2 - tier Shelf



After

Ample Storage with
4 -Tier Shelf

Image: A side-by-side comparison illustrating the benefit of adjustable shelving. The "Before" section shows a limited 2-tier shelf, while the "After" section displays an ample 4-tier storage configuration within the cabinet, highlighting its flexible storage capabilities.

CARE AND MAINTENANCE

Proper care will ensure the longevity and appearance of your shoe cabinet.

- **Cleaning:** Wipe surfaces with a soft, damp cloth. Avoid harsh chemicals or abrasive cleaners, which can damage the engineered wood finish and rattan.
- **Rattan Care:** For the rattan inserts, gently dust with a soft brush or vacuum with a brush attachment. Avoid excessive moisture.
- **Spills:** Immediately wipe up any spills to prevent staining or water damage to the engineered wood.
- **Inspection:** Periodically check all screws and connections to ensure they remain tight. Retighten if necessary.
- **Sunlight Exposure:** Avoid prolonged direct sunlight exposure, which can cause fading or damage to the wood and rattan.

TROUBLESHOOTING

Refer to this section for common issues and their solutions.

Problem	Possible Cause	Solution
Doors are not balanced or close properly.	Hinges are not properly adjusted or loose.	Adjust the screws on the hinges to align the doors. Refer to the hinge adjustment guide in the assembly manual (if provided) or online resources. Ensure all hinge screws are tight.
Rattan panel is separating from the door frame.	Adhesive failure or impact.	Carefully re-glue the rattan panel back into the door frame using a suitable wood or craft adhesive. Apply pressure until dry.
Cabinet feels unstable or wobbly.	Loose connections or uneven floor.	Check and tighten all assembly screws. Ensure the cabinet is placed on a level surface. If necessary, use shims under the legs to stabilize. Confirm the anti-tip device is securely installed.

PRODUCT SPECIFICATIONS

Feature	Detail
Brand	GAOMON
Model Name	Rattan Shoe Cabinet
Color	White
Material	Engineered Wood
Product Dimensions (D x W x H)	13.9" x 46.1" x 28.7"
Item Weight	80 Pounds
Number of Shelves	7 (including adjustable)
Number of Doors	3
Mounting Type	Floor Mount (Freestanding with Anti-Tip)
Assembly Required	Yes
Additional Features	Adjustable Shelf, Anti-Tipping, Heavy Duty, Weatherproof (desktop)

WARRANTY AND CUSTOMER SUPPORT

GAOMON is committed to providing quality products and customer satisfaction.

- **Return Policy:** This product is eligible for a 30-day return policy (refund/replacement) from the date of purchase. Please refer to your retailer's specific return guidelines.

- **Customer Support:** For any questions regarding assembly, missing parts, or product issues, please contact GAOMON customer support through your purchase platform or the contact information provided by the seller.