

[Manuals.plus](#) /

> [UMIDIGI](#) /

> UMIDIGI Note 100A Android 14 Smartphone User Manual

UMIDIGI Note 100A

UMIDIGI Note 100A Android 14 Smartphone User Manual

Model: Note 100A

INTRODUCTION

This manual provides essential information for setting up, operating, maintaining, and troubleshooting your UMIDIGI Note 100A smartphone. Please read it carefully to ensure proper use and to maximize the device's performance and longevity.

WHAT'S IN THE BOX

Verify that all items are present in the package:

- 1 x UMIDIGI Note 100A Smartphone
- 1 x USB Cable
- 1 x Power Adapter (Note: A 10W charger is included; the device supports up to 20W charging.)
- 1 x Pre-applied Screen Protector Film
- 1 x Smartphone Case
- 1 x SIM Tray Ejector
- 1 x User Manual

UMIDIGI Note 100A



Image: UMIDIGI Note 100A package contents, including the phone, charger, cable, case, and manual.

DEVICE OVERVIEW

Familiarize yourself with the physical components of your UMIDIGI Note 100A smartphone.




Image: Front and back view of the UMIDIGI Note 100A smartphone, highlighting its sleek design.



Wi-Fi 2.4GHz / 5GHz



3.5mm
ヘッドフォンジャック



FM ラジオ



Bluetooth 5.2

Image: Detailed diagram of the UMIDIGI Note 100A, showing the 3.5mm headphone jack, Type-C port, speaker, power button, volume buttons, SIM/TF card slot, fingerprint sensor, 8MP front camera, 2MP depth camera, and 13MP main camera.

SETUP

SIM Card and MicroSD Card Installation

The UMIDIGI Note 100A supports nano-SIM cards and features a dual SIM card slot, allowing for either two SIM cards or one SIM card and one TF (MicroSD) card for expanded storage.

1. Locate the SIM tray on the side of the device.
2. Insert the SIM tray ejector tool into the small hole next to the tray and press firmly until the tray pops out.
3. Place your nano-SIM card(s) and/or MicroSD card into the designated slots on the tray, ensuring correct orientation.
4. Carefully reinsert the tray into the device until it clicks into place.

13MP + 8MP デュアルカメラ

今この瞬間を大切に生きる



Image: Illustration of how to insert SIM cards and a MicroSD card into the phone's tray.

Initial Power On

To power on your device for the first time, press and hold the power button located on the side of the phone until the UMIDIGI logo appears on the screen. Follow the on-screen prompts to complete the initial setup process.

RAM Expansion

The UMIDIGI Note 100A comes with 8GB (4GB + 4GB virtual) RAM. To activate the full 8GB RAM, follow these steps:

1. Go to **Settings**.
2. Navigate to **Memory Expansion**.
3. Select **Perform memory expansion size setting**.
4. Choose **4GB** for expansion.
5. Restart your device for the changes to take effect.

8(4+4)GB RAM + 256GB ROM

最大 1TB まで拡張可能




Image: Diagram illustrating the 8GB (4GB+4GB) RAM and 256GB ROM with 1TB expansion capability of the UMIDIGI Note 100A.

OPERATING INSTRUCTIONS

Android 14 System

The UMIDIGI Note 100A runs on the latest Android 14 operating system, offering enhanced data protection, improved system stability, and advanced visual design and functionality for a smoother and more private user experience.

Android 14 システム

よりスムーズな操作と、より安全なプライバシー



Image: Screenshot of the Android 14 user interface, showcasing various widgets and privacy features.

Display Features

Experience content on a large 6.8-inch display with a 120Hz high refresh rate for smooth scrolling and video playback. The display also incorporates eye care technology to reduce eye strain during prolonged use.

6.8インチ 目に優しいディスプレイ

120Hz 高リフレッシュレート

 1600×720
解像度

 450nits
輝度

 6.8インチ
目の保護モード

 120Hz
リフレッシュレート



120Hz

Image: The 6.8-inch display of the UMIDIGI Note 100A, highlighting its 120Hz refresh rate and eye protection mode, with a dynamic image of a snowboarder.



Image: Specifications of the UMIDIGI Note 100A display, including 6.8-inch HD+ size, 1600x720 resolution, 450 nits brightness, and 120Hz refresh rate.

Camera Usage

The smartphone is equipped with a versatile camera system, including a 13MP main camera, a 2MP depth camera, and an 8MP front camera. It supports various shooting modes such as Panorama, Portrait, Night Mode, Time-lapse, and Slow Motion.




Image: Overview of the UMIDIGI Note 100A's camera system, detailing the 8MP front camera, 13MP rear camera, and 2MP depth camera, alongside sample photographs.

Connectivity

The UMIDIGI Note 100A offers comprehensive connectivity options:

- **Wi-Fi:** Supports 2.4GHz and 5GHz bands for fast internet access.
- **Bluetooth:** Features Bluetooth 5.2 for efficient wireless connections with accessories.
- **GPS:** Integrated high-precision navigation system supporting GPS, Glonass, Galileo, and Beidou for accurate location services.
- **FM Radio:** Enjoy FM radio broadcasts anytime, anywhere.

UMIDIGI Note 100A



顔認証



Wi-Fi 2.4GHz
5GHz




Bluetooth
5.2



指紋認証



GPS



デュアルSIM



FM



Image: Visual representation of the UMIDIGI Note 100A's connectivity features, including Wi-Fi 2.4GHz/5GHz, Bluetooth 5.2, 3.5mm headphone jack, FM radio, face recognition, fingerprint recognition, GPS, and dual SIM support.



Image: A smartphone mounted in a car dashboard displaying GPS navigation, illustrating the device's support for GPS, Glonass, Galileo, and Beidou systems.

Security Features

The UMIDIGI Note 100A provides secure and convenient unlocking methods:

- **Fingerprint Recognition:** Unlock your device quickly and securely using the side-mounted fingerprint sensor.
- **Face Recognition:** Use your face to unlock the phone with advanced facial recognition technology.

MAINTENANCE

Battery and Charging

The UMIDIGI Note 100A is equipped with a 5000mAh battery, providing extended usage time. It supports up to 20W fast charging via its USB Type-C port. Please note that a 10W charger is included in the box.



Image: The UMIDIGI Note 100A connected to a charger via its USB Type-C port, displaying a charging animation and indicating 5000mAh battery capacity and 20W charging support.

TROUBLESHOOTING

Network Compatibility

This Android smartphone is designed for use in many countries and regions, but supported frequency bands may vary by carrier and region. Before purchasing, please confirm that your carrier's network bands are compatible with this product. The supported frequency bands are:

- **2G GSM:** B2/3/5/8

- **3G WCDMA:** B1/2/4/5/8
- **4G FDD:** B1/B2/B3/B7/B8/B12(17)/B20/B26(5/18/19)/B28/B66(B4)AB/66
- **4G TDD:** B38/B40/B41F

SPECIFICATIONS

Brand	UMIDIGI
Operating System	Android 14
Installed RAM Size	4 GB (Expandable to 8GB)
CPU Model	Others
CPU Speed	1.8 GHz
Internal Storage	256 GB (Max 1024 GB Flash Memory Support)
Color	White
SIM Card Slot Count	Dual SIM
Connector Type	USB Type-C
Biometric Authentication	Fingerprint Recognition, Face Recognition
SIM Card Size	Nano
Headphone Jack	3.5 mm
Front Camera Resolution	8 MP
Rear Camera Resolution	13 MP
Number of Rear Cameras	3
Number of Front Cameras	1
Battery Capacity	5000 mAh
Video Resolution	1080p, 480p, 720p
Frame Rate	30fps, 60fps, 120fps
Screen Size	6.8 inches
Display Resolution	1600 x 720
Display Type	LCD
Display Pixel Density	258 PPI
Wireless Provider	All network carriers
Mobile Phone Technology	4G
Communication & Connectivity Interface	2G, 3G, 4G, Bluetooth, Wi-Fi
Wireless Communication Technology	LTE

GPS Location Tagging Function	Yes
--------------------------------------	-----

WARRANTY AND SUPPORT

Your UMIDIGI Note 100A comes with a 1-year warranty service. For any issues or inquiries, please use the built-in UMIDIGI After-Sales Service App:

1. Open the **Service Center App** on your device.
2. Navigate to **Customer Service**.
3. Click on **Ask a question**.
4. Follow the on-screen instructions and ensure all required fields (marked with a red asterisk) are filled out before submitting your inquiry.

Our technical staff will respond to your inquiry within 48 hours.