

## TAURUS Sliding Perfect 2800

# Taurus Sliding Perfect 2800 Steam Generator Iron User Manual

Model: Sliding Perfect 2800

## 1. INTRODUCTION

---

The Taurus Sliding Perfect 2800 is a high-performance steam generator iron designed to efficiently remove wrinkles from various fabrics. This appliance combines powerful steam output with an ultra-gliding ceramic soleplate to simplify your ironing tasks. Please read this manual carefully before first use to ensure safe and optimal operation of your device.

## 2. SAFETY INSTRUCTIONS

---

- Always ensure the power supply voltage matches the rating on the appliance.
- Do not immerse the iron or its base in water or any other liquid.
- Keep the appliance out of reach of children and pets.
- Never leave the iron unattended while it is switched on or connected to the power supply.
- Allow the iron to cool completely before storing.
- Do not touch the hot soleplate or steam, as this can cause burns.
- Only use distilled or demineralized water in the water tank to prevent limescale buildup.
- If the power cord is damaged, it must be replaced by the manufacturer, its service agent, or similarly qualified persons to avoid a hazard.

## 3. PRODUCT OVERVIEW

---

Familiarize yourself with the main components of your Taurus Sliding Perfect 2800 steam generator iron:

- **Iron Unit:** The handheld part with the soleplate and controls.
- **Steam Generator Base:** Houses the water tank and heating element.
- **Water Tank:** Removable 1.5L tank for water.
- **Ceramic Soleplate:** The heated surface that glides over fabrics.
- **Steam Control Buttons:** Buttons to select steam levels (ECO, COMFORT, MAX) and activate steam boost.
- **Temperature Dial/Control:** To adjust the soleplate temperature.
- **Power Cord:** Connects the appliance to the electrical outlet.
- **Measuring Cup:** For filling the water tank.



The Taurus Sliding Perfect 2800 steam generator iron, highlighting its 2800W maximum power and 5.5 bar steam pressure capabilities.

## 4. SETUP

1. **Unpacking:** Carefully remove the iron and all accessories from the packaging. Retain packaging for future storage or transport.
2. **Positioning:** Place the steam generator base on a stable, heat-resistant surface, preferably an ironing

board designed for steam generators.

### 3. Filling the Water Tank:

- Ensure the appliance is unplugged.
- Remove the water tank from the base.
- Fill the 1.5L tank with distilled or demineralized water using the provided measuring cup. Do not exceed the 'MAX' fill line.
- Reinsert the water tank securely into the base.



Illustration of refilling the 1.5L water tank, demonstrating the 'Non-Stop System' for continuous use.

4. **Connecting to Power:** Plug the power cord into a grounded electrical outlet.

## 5. OPERATING INSTRUCTIONS

1. **Power On:** Press the power button on the base unit. The indicator light will illuminate, and the iron will begin to heat up.
2. **Select Temperature:** Turn the temperature dial on the iron unit to the appropriate setting for your fabric type (e.g., silk, wool, cotton, linen). Refer to garment care labels.
3. **Wait for Heating:** The iron will take a few minutes to reach the selected temperature. The temperature

indicator light will turn off or change color when ready.

4. **Select Steam Level:** Use the steam control buttons on the iron handle to choose your desired steam level:
  - **ECO Mode:** For delicate fabrics and energy saving.
  - **COMFORT Mode:** Standard steam for most fabrics.
  - **MAX Mode:** Maximum steam for stubborn wrinkles and thick fabrics.



Detail of the control panel, indicating the three adjustable steam levels (ECO, COMFORT, MAX) for different fabric types.

5. **Ironing with Steam:** Press the steam trigger on the iron handle to release continuous steam. For a powerful burst of steam (400g/min Super Steam), press the steam boost button. Glide the iron smoothly over the fabric.



The iron in operation, demonstrating its powerful steam output: 400 g/min super steam boost and 130 g/min continuous steam.

6. **Dry Ironing:** If you prefer to iron without steam, simply do not press the steam trigger.
7. **Vertical Ironing:** For quick wrinkle removal from hanging garments or drapes, hold the iron vertically a few centimeters away from the fabric and press the steam trigger. Ensure the fabric is taut.



**VERTICAL  
IRONING**



The iron performing vertical steaming, ideal for refreshing hanging garments and drapes.

8. **Automatic Shut-off:** For safety and energy saving, the iron features an automatic shut-off function if left inactive for a period.
9. **Finishing:** When done, press the power button to turn off the appliance, then unplug it from the wall socket.

## **6. MAINTENANCE AND CLEANING**

---

Regular maintenance ensures the longevity and optimal performance of your iron.

### **1. Cleaning the Soleplate:**

- Ensure the iron is unplugged and completely cool.
- Wipe the ceramic soleplate with a damp cloth and a non-abrasive cleaner if necessary.
- Do not use abrasive pads or harsh chemicals, as these can damage the soleplate.

## CERAMIC SOLEPLATE



The ultra-gliding ceramic soleplate, designed for even heat distribution and smooth movement across fabrics.

2. **Descaling (Anti-Calc System):** The iron features an anti-calc system. Refer to the specific instructions in your full manual for descaling procedures. Regular descaling is crucial, especially in hard water areas, to prevent mineral buildup and maintain steam performance.
3. **Emptying the Water Tank:** After each use, or before storing, empty any remaining water from the tank.
4. **Storing the Iron:** Once cool, store the iron in an upright position on its base in a dry, safe place.

## 7. TROUBLESHOOTING

If you encounter issues with your iron, consult the following table before contacting customer support:

Problem	Possible Cause	Solution
No steam is produced.	Water tank is empty; iron not hot enough; steam button not pressed.	Fill water tank; wait for temperature indicator; press steam button.
Water leaks from the soleplate.	Temperature too low for steam; tank overfilled.	Increase temperature setting; do not overfill tank.

Problem	Possible Cause	Solution
Iron does not heat up.	Not plugged in; power switch off; faulty outlet.	Check power connection; ensure power switch is on; try a different outlet.
Limescale residue on clothes.	Hard water used; descaling needed.	Use distilled water; perform descaling procedure.

## 8. SPECIFICATIONS

Feature	Detail
Brand	TAURUS
Model Name	Sliding Perfect 2800
Power	2800 W
Steam Pressure	5.5 bar (equivalent)
Super Steam Boost	400 g/min
Continuous Steam Flow	130 g/min
Soleplate Material	Ceramic
Water Tank Capacity	1.5 L
Special Features	Super Steam, Ceramic Soleplate, Smart (ECO, COMFORT, MAX steam modes), Power & Auto-OFF, Vertical Ironing, Anti-Calc, Anti-Drip
Recommended Uses	Vertical ironing, thick fabrics, delicate garments
Voltage	230 V (AC)

## 9. WARRANTY AND SUPPORT

Your Taurus Sliding Perfect 2800 steam generator iron comes with a manufacturer's warranty. Please refer to the warranty card included with your purchase for specific terms and conditions, including the warranty period and coverage details.

For technical assistance, spare parts, or any questions regarding the operation of your appliance, please contact Taurus customer support. Contact information can typically be found on the manufacturer's website or in the documentation provided with your product.

© 2026 TAURUS. All rights reserved.