



Manuals.plus /

- › XO /
- › XO BE18 Wireless Bluetooth Headset User Manual

XO BE18

XO BE18 Wireless Bluetooth Headset User Manual

This manual provides instructions for the proper use and maintenance of your XO BE18 Wireless Bluetooth Headset.

PRODUCT OVERVIEW

The XO BE18 is a stereo audio wireless Bluetooth headset featuring RGB lighting. It is designed for immersive listening experiences and convenient communication, offering multiple playback modes including Bluetooth, AUX, TF card, and FM radio.



Image: The XO BE18 Wireless Bluetooth Headset, showcasing its over-ear design and integrated RGB lighting on the earcups.

PACKAGE CONTENTS

Please ensure all items are present in the package:

- XO BE18 Wireless Bluetooth Headset
- Charging Cable
- User Manual (this document)



PRODUCT INFORMATION

Brand:
XO

S/N:
≥75dB

Product name:
BE18 Glare bluetooth headset

Sensitivity:
94±3dBm

Color:
black

Battery capacity:
250mAh

Bluetooth version:
V5.0

Music time :
About 4 hours

Speaker power:
3 mW

Call time:
About 4 hours

Effective distance:
About 10 m

Charging time:
About 2.5 hours

Working frequency:
20HZ-20KHz

Play mode:
Bluetooth/AUX/TF card/radio

Bluetooth protocol:
A2DP、HSP、HFP

Package Size:
195*195*80mm

Image: The XO BE18 headset shown within its retail packaging, indicating the included accessories.

SETUP

Charging the Headset

1. Locate the charging port on the headset.
2. Connect the provided charging cable to the headset and a compatible USB power source (e.g., computer USB port, USB wall adapter).
3. The LED indicator on the headset will typically show a specific color (e.g., red) during charging and change (e.g., turn off or blue) when fully charged.
4. A full charge takes approximately 2.5 hours.

Powering On/Off

- **To Power On:** Press and hold the Power button for approximately 3-5 seconds until the LED indicator lights up and you hear an audible prompt.
- **To Power Off:** Press and hold the Power button for approximately 3-5 seconds until the LED indicator turns off and you hear an audible prompt.


OPERATING INSTRUCTIONS

Bluetooth Pairing

1. Ensure the headset is powered off.
2. Press and hold the Power button for approximately 5-7 seconds until the LED indicator flashes rapidly (e.g., alternating blue and red), indicating pairing mode.
3. On your device (smartphone, tablet, computer), enable Bluetooth and search for available devices.
4. Select "XO BE18" from the list of found devices.
5. Once paired, the LED indicator will typically flash slowly or turn solid blue, and you will hear a confirmation tone.

Basic Controls

The headset features various buttons for controlling audio playback and calls. Refer to the image below for button locations.






Image: Close-up view of the XO BE18 headset earcup, highlighting the control buttons and ports.

- **Power Button:** Press and hold to power on/off. Short press to play/pause music or answer/end calls.
- **Volume Up (+):** Short press to increase volume. Long press for next track.
- **Volume Down (-):** Short press to decrease volume. Long press for previous track.
- **Mode Button (M):** Short press to switch between Bluetooth, AUX, TF card, and Radio modes.

RGB Lighting

The headset features integrated RGB lighting on the earcups. This lighting typically activates automatically when the headset is powered on. Specific controls for the RGB lighting (if any) may be integrated with the mode button or a dedicated button not explicitly detailed.



LIBERTY

REFUSING TO BE BOUND
YOU CAN GET DRY WITH IT



Support TF card, AUX, compatible with radio function,
not connected to mobile phone
Can also get up



Image: The XO BE18 headset displaying its colorful RGB lighting on the earcups.

Using the Microphone

The built-in microphone allows for hands-free calls. When a call comes in, press the Power button once to answer. Press again to end the call.

AUX Mode

Connect an audio cable (not included) from your device's 3.5mm audio jack to the headset's AUX port to use it in wired mode. The headset does not require power in AUX mode.

TF Card Mode


Insert a TF (microSD) card with audio files into the designated slot. Use the Mode button to switch to TF card mode.

Radio Mode

Use the Mode button to switch to Radio mode. The headset will automatically scan for available FM radio stations.

MAINTENANCE

- **Cleaning:** Use a soft, dry cloth to clean the headset. Do not use abrasive cleaners or solvents.
- **Storage:** When not in use, store the headset in a cool, dry place. The headset features a portable folding design for compact storage.





Portable folding design

Image: The XO BE18 headset shown in its folded configuration, demonstrating its portable design.

- **Battery Care:** To prolong battery life, avoid fully discharging the battery frequently. Charge the headset regularly, even if not in constant use.
- **Water Exposure:** This headset is not waterproof. Avoid exposure to water or excessive moisture.

TROUBLESHOOTING

Problem	Possible Solution
Headset does not power on.	Ensure the headset is fully charged. Connect to a power source and try again.
Cannot pair with device.	<ul style="list-style-type: none">• Ensure the headset is in pairing mode (rapidly flashing LED).• Make sure Bluetooth is enabled on your device.• Move the headset closer to your device.• Forget "XO BE18" from your device's Bluetooth list and try pairing again.
No sound or low volume.	<ul style="list-style-type: none">• Increase volume on both the headset and your connected device.• Ensure the headset is properly connected via Bluetooth or AUX cable.• Check if the audio source is playing.
Microphone not working.	<ul style="list-style-type: none">• Ensure the headset is properly connected.• Check microphone settings on your connected device.
RGB lighting not working.	Ensure the headset is powered on. If the issue persists, contact customer support.

SPECIFICATIONS

Feature	Detail
Model Name	BE18
Connectivity	Wireless (Bluetooth V5.0)
Wireless Range	About 10 meters
Audio Technology	Hi-Fis Audio, Intelligent Noise Reduction
Ear Placement	On Ear
Noise Control	Sound Isolation
Microphone	Built-in
Battery Capacity	250mAh
Music Playback Time	About 4 hours
Call Time	About 4 hours
Charging Time	About 2.5 hours
Standby Time	Long Standby Capability
Speaker Power	3 mW
Sensitivity	94±3dBm
S/N Ratio	>=75dB
Working Frequency	20Hz-20KHz
Play Modes	Bluetooth, AUX, TF Card, Radio
Bluetooth Protocols	A2DP, HSP, HFP
Dimensions (Package)	195 x 195 x 80 mm
Color	Black



Image: A detailed table outlining the technical specifications and product information for the XO BE18 headset.

WARRANTY AND SUPPORT

This product comes with a standard manufacturer's warranty. For specific warranty terms and conditions, please refer to the warranty card included in your product packaging or contact the retailer where you purchased the product.

For technical support or further assistance, please contact your retailer or visit the official XO website (if available).