

THOMSON QY-B210

THOMSON QY-B210 High-Fidelity TV Speaker User Manual

Model: QY-B210

1. INTRODUCTION

Thank you for purchasing the THOMSON QY-B210 High-Fidelity TV Speaker. This manual provides essential information for the safe and correct operation of your device. Please read it thoroughly before use and retain it for future reference.

2. SAFETY INFORMATION

- Do not expose the device to rain, moisture, or extreme temperatures.
- Ensure proper ventilation around the speaker.
- Do not open the speaker enclosure; refer all servicing to qualified personnel.
- Keep out of reach of children.

3. PACKAGE CONTENTS

Verify that all items are present in the package:

- THOMSON QY-B210 TV Speaker
- Remote Control
- Power Adapter
- User Manual
- Audio Cables (e.g., Optical, AUX - specific cables may vary)

4. PRODUCT OVERVIEW

Front View



Figure 1: Front view of the THOMSON QY-B210 TV Speaker, showcasing its sleek design and integrated grille.

Top View with Controls



Figure 2: Top view displaying the integrated touch controls for power, input selection, volume adjustment, and playback.

Rear View with Ports



Figure 3: Rear view illustrating the various input ports including USB, optical, coaxial, HDMI ARC, and AUX, alongside the bass reflex port.

Internal Speaker Components



Figure 4: An exploded view showing the internal speaker drivers and subwoofer components, highlighting the acoustic design.

5. SETUP

5.1 Placement

Position the THOMSON QY-B210 TV Speaker on a stable, flat surface in front of your television, or mount it on a wall. Ensure there is adequate space around the speaker for optimal sound dispersion and ventilation. Avoid placing it in enclosed cabinets that could obstruct sound or airflow.

5.2 Connecting to Power

1. Connect the power adapter to the DC IN port on the back of the speaker.
2. Plug the other end of the power adapter into a wall outlet.

5.3 Audio Connections

The QY-B210 offers multiple connectivity options:

- **HDMI ARC:** For the best audio quality and control, connect an HDMI cable from the speaker's HDMI ARC port to your TV's HDMI ARC port. This allows your TV remote to control the speaker's volume.
- **Optical:** Connect an optical cable from the speaker's OPTICAL port to your TV's optical output.
- **Coaxial:** Connect a coaxial cable from the speaker's COAXIAL port to your TV's coaxial output.
- **AUX:** Use a 3.5mm audio cable to connect the speaker's AUX port to the audio output of your device.
- **USB:** Insert a USB drive into the USB port to play audio files directly.

5.4 Bluetooth Pairing

To connect a Bluetooth device:

1. Power on the speaker.
2. Press the 'Input' button on the speaker or remote control until 'BT' appears on the LED display.
3. Enable Bluetooth on your mobile device and search for 'QY-B210'.
4. Select 'QY-B210' to pair. A confirmation tone will sound upon successful connection.

Your browser does not support the video tag.

Video 1: An overview of the THOMSON QY-B210 TV Speaker's features, including its Hi-Fi sound, built-in subwoofer, touch operation, and Bluetooth pairing capabilities.

6. OPERATING INSTRUCTIONS

6.1 Power On/Off

Press the power button on the speaker or remote control to turn the device on or off.

6.2 Input Selection

Press the 'Input' button on the speaker or remote control to cycle through available input sources (HDMI ARC, Optical, Coaxial, AUX, USB, Bluetooth).

6.3 Volume Control

Use the '+' and '-' buttons on the speaker or remote control to adjust the volume. The LED display will show the current volume level.

6.4 Playback Controls (Bluetooth/USB Mode)

- **Play/Pause:** Press the Play/Pause button.
- **Next Track:** Press the Next Track button.
- **Previous Track:** Press the Previous Track button.

7. MAINTENANCE

To ensure the longevity and performance of your speaker:

- Clean the speaker with a soft, dry cloth. Do not use liquid cleaners or aerosols.
- Avoid blocking the ventilation openings.
- Store the speaker in a cool, dry place when not in use for extended periods.

8. TROUBLESHOOTING

Problem	Possible Cause	Solution
No power	Power cable not connected; outlet not active	Check power cable connection; try a different outlet
No sound	Incorrect input selected; volume too low; audio cable loose	Select correct input; increase volume; check audio cable connections

Problem	Possible Cause	Solution
Bluetooth not connecting	Speaker not in pairing mode; device too far; interference	Ensure speaker is in BT mode; move device closer; restart both devices
Remote control not working	Batteries depleted; obstruction; remote not aimed at sensor	Replace batteries; remove obstructions; aim remote directly at the speaker's sensor

9. SPECIFICATIONS

Feature	Detail
Model Name	QY-B210
Product Dimensions	36.5"D x 2.87"W x 4.65"H
Item Weight	11 Pounds
Speaker Maximum Output Power	180 Watts
Connectivity Technology	Bluetooth 5.3, USB, Optical, Coaxial, HDMI ARC, AUX
Audio Material	PVC Plastic + Wooden Case + Glass
Frequency Response	30Hz-20KHz
Sensitivity	800MV
Mounting Type	Wall Mount

10. WARRANTY AND SUPPORT

For warranty information and technical support, please refer to the warranty card included with your product or visit the official THOMSON website. You may also contact customer service through your retailer for assistance. Please have your model number (QY-B210) and purchase date available when contacting support.

Related Documents - QY-B210

	Thomson Soundbar 2.0 CORE 1 User Manual User manual for the Thomson Soundbar 2.0 (Model: CORE 1), detailing setup, connections, features, and troubleshooting for home cinema audio.
	Thomson Go Plus Pro Bruksanvisning Lär dig installera, konfigurera och använda din Thomson Go Plus Pro smarta display med denna omfattande användarmanual. Innehåller säkerhetsinformation, installationsanvisningar, knappfunktioner, inställningar och felsökning.

	THOMSON SB180BT Barre de Son Bluetooth - Manuel d'utilisation Manuel d'utilisation complet pour la barre de son Bluetooth THOMSON SB180BT. Découvrez comment installer, connecter et utiliser votre appareil avec des instructions claires et des consignes de sécurité pour une expérience audio optimale.
	Thomson Smart TV ar Google TV: Lietotāja rokasgrāmata Šī visaptverošā lietotāja rokasgrāmata sniedz būtisku informāciju jūsu jaunā Thomson Smart TV ar Google TV uzstādīšanai un lietošanai. Tā aptver visu, sākot no sākotnējās instalācijas un savienojumiem līdz funkciju, iestatījumu un problēmu novēršanas izpētei.
	Thomson Go Plus Pro: Navodila za uporabo in nastavitve Podroben uporabniški priročnik za Thomson Go Plus Pro pametni zaslon, ki zajema namestitev, nastavitve, uporabo funkcij, sistemske nastavitve in odpravljanje težav.
	Thomson Go Plus Pro - Uživatelská příručka Uživatelská příručka pro Thomson Go Plus Pro. Získejte podrobné pokyny k instalaci, nastavení, ovládání, bezpečnosti, řešení problémů a technickým specifikacím tohoto inteligentního displeje Thomson.