

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- › [Franke](#) /
- › [Franke Automatic Stopper Color Line 112.0656.939 User Manual](#)

Franke 112.0656.939

Franke Automatic Stopper Color Line 112.0656.939 User Manual

Model: 112.0656.939

1. INTRODUCTION

This manual provides essential information for the proper installation, operation, and maintenance of your Franke Automatic Stopper Color Line, model 112.0656.939. This automatic stopper is designed for use with compatible kitchen sinks, offering a convenient solution for managing your sink's drainage. Please read these instructions carefully before installation and use to ensure optimal performance and longevity of the product.

The Franke Automatic Stopper Color Line 112.0656.939 is constructed from durable plastic with a sleek black matt finish, designed to complement modern kitchen aesthetics.



Image showing the Franke Automatic Stopper Color Line 112.0656.939 in its black matt finish.

2. SETUP AND INSTALLATION

The Franke Automatic Stopper requires proper installation to function correctly. A mounting set is included with your purchase. For best results, professional installation is recommended. If you choose to install it yourself, ensure you have the necessary tools and follow these general guidelines:

1. **Review Components:** Unpack all components and verify that the automatic stopper and mounting set are complete and undamaged. Refer to the included parts list.
2. **Prepare Sink Drain:** Ensure the sink drain opening is clean and free of debris. If replacing an existing stopper, remove it completely.
3. **Install Stopper Mechanism:** Follow the specific instructions provided with the mounting set to securely attach the automatic stopper mechanism to the sink drain. This typically involves sealing the stopper body to the drain opening using gaskets and tightening nuts from underneath the sink.
4. **Connect Control (if applicable):** If your automatic stopper includes a remote control knob or lever, connect it according to the mounting set instructions. This usually involves a cable or rod that links the control to the stopper

mechanism.

5. **Test for Leaks:** After installation, fill the sink with water and check for any leaks around the stopper and drain connections. Tighten connections as needed.

Important: Always turn off the water supply before beginning any plumbing installation. If you are unsure about any step, consult a qualified plumber.

3. OPERATING INSTRUCTIONS

The Franke Automatic Stopper Color Line 112.0656.939 is designed for ease of use, allowing you to open and close your sink drain efficiently. The operation typically involves a remote control mechanism, such as a knob or lever, usually located on the sink or countertop.

- **To Close the Drain:** Rotate or push the control knob/lever to the 'closed' position. This will lower the stopper into the drain opening, sealing it and allowing the sink to fill with water.
- **To Open the Drain:** Rotate or pull the control knob/lever to the 'open' position. This will lift the stopper, allowing water to drain freely from the sink.

Ensure the stopper moves smoothly between the open and closed positions. Avoid forcing the mechanism if resistance is felt, as this may indicate an obstruction or improper installation.

4. MAINTENANCE

Regular maintenance will help keep your Franke Automatic Stopper in optimal condition and extend its lifespan.

- **Cleaning:** Clean the visible parts of the stopper and the surrounding drain area regularly with a soft cloth and mild soap. Avoid abrasive cleaners, scouring pads, or harsh chemicals, as these can damage the black matt finish and plastic material.
- **Debris Removal:** Periodically remove the stopper (if easily detachable) and clear any accumulated food particles, hair, or other debris from the drain opening and the stopper mechanism. This prevents blockages and ensures smooth operation.
- **Check for Wear:** Inspect the stopper's seals and moving parts for any signs of wear or damage. If seals appear cracked or worn, they may need replacement to prevent leaks.

5. TROUBLESHOOTING

If you encounter issues with your automatic stopper, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Stopper does not seal completely / Sink leaks slowly	Debris under stopper; Worn or misaligned seal; Loose connection.	Clean stopper and drain area. Check and reposition the seal. Tighten mounting nuts if accessible.
Stopper mechanism is stiff or difficult to operate	Accumulated debris; Misalignment of control cable/rod.	Remove debris from the mechanism. Check for kinks or obstructions in the control cable/rod.
Water drains slowly when stopper is open	Partial blockage in the drain pipe below the stopper.	Clear any blockages in the drain pipe. This may require a drain cleaner or professional assistance.

If these troubleshooting steps do not resolve the issue, please contact Franke customer support for further assistance.

6. SPECIFICATIONS

Below are the technical specifications for the Franke Automatic Stopper Color Line 112.0656.939:

- **Model Number:** 112.0656.939
- **Brand:** Franke
- **Material:** Plastic
- **Color:** Black Matt
- **Product Dimensions:** 1.97 x 1.97 x 0.79 inches (5 x 5 x 2 cm)
- **Item Weight:** 8.4 ounces (0.24 Kilograms)
- **Included Components:** 1 x Franke Automatic stopper Color Line - black matt - 112.0656.939, mounting set, user manual
- **Batteries Required:** No

7. WARRANTY AND SUPPORT

For warranty information, product support, or to purchase replacement parts, please contact Franke customer service or visit the official Franke website. Keep your proof of purchase for warranty claims.

Franke Official Website: www.franke.com

