



Manuals.plus /

› eazpower /

› eazpower Invisible Wireless Charger (Model E30SZ) - User Manual

## eazpower E30SZ

# eazpower Invisible Wireless Charger (Model E30SZ) - User Manual

Model: E30SZ | Brand: eazpower

## 1. INTRODUCTION

---

Thank you for choosing the eazpower Invisible Wireless Charger. This innovative device offers versatile charging solutions, allowing you to charge your compatible devices either on top of a surface or discreetly hidden underneath it. Designed for convenience and a clutter-free environment, it supports charging through various materials up to 30mm thick.

## 2. WHAT'S INCLUDED

---

- 15W Under Desk Wireless Charger
- QC3.0 Adapter
- USB Type A to C Cable
- Power Sticker
- Adhesive Metal Ring
- User Instructions

## 3. SETUP AND INSTALLATION

---

The eazpower Invisible Wireless Charger offers two primary installation methods: on-table use or hidden under-table use. The installation process is designed to be straightforward and requires no drilling for under-table mounting.

### 3.1. Under-Table Installation (0-30mm Charging Distance)

For a clean and neat table surface, install the charger underneath. This method is suitable for tables made of solid wood, slate, granite, marble, glass, plastic, or quartz.

# Invisible Wireless Charger Under Desk

Long Charging Distance of up to 30mm (0"-1.18")



The eazpower Invisible Wireless Charger installed beneath a wooden desk, with a smartphone wirelessly charging on the surface above. The image highlights the 0-30mm charging distance capability.

## Installation Steps:

1. **Plug in the Charger:** Connect the charger to the QC3.0 adapter and plug it into a power socket.
2. **Mount the Adhesive Metal Ring:** Rip off the protective layer of the 3M tape from the adhesive metal ring. Mount this ring in your desired position underneath the table.

3. **Attach the Charger:** Attach the wireless charger to the adhesive metal ring. Ensure it is securely in place.
4. **Use the Alignment Assistant:** Place the provided "Alignment assistant" on the table surface directly above where the charger is mounted. Move the assistant around until all the indicator lights on it are fully illuminated. This indicates optimal alignment for charging.
5. **Apply Power Sticker (if needed):** If your table thickness is between 18-30mm, tear off the transparent sticker from the alignment assistant and stick the power sticker onto the blank area on the table surface, directly above the charger. For thicknesses between 0-18mm, the power sticker is optional.
6. **Begin Charging:** Place your phone on the power sticker (or directly on the table if no sticker is used) to initiate charging.

### ***Feel free to use it on or under the desk(0"-1.18")***



#### **Under the Table**

**For a clean and neat table**



#### **On the Table**

**For thick cases charging or portable purposes**

Visual guide illustrating the six steps for installing the eazpower Invisible Wireless Charger under a desk, including using the alignment assistant and power sticker.

#### **Video Guide:**

Your browser does not support the video tag.

Official video demonstrating the installation steps for the eazpower Invisible Wireless Charger under a desk, including the use of the alignment assistant and power sticker.

### **3.2. On-Table Use (Charging Pad)**

The charger can also be used as a standard wireless charging pad placed directly on the table surface. This is ideal for ultra-thick cases, Otterbox, or PopSockets, as it eliminates the need for the power sticker and allows for direct contact charging.

# Two options for you to use



## On the table

Ultra Thick Cases/Otterbox/Popsocket Compatible  
(No Metal Ring Stand Allowed)



## Under the Table

Thin Case ONLY

Illustration of the two usage options: 'On the table' for ultra-thick cases and accessories, and 'Under the table' for thin cases, emphasizing the versatility of the charger.

## 4. OPERATING INSTRUCTIONS

Once installed, operating the eazpower Invisible Wireless Charger is simple. Place your compatible device directly on the designated charging area (either the power sticker or the charger itself if used on-table). The device will begin charging automatically.

## 4.1. Universal Compatibility

This charger is universally compatible with all Qi wireless standard phones and earphones. It supports a wide range of devices, including:

- **iPhone Series:** iPhone 17/17 Pro/17 Pro Max/17 Air, 16/16e/16 Plus/16 Pro/16 Pro Max, 15, 14, 13, 12/12 mini, SE, 11/11 Pro/11 Pro Max, X/Xs/Xs Max, 8/8 Plus.
- **Samsung Phones:** Galaxy S25, S24, S23 Ultra, S22, S21, S20+, S20 Ultra, S10, S10 Plus, S10E, S9 Plus, S9, Note 9, Note 8, S8, S8 Plus, S7, S7 Edge.
- **Other Qi Wireless Phones:** Google Pixel, Sony Xperia, LG V50/V40/V30.
- **Earbuds:** AirPods (with wireless charging case), Samsung Galaxy Buds, Soundcore Liberty. (Note: Cannot charge Apple Watch).

# Upgraded Version of Wireless Charger

Before

Now

Messy cords

Clean desk



Digging hole

No damage



Detailed compatibility chart for the eazpower wireless charger, listing various iPhone, Samsung, Google Pixel, Sony, LG, and earbud models.

## 4.2. Charging Through Thick Cases

The charger is designed to work with thick phone cases, PopSockets, and OtterBox covers when used directly on the table. When installed under the table, it is recommended for thin cases only, especially for table thicknesses between 18-30mm where the power sticker is required.

## Universal Compatibility

### For iPhone

iPhone 12-17 Series  
Max/X/XS/XS Max/XR/8 Plus/8



### For Samsung

Samsung Galaxy S25/S25+/S25 Ultra/  
S24 Ultra/S24/S23/S22/S21/S20/  
S10/S9/S8, Z Fold Flip 3, Note 8/  
S7 Edge/S7/S6 Edge plus/Note 5



### For other Qi enabled Devices

Google Pixel 9/8/7/6/5/4/3,  
Sony Xperia XZ3, XZ2, LG V50,  
V40, V30



### For Wireless Earbuds

AirPods Pro 3/Pro 2/Pro/4/3/2  
Galaxy Buds,  
and other wireless earbuds



Visual guide detailing charging compatibility based on table thickness (0mm, 0-18mm, 18-30mm) and phone accessories like grips, stands, thick cases, metal cases, and credit cards.

## 5. SAFETY PRECAUTIONS

---

The eazpower Invisible Wireless Charger is built with multiple safety protections to ensure safe and reliable charging for your devices:

- Over-Voltage Protection
- Over-Current Protection
- Foreign Object Detection
- Over-Temperature Protection

These features prevent damage to your device and the charger during operation.

# Universal Compatibility

## 15W Fast Charge Mode for Google/LG/SONY



Google Pixel  
9/8/7 Series



Google Pixel  
5/5XL



Google Pixel  
4/4XL



Sony Xperia  
5V/5 IV



Sony Xperia  
XZ3/2/1 III



LG V60/V50/V40/  
V30+/V30

## 10W Fast Charge Mode for Samsung



S25/S25+/  
S25 Ultra



S24/S24+/  
S24 Ultra



S23/S23+/  
S23 Ultra



S22/S22+/  
S22 Ultra



S21/S21+/  
S21 Ultra



S20/S20+/  
S20 Ultra

## 7.5W Fast Charge Mode for iPhone



iPhone 17  
Series



iPhone 16  
Series



iPhone 15  
Series



iPhone 14  
Series



iPhone 13  
Series



iPhone 12  
Series

## 5W Fast Charge Mode for AirPods



AirPods Pro 3/  
Pro 2/Pro 4/3/2



Samsung Galaxy Buds/  
Buds+/Buds Pro/Buds Live



Soundcore Liberty  
Air2/2 Pro/Air 2Pro



A smartphone charging on a nightstand, accompanied by icons illustrating the charger's built-in safety features: Over-Voltage, Over-Current, Foreign Object Detection, and Over-Temperature Protection.

## 6. TROUBLESHOOTING

If you encounter issues with your eazpower Invisible Wireless Charger, please refer to the following common solutions:

- **Device Not Charging:** Ensure your device is Qi-compatible and correctly centered on the charging area/power

sticker. Verify that the charger is properly plugged into the QC3.0 adapter and a working power outlet.

- **Slow Charging:** Confirm you are using the provided QC3.0 adapter. Ensure optimal alignment using the alignment assistant. Very thick cases or metallic objects between the phone and charger can impede charging speed.
- **Overheating:** The charger has built-in over-temperature protection. If your device or the charger feels excessively hot, remove the device and unplug the charger. Ensure there are no foreign objects on the charging surface.
- **Alignment Issues:** Re-use the alignment assistant to find the optimal charging spot. For under-table installation, ensure the adhesive metal ring and charger are securely attached.

## 7. SPECIFICATIONS

---

Feature	Detail
Brand	eazpower
Model Number	E30SZ
Connector Type	USB Type C
Special Feature	Wireless Charging
Color	Black
Input Voltage	12 Volts
Amperage	1.5 Amps
Wattage	10 watts (Max 15W with QC3.0 adapter)
Output Current	1.67 Amps
Output Voltage	9 Volts
Power Source	Corded Electric
Mounting Type	Desktop Mount Under Table or On the Table
Item Weight	0.32 Kilograms
Enclosure Material	Acrylonitrile Butadiene Styrene

## 8. WARRANTY AND SUPPORT

---

The eazpower Invisible Wireless Charger (Model E30SZ) comes with a **2-Year Warranty**. For any product inquiries, technical support, or warranty claims, please contact eazpower customer service. Refer to the contact information provided in your product packaging or visit the official eazpower website.