

## Augnner B005

# Augnner Sound Machine Alarm Clock User Manual

Model: B005

## INTRODUCTION

Thank you for purchasing the Augnner Sound Machine Alarm Clock. This device combines a sound machine with 32 soothing sounds, an alarm clock, a night light, and a Bluetooth speaker, designed to enhance your sleep environment and daily routine. This manual provides detailed instructions for setup, operation, and maintenance to ensure optimal performance and longevity of your device.



Image: The Augnner Sound Machine Alarm Clock in beige, shown next to a smartphone displaying its app control interface. The clock face shows "9:00" and the base emits a soft light. Various colored lights are shown at the bottom, indicating the night light feature.

## PRODUCT FEATURES

- 32 Non-Looping Sleep Sounds:** Features a wide range of natural sounds including rain, streams, birdsong, drizzle, breeze, waves, and trains, along with white noise, brown noise, and pink noise.
- Dimmable Alarm Clock:** Integrates an alarm clock with a dimmable display (off, 10%, 50%, 100% brightness) to prevent sleep disturbance.
- Portable Design:** Compact size (3.15 x 3.15 x 1.85 inches) makes it suitable for home, office, or travel.
- Long-lasting Battery:** Equipped with an 800 mA built-in battery, providing 8+ hours of continuous use on a 1-2 hour Type-C charge.
- Changeable Night Light:** Offers 8 unique light modes, RGB breathing, and 3000 adjustable color temperatures, controllable via the app.
- Bluetooth Speaker:** Bluetooth 5.4 for fast and stable connection to play audio from your devices.

- **Memory Function:** Remembers your last settings for convenience.
- **Auto-off Timer:** Customizable timer to automatically turn off the sound machine.



Image: The Augnner Sound Machine Alarm Clock on a wooden table, highlighting its "4 in 1" functionality: Sound Machine (32 soothing sounds), Alarm Clock (memory function), Bluetooth Speaker (Bluetooth 5.4), and Night Light (0-100% stepless dimming).

## PACKAGE CONTENTS

Please check the package contents upon unboxing:

- Augnner Sound Machine Alarm Clock (Model: B005)
- USB Type-C Charging Cable
- User Manual

## SETUP

- Unpack:** Carefully remove the sound machine and all accessories from the packaging.
- Charge:** Before first use, fully charge the device using the provided USB Type-C cable. Connect the cable to the device's charging port and a compatible USB power adapter (not included). The display will indicate charging status.
- Placement:** Place the sound machine on a stable, flat surface away from direct sunlight, heat sources, and water.
- Initial Power On:** Press and hold the Power button () on the top panel to turn on the device.



Image: Overhead view of the Augnner Sound Machine Alarm Clock, showing the layout of its control buttons and their functions: Volume +/Previous Sound, Alarm on/off, Time Setting, Pause/Bluetooth, Auto-off Timer, Volume -/Next Sound, Power Switch & Display brightness adjustment, and Light Control & Snooze.

## OPERATING INSTRUCTIONS

### Button Functions Overview




Image: A diagram illustrating the top panel buttons of the sound machine: Time setting, Alarm setting, Play/Bluetooth, Timer off, On-Off button/Display dimmer, and Light/Snooze.



Image: A close-up diagram detailing the functions of the top buttons: PAUSE/BLUETOOTH (short press to pause, long press for Bluetooth mode), VOLUME +/- (short press for volume, long press for sound track change), ALARM CLOCK BUTTON (short press for on/off, long press for settings, cycle through settings), TIMER BUTTON (short press to cycle through 30/60/90/120/240/OFF minutes).

## Power On/Off and Display Brightness

- **Power On/Off:** Press and hold the Power button () for 2 seconds.
- **Display Brightness:** Short press the Power button () to cycle through display brightness levels: Off, 10%, 50%, 100%.



Image: Four images of the sound machine's clock display showing different brightness levels: OFF, 10%, 50%, and 100%.

## Sound Selection and Volume Control

- **Adjust Volume:** Short press the + or - buttons to increase or decrease the volume.
- **Change Sound:** Long press the + button to go to the previous sound track. Long press the - button to go to the next sound track.
- **Pause/Play:** Short press the Play/Bluetooth button () to pause or resume the current sound.

## Night Light Control

- **Turn On/Off Light:** Short press the Light/Snooze button (\*) to turn the night light on or off.
- **Change Light Mode/Color:** Continue short pressing the Light/Snooze button (\*) to cycle through the 8 unique light modes and RGB breathing. For infinite dimming and variable color temperature, use the mobile application.

# Say Goodbye to Insomnia Applicable to all kinds of people



## Sleep Deeply




Image: A person using the Augnner Sound Machine Alarm Clock at night, with the device emitting a yellow light. A smartphone screen shows the app interface for controlling light colors and rhythm. Below the main image, a spectrum of 8 colors (red, yellow, green, cyan, blue, purple, pink, white) is displayed, indicating the available night light options.

### Clock and Alarm Settings

- Set Time:** Long press the Time Setting button (+) to enter time setting mode. Use the + and - buttons to adjust the hour and minute. Short press the Time Setting button (-) to confirm and move to the next setting.
- Set Alarm:** Long press the Alarm button (+) for 2 seconds to enter alarm settings. Short press the Alarm button (+) again to cycle through settings: hour, minute, ringtone, volume, workday. Adjust values using + and - keys.
- Turn Alarm On/Off:** Short press the Alarm button (+) to toggle the alarm on or off.
- Snooze:** When the alarm sounds, short press the Light/Snooze button (\*) to activate snooze.



Image: Two images of the sound machine's display, illustrating the 12-hour format (e.g., 10:30 AM) and the 24-hour format (e.g., 22:30).

## App Control

The Augnner Sound Machine Alarm Clock can be controlled via a dedicated mobile application. Search for "White Whisper" in your device's app store or scan the QR codes below to download.



Image: A smartphone screen showing the "White Whisper" app interface, alongside three QR codes for downloading the app from the App Store, Google Play, and another Android App Store link.

Download links: [App Store \(iOS\)](#) | [Google Play \(Android\)](#) | [Android App Store \(Alternative\)](#)

- **App Features:** The app allows for comprehensive control over sound selection, volume, night light colors and dimming, alarm settings, and sleep timer functions.
- **Child Lock:** The app also provides a child lock switch to prevent unintended operation, which is useful for households with young children.

## Bluetooth Pairing

- **Enter Pairing Mode:** Long press the Play/Bluetooth button ( ) for more than 2 seconds to enter Bluetooth pairing mode. The device will indicate it's ready to pair.
- **Connect:** On your mobile device, enable Bluetooth and search for "Augnner B005" (or similar name). Select the device to pair.
- **Play Audio:** Once paired, you can play audio from your mobile device through the sound machine.

## Auto-Off Sleep Timer

- **Set Timer:** Short press the Timer button ( ) to cycle through preset auto-off times: 30, 60, 90, 120, 240 minutes, or OFF (no time limit).
- **App Control:** The app also allows for more precise control over the sleep timer settings.




Image: A person sleeping in bed with the sound machine on a bedside table, illustrating the auto-off timer feature. An hourglass icon indicates the timer function.

## MAINTENANCE

- Cleaning:** Wipe the device with a soft, dry cloth. Do not use abrasive cleaners or solvents.
- Storage:** Store the device in a cool, dry place when not in use for extended periods.
- Battery Care:** To prolong battery life, avoid fully discharging the battery frequently. Charge the device regularly.

## TROUBLESHOOTING

Problem	Possible Cause	Solution
Device does not turn on.	Low battery; Power button not pressed correctly.	Charge the device fully. Press and hold the Power button for 2 seconds.
No sound or low volume.	Volume too low; Sound paused; Incorrect sound selected.	Increase volume using + button. Press Play/Bluetooth button to resume. Cycle through sounds using +/- long press.
Bluetooth not connecting.	Device not in pairing mode; Bluetooth disabled on mobile device; Too far from device.	Long press Play/Bluetooth button to enter pairing mode. Ensure Bluetooth is enabled on your phone. Move closer to the sound machine.
Clock display is off.	Display brightness set to OFF.	Short press the Power button () to cycle through brightness levels until the display is visible.
Alarm does not sound.	Alarm not set or turned off; Volume too low.	Check alarm settings and ensure it's enabled. Increase alarm volume.

## SPECIFICATIONS

- Model:** B005
- Product Dimensions:** 3.15 x 1.85 x 3.15 inches

- **Weight:** 11.2 ounces
- **Material:** ABS+PC+Silicone+Fabric
- **Power Source:** Battery Powered (800 mA built-in battery)
- **Charging Port:** USB Type-C
- **Sound Tracks:** 32 (including White Noise, Brown Noise, Pink Noise, Birdsong, Breeze, Drizzle, Ocean Waves, Rain, Stream, Trains, etc.)
- **Night Light Colors:** 8 unique modes + RGB breathing, 3000 adjustable color temperatures
- **Bluetooth Version:** 5.4

## SAFETY INFORMATION

---

Please read and adhere to the following safety guidelines:

- Do not use the device near water or in excessively humid environments.
- This product is not a toy. Keep out of reach of small children. Adult supervision is required when children are present.
- Prolonged exposure to high volumes may cause hearing damage. Use at moderate volume levels.
- Do not attempt to disassemble, repair, or modify the device. This will void the warranty and may cause damage or injury.
- Use only the provided charging cable.

## WARRANTY AND SUPPORT

---

Augnner products are designed and manufactured to the highest quality standards. For information regarding warranty coverage, technical support, or customer service inquiries, please refer to the contact information provided on the product packaging or visit the official Augnner website. Please retain your proof of purchase for warranty claims.

**Manufacturer:** Augnner

**Date First Available:** November 18, 2024

