

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

Manuals.plus /

› [VEVOR](#) /

› VEVOR 61 Key Digital Keyboard Piano User Manual

VEVOR BD-663

VEVOR 61 Key Digital Keyboard Piano User Manual

Model: BD-663

INTRODUCTION

This manual provides comprehensive instructions for the VEVOR 61 Key Digital Keyboard Piano. Please read this manual thoroughly before operating the instrument to ensure proper use, optimal performance, and longevity of your product. This digital piano is designed for beginners and experienced players alike, offering a wide range of tones, rhythms, and features for learning and creative expression.

PACKAGE CONTENTS

Upon unboxing, please verify that all components are present:

- VEVOR 61 Key Digital Keyboard Piano
- Music Stand
- Headphones
- USB Charging Cable
- Piano Stickers
- Music Sheet Clip
- User Manual (this document)

Item Model Number: **BD-663**Tones: **200**Number of Keys: **61 (C3 - C8)**Main Material: **HIPS Plastic**Rhythms: **200**Net Weight: **4.6 lbs/2.1 kg**USB
Charging Cable
(6.56 ft/2 m)×1Sheet Music
Stand×1Piano
Stickers×1

Headphones×1

Music Sheet
Clip×1

Figure 1: Product dimensions and included accessories.

SETUP GUIDE

1. Power Connection

The VEVOR Digital Keyboard Piano can be powered via the included USB charging cable or by batteries (not included). Connect the USB cable to the designated port on the piano and to a compatible USB power adapter (e.g., phone charger, computer USB port).

2. Music Stand Installation

Insert the music stand into the slots located on the top rear of the keyboard. Ensure it is securely seated to hold your sheet music or tablet.

3. Connecting Peripherals

Locate the input/output ports on the back or side of the keyboard:

- **Audio Output (Headphones):** Connect the included headphones or external speakers to the 3.5mm audio output jack for private practice or amplified sound.
- **Microphone Input:** Connect a microphone to the microphone input jack for vocal accompaniment.
- **Audio Input:** Connect external audio sources (e.g., smartphone, MP3 player) to the audio input jack to play along with your favorite songs.

SUPPORT MULTIPLE DEVICE CONNECTIONS

Ideal for recording or connecting external audio sources



Figure 2: Overview of device connection ports.

4. Applying Piano Stickers

For beginners, the included piano stickers can be applied to the keys to help identify notes and facilitate learning. Carefully peel and stick them onto the corresponding keys as indicated in the sticker guide (if provided) or based on standard piano key labeling.

OPERATING INSTRUCTIONS

1. Power On/Off

Press the **POWER** button to turn the keyboard on or off. The LED display will illuminate upon power-on.

2. Volume Control

Adjust the master volume using the **VOLUME +/-** buttons or knob (if present) to your desired level.

3. Selecting Tones (Instruments)

The keyboard features 200 standard tones. To select a tone, press the **TONE** button and then use the number pad or +/- buttons to enter the desired tone number. The selected tone will be displayed on the LED screen.

4. Selecting Rhythms

The keyboard includes 200 international rhythms. Press the **RHYTHM** button and use the number pad or +/- buttons to select a rhythm. Press **START/STOP** to begin or end the rhythm playback.

5. Playing Demo Songs

There are 60 built-in demo songs. Press the **DEMO SONG** button and use the number pad or +/- buttons to choose a song. Press **PLAY** to start the demo song.

6. Using the LED Display

The crystal-clear LED display provides real-time information, showing the selected tone, rhythm, demo song number, and other operational parameters. This allows for easy navigation and control of the keyboard's functions.

VEVOR
TOUGH TOOLS, HALF PRICE

PERFECT FOR BEGINNERS

Practice a variety of music styles



LED Screen for Real-Time Display

61 Keys



200 Tones



200 Rhythms



60 Demos



Figure 3: The LED screen provides real-time display of settings.

PRACTICE WITHOUT DISTURBING OTHERS

Support headphone or speaker playback



Dual Speakers, Stereo Sound



Quality Headphones Focused Practice



Figure 4: Practice privately with headphones for focused learning.

KEY FEATURES

61 Standard-Sized Keys

The keyboard features 61 standard-sized keys, providing a familiar feel for piano players and aiding in proper finger placement and technique development.

200 Tones and 200 Rhythms

Explore a vast array of musical possibilities with 200 different instrument tones and 200 diverse rhythms, allowing for versatile musical expression across various genres.

60 Demo Songs

Learn and practice with 60 pre-recorded demo songs, perfect for beginners to understand song structure and rhythm.

Built-In Dual Speakers

Equipped with two integrated speakers, the piano delivers clear and powerful sound, creating an immersive audio experience for both practice and performance.



Figure 5: Dual speakers provide crisp, clear audio.

Connectivity Options

The piano supports multiple device connections, including audio output for headphones or external speakers, microphone input for singing along, and audio input for connecting external music sources. This versatility makes it ideal for various practice and performance scenarios.

MAINTENANCE

To ensure the longevity and optimal performance of your VEVOR Digital Keyboard Piano, follow these maintenance guidelines:

- **Cleaning:** Use a soft, dry cloth to wipe the surface of the keyboard. For stubborn dirt, slightly dampen the cloth

with water and a mild, non-abrasive cleaner, then wipe dry immediately. Avoid using harsh chemicals or abrasive materials.

- **Storage:** Store the keyboard in a cool, dry place away from direct sunlight, extreme temperatures, and high humidity. When not in use for extended periods, consider covering it to protect against dust.
- **Handling:** Handle the keyboard with care. Avoid dropping it or subjecting it to strong impacts. Do not place heavy objects on top of the keys.
- **Power:** Disconnect the power adapter when the keyboard is not in use or during electrical storms. If using batteries, remove them if the keyboard will not be used for a long time to prevent leakage.

TROUBLESHOOTING

If you encounter any issues with your VEVOR Digital Keyboard Piano, please refer to the following common problems and solutions:

Problem	Possible Cause	Solution
No power/Keyboard does not turn on.	Power adapter not connected properly; Batteries are dead or incorrectly inserted; Power button not pressed firmly.	Ensure power adapter is securely connected. If using batteries, replace them with new ones and check polarity. Press the POWER button firmly.
No sound from speakers/headphones.	Volume is too low; Headphones not fully plugged in; External speakers not connected or powered on.	Increase the master volume. Ensure headphones are fully inserted into the audio output jack. Check connections and power for external speakers.
Keys feel loose or unresponsive.	Normal wear and tear; Minor manufacturing variation.	While some key movement is normal, if a key is completely unresponsive, contact customer support. Avoid excessive force on keys.
Microphone or external audio input not working.	Cable not connected properly; Device volume too low; Incompatible device.	Ensure cables are fully inserted into the correct input jacks. Check the volume on the connected device. Ensure the connected device is compatible.
Distorted sound.	Volume too high; Poor quality audio source; Damaged speakers.	Lower the volume. Try a different audio source. If distortion persists, contact customer support.

SPECIFICATIONS

Feature	Detail
Model Name	61 Key Digital Keyboard Piano
Item Model Number	BD-663
Number of Keys	61
Tones	200
Rhythms	200

Feature	Detail
Demo Songs	60
Connectivity Technology	Auxiliary
Connector Type	3.5mm Jack, USB Type A
Power Source	Battery Powered / USB Powered
Item Weight	5.07 Pounds (2.3 kg)
Package Dimensions	37.2 x 12.99 x 4.92 inches (94.5 x 33 x 12.5 cm)
Manufacturer	VEVOR
UPC	197988851295

WARRANTY AND SUPPORT

VEVOR products are designed for durability and performance. For warranty information, technical support, or service inquiries, please contact VEVOR customer service through their official website or the contact information provided with your purchase. Please have your model number (BD-663) and purchase details ready when contacting support.

For more information, visit the official VEVOR Store: [VEVOR Store on Amazon](#)