

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

- › [Olfjurk](#) /
- › [Automatic Dog & Cat Feeder User Manual](#)

Olfjurk PF002S

Olfjurk Automatic Dog & Cat Feeder

Model: PF002S

INTRODUCTION

Thank you for choosing the Olfjurk Automatic Dog & Cat Feeder. This device is designed to provide a convenient and reliable way to feed your pets on a scheduled basis, ensuring they receive fresh food even when you are away. With its customizable meal settings and dual power supply, you can maintain your pet's healthy eating habits with ease.



The Ol'fjurk Automatic Dog & Cat Feeder, shown here dispensing kibble into its feeding bowl.

SAFETY INFORMATION

- Read all instructions carefully before using the feeder.
- Keep the feeder away from children and pets when not in use or during assembly.
- Use only dry pet food with a kibble size between 3-13mm to prevent jamming.
- Do not immerse the main base unit in water or any other liquid. Only detachable components are washable.
- Ensure the power adapter is securely connected and the batteries (if used) are inserted correctly.
- Do not attempt to disassemble or repair the feeder yourself. Contact customer support for assistance.

PACKAGE CONTENTS

Please check the package contents to ensure all items are present:

- Automatic Pet Feeder Main Unit (Base with control panel)
- Food Storage Bucket (4L capacity)
- Food Dish/Bowl
- USB Power Cable (Adapter not included)
- Desiccant Pack (pre-installed or separate)
- User Manual

PRODUCT OVERVIEW

Familiarize yourself with the components of your Olfjurk Automatic Pet Feeder:



Labeled components of the Olfjurk Automatic Pet Feeder, including the food bucket lid, buckle, desiccant compartment, control panel, food outlet, and food dish. Dimensions are also indicated.

- **Food Bucket Lid:** Secures the food and contains the desiccant pack.

- **Buckle:** Locks the lid securely to the food bucket.
- **Desiccant:** Helps keep the pet food fresh and dry.
- **Food Storage Bucket:** Transparent container for storing dry pet food (4L capacity).
- **Control Panel:** Features an LCD screen and buttons for setting up the feeder.
- **Food Outlet:** Where the kibble is dispensed from the feeder.
- **Food Dish:** Removable bowl for pets to eat from.

SETUP

1. Assembly

1. Place the main unit on a flat, stable surface.
2. Attach the food dish to the front of the main unit by aligning the slots and pushing it firmly until it clicks into place.
3. Place the food storage bucket onto the main unit, ensuring it is seated correctly.
4. Open the food bucket lid and ensure the desiccant pack is in its compartment. Replace the desiccant pack every 1-2 months for optimal freshness.

2. Power Supply

The feeder supports dual power supply for continuous operation:

Dual Power Supply



The feeder can be powered by a DC 5V power adapter (via USB cable) or by 3 D-type batteries for backup.

- **DC 5V Power Adapter (Primary):** Connect the USB power cable to the feeder's power port and plug it into a DC 5V power adapter (not included) connected to a wall outlet.
- **3*Type D Batteries (Backup):** For power outage protection, insert three D-type batteries (not included) into the battery compartment at the bottom of the feeder. Ensure correct polarity.

3. Filling the Food Container

Open the food bucket lid and pour dry pet food into the transparent storage bucket. The 4L capacity allows for several weeks of feeding. Close the lid securely using the buckle to maintain freshness.

OPERATING INSTRUCTIONS

The LCD screen and control buttons allow for easy programming of your feeder.

Customized Feeding Schedule

Helps pets eat regularly and stay healthy



Up to 6 Meals



Up to 15 Portions
per Meal



Food Capacity



Kibble Size



The feeder supports up to 6 meals per day, with up to 15 portions per meal, and has a 4L food capacity. Recommended kibble size is 3-13mm.

1. LCD Screen Overview

The LCD screen displays the current time, programmed meal times, and portion settings. Use the buttons below the screen to navigate and adjust settings.

2. Setting Current Time

1. Press the "SET" button to enter time setting mode. The hour digit will flash.
2. Use the "+" and "-" buttons to adjust the hour.
3. Press "SET" again to move to the minute digit. Adjust with "+" and "-".
4. Press "SET" to confirm and exit time setting.

3. Setting Meal Times and Portions

You can program up to 6 meals per day, with 1 to 15 portions per meal.

1. Press the "MEAL" button to cycle through meal settings (M1, M2, M3, M4, M5, M6).

2. When a meal (e.g., M1) is selected, its time will flash. Use "+" and "-" to set the desired feeding time (hour and minute).
3. Press "MEAL" again to move to the portion setting for that meal. The portion number will flash.
4. Use "+" and "-" to adjust the number of portions (1-15). *Note: The actual amount of food per portion may vary slightly based on kibble size. Adjust as needed.*
5. Repeat for all desired meals (M1-M6). If a meal is not set, it will not dispense food.
6. Press "SET" to save settings and exit programming mode.

4. Manual Feeding

To dispense food manually, press and hold the "MANUAL" button. The feeder will dispense one portion of food. Release the button to stop.

MAINTENANCE

1. Cleaning

Regular cleaning ensures hygiene and proper functioning of the feeder.



The food bucket and food dish are detachable for easy cleaning. Remember, the main base unit should not be washed with water.

- **Detachable Components:** The food storage bucket and food dish can be easily detached from the main unit. Wash them with mild soap and water, then rinse thoroughly and dry completely before reassembling.
- **Main Unit:** Wipe the main unit (base with control panel) with a soft, damp cloth. **Do not wash the base directly with water or immerse it.**
- Ensure all parts are completely dry before refilling with food or reconnecting power.

2. Desiccant Pack Replacement

The desiccant pack helps keep food fresh. It is recommended to replace it every 1-2 months, or more frequently in humid environments.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Feeder not dispensing food.	<ul style="list-style-type: none">◦ No power or low battery.◦ Food outlet jammed.◦ No food in hopper.◦ Incorrect schedule settings.	<ul style="list-style-type: none">◦ Check power adapter connection or replace D-type batteries.◦ Clear any obstructions from the food outlet. Ensure kibble size is appropriate (3-13mm).◦ Refill the food storage bucket.◦ Verify meal times and portions are correctly set on the LCD screen.
LCD screen is blank.	<ul style="list-style-type: none">◦ No power.◦ Batteries drained or incorrectly inserted.	<ul style="list-style-type: none">◦ Ensure power adapter is connected and working.◦ Check battery polarity and replace batteries if needed.
Food is not fresh.	<ul style="list-style-type: none">◦ Lid not securely closed.◦ Desiccant pack needs replacement.	<ul style="list-style-type: none">◦ Ensure the food bucket lid is buckled tightly.◦ Replace the desiccant pack.

If the problem persists, please contact Olfjurk customer support.

SPECIFICATIONS

Model Number	PF002S
Capacity	4 Liters
Power Supply	DC 5V (USB cable, adapter not included) or 3 x D-type batteries (not included)
Max Meals Per Day	6
Portions Per Meal	1-15
Recommended Kibble Size	3-13 mm
Dimensions (LxWxH)	7.7 x 7.7 x 9.3 inches (19.6 x 19.6 x 23.6 cm)

Weight	3.29 pounds (1.49 kg)
---------------	-----------------------

WARRANTY AND SUPPORT

The Olfjurk Automatic Dog & Cat Feeder comes with a **1-year manufacturer's warranty** from the date of purchase. For technical support, warranty claims, or any questions regarding your product, please contact Olfjurk customer service through the retailer where you purchased the product or visit the official Olfjurk website for contact information. Please have your model number (PF002S) and purchase date ready when contacting support.



© 2025 Olfjurk. All rights reserved.

Related Documents - PF002S

	<p>Olfjurk Smart Pet Feeder PF002V Instruction Manual Comprehensive instruction manual for the Olfjurk Smart Pet Feeder PF002V, covering safety, setup, operation, cleaning, maintenance, and troubleshooting.</p>
	<p>Olfjurk Smart Pet Feeder PF002W Instruction Manual Comprehensive instruction manual for the Olfjurk Smart Pet Feeder (Model PF002W), covering setup, operation, app integration, cleaning, maintenance, and troubleshooting. Includes safety guidelines, specifications, and app usage.</p>
	<p>Manuale Utente Scalda Latte Portatile Olfjurk OLF8119 Guida completa all'uso, pulizia e manutenzione dello scaldalatte portatile Olfjurk OLF8119. Scopri le funzioni, le specifiche tecniche e le soluzioni ai problemi comuni per garantire un riscaldamento sicuro ed efficiente delle bevande per neonati.</p>
	<p>Manual de Usuario Olfjurk: Especificaciones Técnicas y Guía de Uso Descubra las especificaciones técnicas, el uso seguro y el mantenimiento del sacaleches Olfjurk. Incluye instrucciones de montaje, desmontaje, limpieza y esterilización para una experiencia óptima.</p>