

- Manuals.plus /
- › JACKYLED /
- › JACKYLED ARWL04 Battery Operated Wall Sconces Instruction Manual

JACKYLED ARWL04

JACKYLED ARWL04 Battery Operated Wall Sconces Instruction Manual

Model: ARWL04 | Brand: JACKYLED

INTRODUCTION

This manual provides comprehensive instructions for the safe and efficient use of your JACKYLED ARWL04 Battery Operated Wall Sconces. Please read this manual thoroughly before installation and operation, and retain it for future reference.



Image: Two JACKYLED ARWL04 Battery Operated Wall Sconces, showcasing their sleek design.


PACKAGE CONTENTS

Ensure all items listed below are present in your package:

- 2 x JACKYLED Wall Sconces
- 2 x Remote Controls
- 2 x USB-C Charging Cables
- Mounting Hardware (Iron Plates, Anchors, Screws)
- User Manual

Specs & Accessories

2 Sets of Lights with Interchangeable Remotes



Remote Control
No Batteries



Press:
ON/Change Color/OFF

Hold:
Smooth Dimming



Image: Overview of the package contents, including two wall sconces, two remote controls, and mounting hardware.

SETUP AND INSTALLATION

The JACKYLED ARWL04 wall sconces are designed for effortless, cordless installation. No electrical wiring is required.

1. **Charge the Sconces:** Before installation, fully charge both wall sconces using the provided USB-C cables. The charging port is located at the bottom of the main unit.

2. **Select Mounting Location:** Choose a desired location on your wall. The sconces attach magnetically to metal plates, allowing for flexible positioning.
3. **Install Metal Plates:** Use the provided screws and anchors to securely fix the metal mounting plates to the wall. Ensure the plates are level if a symmetrical appearance is desired. The iron plates can be installed squarely or diagonally.
4. **Attach Sconces:** Once the metal plates are firmly installed, simply align the magnetic back of each sconce with a mounted plate. The strong magnets will hold the sconce in place.




Image: Diagram illustrating the two-step cordless installation process: mounting the iron plate and magnetically attaching the light.




Image: Close-up view of the magnetic attachment mechanism between the sconce and the wall plate.

OPERATING INSTRUCTIONS

Power On/Off and Light Modes

The sconces can be controlled via the included remote control or the manual button located on the bottom of the main unit.

- **Manual Control:** Press the button on the bottom of the sconce to cycle through Warm Light (3000K), Natural Light (4500K), Cool Light (6000K), and Off. Hold the button to smoothly adjust brightness (10% to 100%).
- **Remote Control:** Use the 'ON' and 'OFF' buttons to power the lights. Dedicated buttons for 3000K (Warm), 4500K (Natural), and 6000K (Cool) allow for direct selection of color temperature. Use the brightness up/down buttons to adjust intensity.

3-Color Dimmable Light

Set Your Ambience Light as You Like



3000K Warm Light



4500K Natural Light



6000K Cool Light



10%-100% Smooth Dimming

Image: Visual representation of the three color temperatures (Warm, Natural, Cool) and smooth dimming capability.

Timing Function

The remote control includes a timing function to automatically shut off the lights after a set duration:

- Select from 15, 30, 60, or 120 minutes. The lights will automatically turn off after the selected time.

Memory Function

The sconces feature a memory function that recalls your last brightness and color temperature setting when turned back on.

Flexible Arms

Each sconce features dual arms that can be rotated independently up to 300 degrees. This allows for customization of the light direction and aesthetic arrangement.




Image: Demonstrates the 300-degree flexible arms, allowing for various light configurations.

MAINTENANCE

Charging the Battery

The sconces are powered by a built-in 4000mAh Lithium Ion battery. To recharge, simply detach the sconce from its magnetic wall plate and connect the provided USB-C cable to the charging port at the bottom of the unit. Connect the other end to a compatible USB power source.



Image: Close-up of the USB-C charging port located on the bottom of the wall sconce.

Cleaning

Wipe the sconces with a soft, dry cloth. Avoid using abrasive cleaners or solvents that may damage the finish.

TROUBLESHOOTING

- **Light not turning on:**
 - Ensure the battery is charged.
 - Check if the remote control batteries (AAA, not included) need replacement.
 - Verify the remote control is pointed towards the IR sensor on the sconce.
- **Remote control not responding:**
 - Replace remote control batteries.
 - Ensure no obstructions are between the remote and the sconce's IR sensor.
- **Sconce not staying on wall:**
 - Ensure the metal mounting plate is securely fastened to the wall.
 - Verify the sconce is correctly aligned with the magnetic plate.

SPECIFICATIONS

Brand	JACKYLED
Model Name	ARWL04
Color	Black
Material	Metal
Product Dimensions	26.5"L x 3.2"W x 2.4"H
Power Source	Battery Powered (4000mAh Lithium Ion)

Light Source Type	LED
Color Temperature	3000K (Warm), 4500K (Natural), 6000K (Cool)
Brightness	10% to 100% Dimmable (Max 150 Lumens)
Control Method	Remote, Touch Button
Special Features	300° Rotate, Adjustable Color Temperature, Dimmable, Timer, Wireless
Number of Items	2
Indoor/Outdoor Usage	Indoor

WARRANTY AND SUPPORT

The JACKYLED ARWL04 Wall Sconces come with a**Lifetime Warranty**. For any questions, technical support, or warranty claims, please refer to the contact information provided on the product packaging or the official JACKYLED website.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0DM91HMCF>

More documents and user manuals: <https://manuals.plus/>