

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [JOYTUTUS](#) /

› [JOYTUTUS Inflatable SUV Tent \(Model H1201-01011-BL\) Instruction Manual](#)

JOYTUTUS H1201-01011-BL

JOYTUTUS Inflatable SUV Tent (Model H1201-01011-BL) Instruction Manual

Your Guide to Easy Setup and Enjoyable Camping

1. PRODUCT OVERVIEW

The JOYTUTUS Inflatable SUV Tent (Model H1201-01011-BL) is designed for versatile outdoor use, offering a spacious and secure shelter for up to 6 people. This dual-use tent can be attached to your SUV, CUV, MPV, or Jeep, or used as a standalone unit. Key features include a rapid inflation system for quick setup, two awnings for sun protection, and a waterproof design for various weather conditions.



Figure 1: JOYTUTUS Inflatable SUV Tent (Model H1201-01011-BL) in use with an SUV.

2. SETUP INSTRUCTIONS

2.1. Unpacking and Component Check

Before beginning assembly, unpack all components and verify that all parts are present according to the packing list. The tent includes the main tent body, a hand-operated air pump, canopy support poles, ground stakes, and guy ropes.



Weight 30.2lbs



Canopy support pole *2



Hand-operated Air Pump *1



Ground stake *16



Guy rope *4



Figure 2: Tent components including the tent, pump, poles, stakes, and ropes.

2.2. Tent Installation (Inflatable)

- 1. Unfold the Tent:** Lay the tent body flat on a clean, level surface.
- 2. Locate Inflation Valves:** Identify the inflation valves on the tent's air beams. Ensure all valves are securely closed before inflation.

3. **Inflate the Tent:** Connect the hand-operated air pump to the main inflation valve. Begin pumping air into the tent. The tent features a rapid inflation system designed for quick setup.
4. **Monitor Pressure:** The recommended pressure range for the tent's air beams is 5.5-6.5 PSI. Do not over-inflate.
5. **Secure the Tent:** Once inflated, use the provided ground stakes and guy ropes to secure the tent firmly to the ground.

Inflatable Tent: Ready in 1 Min!



Figure 3: Inflation process of the SUV tent.

Your browser does not support the video tag.

Video 1: Demonstrates the quick setup of the inflatable SUV tent.

2.3. Connecting to Vehicle

The tent features a channel cloth designed to connect securely to the rear of your SUV. This creates a seamless extension from your vehicle to the tent.

- 1. Position the Tent:** Align the tent's vehicle attachment sleeve with the rear of your SUV.
- 2. Attach the Sleeve:** Secure the sleeve around your vehicle's rear hatch using the integrated straps and buckles. Ensure a snug fit to prevent gaps.
- 3. Adjust for Fit:** For larger vehicle models, you can open the zipper on the channel cloth to adjust the tail size, ensuring a proper seal.
- 4. Secure to Vehicle:** Use additional straps to hook onto car door handles and wheels for enhanced stability, especially in windy conditions.

Stand Alone or SUV Mode

Expand Your Room



Figure 4: Tent in dual-use mode, attached to an SUV.

3. OPERATING THE TENT

3.1. Dual-Use Functionality

The JOYTUTUS SUV Tent offers flexibility:

- **SUV Mode:** Connect the tent to your vehicle for extended living space and direct access to your car's storage.

- **Standalone Mode:** Detach the tent from your vehicle to use it as a traditional ground tent, allowing you to drive away while leaving your camp set up.

3.2. Awning Setup

The tent includes two integrated awnings that can be set up for additional shade and shelter. Use the provided canopy support poles and guy ropes to extend and secure the awnings in your desired configuration.

2-in-1 Sunshade

Front or Side Coverage, Your Call!



Figure 5: Tent with flexible sunshades extended.

3.3. Ventilation and Access

The tent features dual doors and multiple mesh windows to enhance ventilation and provide easy access. The mesh screens keep insects out while allowing airflow. The main tent area offers a 6.6 ft peak height for comfortable movement.



Figure 6: Interior layout with designated playspace and sleep zone.

3.4. Entertainment and Private Space

One large awning can serve as a projection screen for outdoor movie nights. A dedicated small triangular area within the tent offers secure storage or can function as a private dressing room.

4. MAINTENANCE

4.1. Cleaning

Clean the tent with mild soap and water. Avoid harsh chemicals or abrasive cleaners that could damage the fabric or waterproof coating. Ensure the tent is completely dry before packing to prevent mold and mildew.

4.2. Storage

To pack up the tent, deflate all air beams and fold the tent neatly. Store all components in the provided tent storage bag in a cool, dry place away from direct sunlight.

Your browser does not support the video tag.

Video 2: Demonstrates the setup and pack-up process of the inflatable SUV tent.

4.3. Waterproofing

The tent is constructed from durable 600D Oxford fabric with a 1200PU coating. All seams are sealed and taped to provide superior waterproof protection. The woven polyethylene bottom further ensures a dry interior.



Figure 7: Waterproof and windproof features of the tent material.

5. TROUBLESHOOTING

- **Tent Not Inflating Properly:** Check all inflation valves to ensure they are securely closed. Verify that the pump hose is properly attached to the valve.

- **Tent Instability:** Ensure all ground stakes are firmly inserted into the ground and guy ropes are taut. For vehicle attachment, double-check all straps securing the tent to the car.
- **Water Leakage:** While the tent is designed to be waterproof, inspect seams and zippers for any damage or improper closure. Ensure the rainfly (if applicable) is correctly positioned.

6. SPECIFICATIONS




Feature	Detail
Product Dimensions	96"L x 80.4"W x 79"H
Item Weight	30.2 Pounds
Occupancy	6 Person
Seasons	4 Season
Water Resistance Technology	600D Oxford fabric with 1200PU coating and seam taping
Material	Oxford
Color	Gray Blue
Assembly Time	1 Minutes (Inflatable System)
Number of Rooms	2

7. WARRANTY AND SUPPORT

For warranty information, technical support, or replacement parts, please refer to the official documentation included with your product or contact JOYTUTUS customer service directly. Contact details are typically found on the product packaging or the manufacturer's website.

Related Documents - H1201-01011-BL

	<p>Joytutus Vehicle Armrest Cover Installation Guide - Model A3331-00001-BK</p> <p>Step-by-step installation guide for the Joytutus vehicle armrest cover (SKU: A3331-00001-BK), including parts list and application scenarios for Wrangler JL and Gladiator JT.</p>
	<p>H-K-Y H1201 Visual Negative Pressure Ear Cleaner User Manual</p> <p>Comprehensive user manual for the H-K-Y H1201 Visual Negative Pressure Ear Cleaner, detailing product overview, features, specifications, installation, usage, troubleshooting, and after-sales service.</p>

	<p>Panasonic Network Camera BL-VT164/BL-VP100 Series Operating Instructions</p> <p>Detailed operating instructions for Panasonic BL-VT164 Series and BL-VP100 Series network cameras. Covers setup, configuration, monitoring, and maintenance.</p>
	<p>HIOS Brushless Driver BL Series Operation Manual</p> <p>Comprehensive operation manual for HIOS BL Series Brushless Drivers, covering specifications, parts identification, accessories, operating procedures, torque adjustment, and troubleshooting for models like BL-2000, BL-3000, BL-5000, and BL-7000.</p>
	<p>HIOS Brushless Driver BL Series Operation Manual</p> <p>This operation manual provides detailed information on the HIOS Brushless Driver BL Series, including models BL-2000, BL-3000, BL-5000, and BL-7000. It covers parts identification, specifications, accessories, power supplies, operating procedures, torque adjustment, and troubleshooting.</p>
	<p>Panasonic Network Camera Setup Guide: BL-C210 & BL-C230 Installation and Configuration</p> <p>Comprehensive setup guide for Panasonic network cameras, models BL-C210 and BL-C230. Learn how to install, configure network settings, access remotely, and use viewer software.</p>