

[Manuals.plus](#) /

› [TYBERLEY](#) /

› TYBERLEY Benyar 5176 Automatic Mechanical Watch User Manual

TYBERLEY 5176

TYBERLEY Benyar 5176 Automatic Mechanical Watch User Manual

Model: 5176

INTRODUCTION

This manual provides essential instructions for the setup, operation, and maintenance of your TYBERLEY Benyar 5176 Automatic Mechanical Watch. Please read this guide thoroughly to ensure proper use and longevity of your timepiece.



Image: Front view of the TYBERLEY Benyar 5176 Automatic Mechanical Watch with a blue dial and stainless steel strap.

SETUP

1. Initial Winding

Your Benyar 5176 watch features an automatic mechanical movement. If the watch has stopped or has not been worn for an extended period, it requires initial winding to start. To wind the watch:

1. Unscrew the crown (if applicable) and pull it out to the first position.
2. Rotate the crown clockwise approximately 30-40 times. This will build up the power reserve.

3. Push the crown back in and screw it down to ensure water resistance.

The watch will then continue to wind itself through the motion of your wrist while worn.

2. Setting the Time

To set the correct time:

1. Unscrew the crown (if applicable) and pull it out to the second position.
2. Rotate the crown to move the hands clockwise until the desired time is displayed.
3. Once the time is set, push the crown back in and screw it down firmly to maintain water resistance.



Image: The TYBERLEY Benyar 5176 Automatic Mechanical Watch worn on a wrist, showcasing its design.

3. Adjusting the Strap

The stainless steel strap is adjustable. If the strap is too long, links can be removed using the included bracelet adjuster tool. It is recommended to have this adjustment performed by a professional watchmaker to prevent damage.

OPERATING THE WATCH

Automatic Movement

The Benyar 5176 watch is powered by a G2666Z self-winding mechanical movement. This movement harnesses the kinetic energy from your arm's motion to power the watch. When worn regularly, the watch will maintain its power reserve. If the watch is not worn for an extended period, it may stop and require manual winding as described in the "Initial Winding" section.

Luminous Function

The watch features luminescent hands and hour markers, allowing for clear time reading in low-light conditions. Exposure to light charges the luminous material.

Water Resistance (50M / 5 BAR)

This watch is rated for 50 meters (5 BAR) of water resistance. This means it is suitable for daily use, such as hand washing, face washing, and light rain exposure. It is **not** suitable for showering, bathing, swimming, diving, or any water sports. Ensure the crown is always screwed down tightly to maintain water resistance.



Image: The TYBERLEY Benyar 5176 Automatic Mechanical Watch displayed on a stand, highlighting its full design.

Your browser does not support the video tag.

Video: An official product video showcasing the TYBERLEY Benyar 5176 Automatic Mechanical Watch, demonstrating its features and design, including the luminous dial and water resistance.

MAINTENANCE

Cleaning

Regular cleaning of your watch strap and case is recommended. Use a soft, dry cloth to wipe away dust and smudges. For the stainless steel strap, a slightly damp cloth can be used, followed by immediate drying. Avoid using harsh chemicals or abrasive materials.

General Care

- **Avoid Violent Collisions:** Protect your watch from impacts and drops.
- **Magnetic Fields:** Keep the watch away from strong magnetic fields, as these can affect the accuracy of the mechanical movement.
- **Temperature Extremes:** Avoid exposing the watch to extremely hot or cold temperatures, and do not wear it in hot baths or saunas, as this can compromise water resistance and damage internal components.
- **Water Exposure:** Excessive water exposure, beyond the rated water resistance, can shorten the life of the watch.



Image: A warning label from the watch packaging, advising against violent collisions, magnetic fields, and wearing the watch in hot baths.

TROUBLESHOOTING

- **Watch Stops Running:** If the watch stops, it may have run out of power reserve. Manually wind the watch 30-40 times using the crown, then wear it regularly. If the issue persists, contact support.
- **Time Inaccuracy:** Minor variations in timekeeping are normal for mechanical watches. If the watch is consistently gaining or losing significant time, it may require adjustment. Ensure it has not been exposed to strong magnetic fields.
- **Condensation Under Crystal:** If condensation appears under the watch crystal, it indicates a breach in water resistance. Stop using the watch immediately and contact support for inspection and repair.

SPECIFICATIONS

Model Number	BY5176-FRE-BY5177
Movement	G2666Z Automatic Mechanical
Case Diameter	41mm
Dial Thickness	14mm
Band Width	21mm
Strap Length	240mm
Case Material	Alloy
Strap Material	Stainless Steel
Dial Window Material	Crystal Hardlex
Water Resistance	50M (5 BAR)
Clasp Type	Fold-over-clasp with safety

WARRANTY AND SUPPORT

Your TYBERLEY Benyar 5176 Automatic Mechanical Watch comes with a **1-year warranty** covering manufacturing defects. Additionally, we offer a **30-day free return policy** from the date of purchase.

For any issues or inquiries regarding your watch, please do not hesitate to contact our customer support team. We are committed to providing excellent service.

Contact Email: pagani.designwatchstore@gmail.com

