



Manuals.plus /

› Dytale /

› Dytale Wireless Headphones for TV, Model TV001 Grey - User Manual

Dytale TV001

Dytale Wireless Headphones for TV

MODEL TV001 GREY - USER MANUAL

Introduction

Thank you for choosing the Dytale Wireless Headphones for TV. This manual provides detailed instructions for setting up, operating, and maintaining your headphones to ensure an optimal audio experience. Please read this manual thoroughly before use and retain it for future reference.

What's in the Box

- Dytale Wireless Headphones (Grey)
- Charging Base / Transmitter
- Audio Cables (Optical, 3.5mm AUX, RCA)
- USB Charging Cable
- User Manual



Image: Dytole Wireless Headphones and Charging Base. The headphones are black/grey, resting on their charging base.

Setup

1. Charging the Headphones

Before first use, fully charge the headphones. Place the headphones onto the charging base. The indicator light on the base will show the charging status:

- **Red Light:** Charging
- **Solid Green Light:** Fully Charged

A full charge provides approximately 65 hours of playback.



Image: Dytale Wireless Headphones resting on their charging dock, with an arrow graphic indicating 65 hours of playtime.

2. Connecting the Transmitter to Your TV

The charging base also functions as the wireless transmitter. Connect it to your TV using one of the following methods:

1. **Optical Audio (Recommended for best quality):** Connect the optical cable from the transmitter's 'Optical In' port to your TV's 'Optical Out' port.
2. **3.5mm AUX Audio:** Connect the 3.5mm audio cable from the transmitter's 'AUX In' port to your TV's 'Headphone Out' or 'Audio Out' port.
3. **RCA Audio:** Use the RCA audio cable to connect the transmitter to your TV's 'Audio Out' (red and white) ports.

Ensure your TV's audio output settings are configured correctly for the chosen connection type (e.g., PCM for Optical output).



Image: Diagram illustrating the multiple connection methods (Optical, RCA, AUX 3.5mm, Bluetooth 5.2) for the Dytale Wireless Headphones, compatible with various TV brands, iPhones, Android phones, and computers.

3. Bluetooth Connection (for Mobile Devices/Computers)

The headphones also support Bluetooth 5.2 for connection to other devices:

1. Ensure the headphones are charged and powered on.
2. Activate Bluetooth on your mobile phone or computer.
3. Search for available devices and select "Dytale TV001" to pair.

4. Once paired, the headphones will connect automatically when in range.

Operating Instructions

Power On/Off

- **To Power On:** Press and hold the Power button on the headphone earcup until the indicator light illuminates.
- **To Power Off:** Press and hold the Power button until the indicator light turns off.

Volume Control

Use the volume control buttons located on the earcup to adjust the audio level to your preference.

Wearing the Headphones

Adjust the headband for a comfortable fit. The earcups are designed to fit over your ears for optimal sound isolation and comfort during extended use.

Wireless Range

The headphones maintain a stable connection up to 30 meters (100 feet) from the transmitter, allowing freedom of movement within your home.



Image: A man wearing Dytole Wireless Headphones is vacuuming a living room while watching television, demonstrating the wireless freedom.

Maintenance

- **Cleaning:** Use a soft, dry cloth to clean the headphones and charging base. Do not use abrasive cleaners or solvents.
- **Storage:** When not in use, store the headphones on the charging base or in a cool, dry place away from direct sunlight and extreme temperatures.
- **Battery Care:** To prolong battery life, avoid fully discharging the headphones frequently. Charge them regularly.

Troubleshooting

Problem	Solution
No sound from headphones	Ensure headphones are powered on and charged. Verify the transmitter is correctly connected to the TV and powered on. Check TV audio output settings (e.g., select Optical/AUX output). Increase headphone and TV volume.
Headphones not charging	Ensure the charging base is connected to power. Properly seat the headphones on the charging base. Check for any debris on charging contacts.
Poor audio quality or static	Move closer to the transmitter to improve signal. Ensure no strong interference sources (e.g., Wi-Fi routers, microwaves) are nearby. Check cable connections for looseness.

Specifications

Brand: Dytol

Model Number: TV001

Color: Grey

Ear Placement: Over Ear

Connectivity Technology: Wireless (Transmitter), Bluetooth 5.2

Bluetooth Range: Up to 35 meters (115 feet)

Battery Life: Up to 65 Hours

Impedance: 32 Ohms

Frequency Range: 20 Hz to 20,000 Hz

Audio Driver Type: Dynamic Driver

Noise Control: Active Noise Cancellation

Headphone Jack: 3.5 mm Jack (for wired use, cable not included)

Material: Plastic

Additional Features: Volume Control, Foldable, Lightweight

Warranty and Support

The Dytol Wireless Headphones Model TV001 Grey come with an **18-month warranty** from the date of purchase. This warranty covers manufacturing defects and ensures reliable performance under normal use.

For technical support, warranty claims, or any questions regarding your product, please contact Dytol customer service through the retailer's platform or visit the official Dytol website for contact information.