

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [FOREVER](#) /

› [FOREVER Kids Look Me! 3 KW-520 Smartwatch User Manual](#)

FOREVER KW-520

FOREVER Kids Look Me! 3 KW-520 Smartwatch User Manual

Your comprehensive guide to setting up, operating, and maintaining your FOREVER Kids Look Me! 3 KW-520 Smartwatch.

PRODUCT OVERVIEW

The FOREVER Kids Look Me! 3 KW-520 is a feature-rich smartwatch designed for children, offering a blend of fun and safety. It comes equipped with advanced GPS/LBS/Wi-Fi location tracking in 4G, allowing parents to monitor their child's whereabouts and set safe zones. This smartwatch serves as a practical alternative to a smartphone, enabling calls, video calls, and voice messages with parental control over contacts. A dedicated SOS emergency button provides quick access to help in critical situations. Its robust IP65 waterproof design ensures durability against daily splashes and activities, making it suitable for active children. Additionally, it includes a pedometer, learning apps, and various playful functions.



Image: The FOREVER Kids Look Me! 3 KW-520 Smartwatch in blue, shown on a child's wrist and as a standalone device displaying its main interface and game selection. This image highlights the watch's design and some of its key functionalities.

WHAT'S IN THE Box

Upon unboxing your FOREVER Kids Look Me! 3 KW-520 Smartwatch, you should find the following items:

- User Manual
- Charging Cable
- SIM Card Tool

SETUP GUIDE

1. Inserting the SIM Card

The smartwatch requires a Nano-SIM card for full functionality, including calls, messages, and location tracking. Ensure

the SIM card is active and has a data plan.

1. Locate the SIM card slot on the side of the smartwatch.
2. Use the provided SIM card tool to gently open the SIM tray.
3. Carefully place the Nano-SIM card into the tray, ensuring correct orientation as indicated by the diagram on the tray.
4. Gently push the SIM tray back into the slot until it clicks into place.



Image: A detailed view of the smartwatch highlighting the SIM card slot, indicating where the Nano-SIM card should be inserted.

2. Initial Charging

Before first use, fully charge the smartwatch. A full charge typically takes approximately 2-3 hours.

1. Connect the charging cable to the charging port on the smartwatch.
2. Plug the other end of the cable into a compatible USB power adapter (not included) or a computer's USB port.
3. The watch display will show a charging indicator.

3. App Installation and Pairing

To manage the smartwatch's features and communicate with your child, install the dedicated FOREVER app on your smartphone.

1. Scan the QR code provided in the watch's packaging or search for the "FOREVER Kids" app in your smartphone's app store (Google Play Store or Apple App Store).
2. Download and install the app.
3. Open the app and follow the on-screen instructions to create an account and pair your smartwatch. This usually involves scanning a QR code displayed on the watch's screen.
4. Once paired, you can configure contacts, set safe zones, and access other parental control features.



Image: A smartphone displaying the companion application for the smartwatch, showing features like location tracking, activity monitoring, and settings, which are managed by parents.

OPERATING YOUR SMARTWATCH

1. Basic Navigation

The smartwatch features a 1.85-inch touchscreen display for easy interaction. Swipe left/right or up/down to navigate through menus and applications. The side button typically serves as a power button and a back button.



Image: The smartwatch display showing the current time and date, demonstrating the clear and intuitive interface for daily use.

2. Making Calls and Video Calls

Once a SIM card is inserted and contacts are configured via the app, your child can make and receive calls.

- **Voice Calls:** Navigate to the "Phone" or "Contacts" application on the watch. Select a contact from the approved list to initiate a call.
- **Video Calls:** Access the "Video Call" application. Select an approved contact to start a video conversation.
- Only contacts added by the parent through the app can be called or can call the watch.



Image: A child using the smartwatch for a video call with an adult, illustrating the device's communication capabilities.

3. Using GPS Tracking and Geofence

The smartwatch utilizes GPS, LBS (Location Based Service), and Wi-Fi for accurate location tracking, which can be viewed through the companion app.

- **Real-time Tracking:** Open the app on your smartphone to see your child's current location on a map.
- **Geofence (Safe Zones):** In the app, you can define safe areas (e.g., home, school). You will receive notifications if your child enters or exits these predefined zones.

4. SOS Function

In case of an emergency, the smartwatch features a dedicated SOS button.

- **Activating SOS:** Press and hold the SOS button (usually a side button marked with SOS or a distinct color) for a few seconds.
- **Emergency Contacts:** The watch will automatically dial pre-set emergency contacts in a loop until one answers. It

will also send an alert message with the child's location to these contacts.



Image: A child on a bicycle, with an inset showing the smartwatch and its prominent SOS button, emphasizing the emergency call feature for safety.

5. Games and Learning Apps

The smartwatch includes pre-installed arcade and math games designed to entertain and educate children in an age-appropriate manner.



Image: A group of children smiling, with the smartwatch in the foreground displaying a menu of pre-installed games, highlighting its entertainment and educational features.

Maintenance and Care

- **Cleaning:** Wipe the smartwatch regularly with a soft, dry cloth. For stubborn dirt, slightly dampen the cloth with water. Avoid using harsh chemicals or abrasive materials.
- **Water Resistance:** The KW-520 has an IP65 rating, meaning it is splash-proof and resistant to dust. It is suitable for everyday use and light rain, but it should not be submerged in water, used for swimming, or exposed to high-pressure water jets.
- **Battery Care:** To prolong battery life, avoid extreme temperatures. Charge the watch regularly and avoid letting the battery drain completely for extended periods.

Troubleshooting

Problem	Possible Cause / Solution
Smartwatch does not turn on.	Battery might be completely drained. Connect to charger and wait a few minutes before attempting to power on.
SIM card not recognized.	Ensure the SIM card is correctly inserted and fully seated in the tray. Verify the SIM card is active and not damaged. Restart the smartwatch after inserting the SIM card.
Cannot make or receive calls.	Check for network signal strength on the watch. Ensure the SIM card has sufficient credit or an active plan. Verify that the contacts are correctly added and synced via the app.
Inaccurate location tracking.	GPS accuracy can be affected by environment (e.g., indoors, dense buildings). Ensure the watch has a clear view of the sky for better GPS signal. Check if Wi-Fi is enabled on the watch for improved indoor positioning.
Battery drains quickly.	Frequent calls, video calls, or continuous GPS tracking can consume more battery. Adjust settings in the app to optimize battery usage (e.g., location update frequency). Ensure no background apps are running unnecessarily.

TECHNICAL SPECIFICATIONS

Feature	Detail
Model Number	KW-520
Display Size	1.85 inches (4.7 cm)
Connectivity	4G, GPS, LBS, Wi-Fi, Bluetooth
Water Resistance	IP65 (Splash-proof)
Battery Type	Lithium-Ion
Product Dimensions	25 x 4 x 5 cm
Product Weight	53 grams
Internal Storage	16 MB
Manufacturer	TelForceOne
Country of Origin	China

WARRANTY AND SUPPORT

For information regarding the product warranty, please refer to the warranty card included in your product packaging or contact the retailer where the product was purchased. For technical support, frequently asked questions, or further assistance, please visit the official FOREVER brand store or contact their customer service directly.

Official Brand Store: [FOREVER Store on Amazon.de](#)

Related Documents - KW-520

	<p><u>Forever Call Me! 2 Smartwatch KW-60 User Manual</u> User manual for the Forever Call Me! 2 Smartwatch KW-60, providing instructions on installation, charging, app setup, and basic operations.</p>
	<p><u>Forever KidsWatch KW-210 Find Me!2 User Manual</u> User manual for the Forever KidsWatch KW-210 Find Me!2, detailing its features, setup, operation, and safety guidelines. Learn how to install a SIM card, charge the device, use its functions like calling, chat, and location tracking, and troubleshoot common issues.</p>
	<p><u>Forever LOOK Me2! KW-510 Kids Smartwatch User Manual</u> Comprehensive user manual for the Forever LOOK Me2! KW-510 Kids Smartwatch, covering specifications, setup, app functions, safety guidelines, and troubleshooting.</p>
	<p><u>Forever KidsWatch KW-310 User Manual</u> User manual for the Forever KidsWatch KW-310 children's smartwatch. Covers setup, features, app integration, settings, troubleshooting, and safety guidelines.</p>
	<p><u>Guía de Instalación y Configuración del Smartwatch Forever KW-300</u> Instrucciones detalladas para instalar la tarjeta SIM, configurar el APN y emparejar el smartwatch Forever KW-300 con la aplicación Forever Kidscare. Incluye lista de operadores y solución de problemas.</p>



[Forever KW-400 Kids Watch User Manual](#)

Comprehensive user manual for the Forever KW-400 Kids Watch, detailing setup, features, application usage, and troubleshooting. Learn how to charge, prepare, and operate the watch for optimal safety and communication.