

[Manuals.plus](#) /

› [Energizer](#) /

› Energizer Weatheready Rechargeable Flashlight User Manual (Model E304230100)

Energizer E304230100

Energizer Weatheready Rechargeable Flashlight User Manual

Model: E304230100

1. INTRODUCTION

The Energizer Weatheready Rechargeable Compact Handheld Light is designed to provide reliable illumination during power outages and for general use. Featuring a convenient plug-in design, this LED light ensures it is always charged and ready for emergency situations. It offers bright light, a durable construction, and automatic activation during power failures.



Figure 1: Energizer Weatherready Rechargeable Flashlights

2. PACKAGE CONTENTS

Your Energizer Weatherready Rechargeable Flashlight package includes:

- Three (3) Energizer Weatherready Rechargeable Compact Handheld Lights

INCLUDES

- 3 LIGHTS

PRODUCT SIZE: 5.25" X 1.5" X 1.75"



Figure 2: Contents of the package

3. SETUP

3.1 Initial Charging

Before first use, ensure the flashlight is fully charged. The unit features a retractable AC plug for direct insertion into any standard electrical outlet. A red LED charging indicator light will illuminate to confirm the unit is charging.



Figure 3: Retractable plug and charging indicator

3.2 Automatic Power Outage Activation

For the flashlight to automatically turn on during a power outage, leave the switch in the 'ON' position while it is plugged into the wall outlet and charging. This ensures the light activates immediately when power is lost, making it easy to locate.



Figure 4: Automatic power outage feature

Your browser does not support the video tag.

Video 1: Demonstrates the automatic power-on feature during a simulated power failure. The flashlight, when plugged in and set to 'ON', illuminates instantly when the power supply is interrupted.

4. OPERATING INSTRUCTIONS

4.1 Flashlight Function

To use as a handheld flashlight, simply unplug the unit from the wall. If the switch was left in the 'ON' position, the flashlight will activate automatically. You can then use the power button to cycle through different brightness settings or turn it off.



Figure 5: Flashlight in handheld use

4.2 Night Light Function

When plugged into an outlet and the switch is in the 'ON' position, the flashlight can function as a night light. It will emit a soft glow, providing continuous low-level illumination.

4.3 Power Outage Light

As described in Section 3.2, if the flashlight is plugged in and the switch is 'ON', it will automatically illuminate when the household power supply is interrupted.

Your browser does not support the video tag.

Video 2: Demonstrates the various lighting modes including power failure light, night light, flashlight, and tabletop light, showcasing the product's versatility.

5. MAINTENANCE

To maintain your Energizer WeatherReady Flashlight, wipe the exterior with a soft, dry cloth. Avoid using abrasive cleaners

or solvents. Ensure the unit is kept in a dry environment. The internal battery is non-removable and rechargeable, requiring no replacement.

6. TROUBLESHOOTING

- **Light does not turn on when unplugged:** Ensure the unit is fully charged. The red charging indicator should be on when plugged in. Verify the switch is in the 'ON' position.
- **Light does not turn on during power outage:** Confirm the flashlight was plugged into an active outlet and the switch was in the 'ON' position prior to the power loss.
- **Reduced runtime:** Battery performance may decrease over time with repeated charging cycles. Ensure the unit is charged overnight for optimal performance.

7. SPECIFICATIONS

Feature	Detail
Brand	Energizer
Model Name	ENR ENRCCHF23G.1 NA COMP RCH WB 3PK AMZ
Model Number	E304230100
Power Source	Battery Powered (Rechargeable)
Light Source Type	LED
Brightness	40 Lumens (White Brightness)
Material	Plastic
Product Dimensions	1.77"D x 4.49"W x 6.46"H
Item Weight	0.24 Kilograms
Battery Cell Composition	NiMH
Water Resistance Level	Not Water Resistant



Figure 6: Brightness and charging details

8. WARRANTY AND SUPPORT

Warranty information for this product is not applicable as per manufacturer specifications. For any product inquiries or support, please refer to the Energizer official website or contact their customer service directly.

© 2025 Energizer. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question