

- Manuals.plus /
- > Aroepurt /
 - > Aroepurt Flip Stand Wallet Case and Tempered Glass Screen Protector User Manual

Aroepurt HPPL67A

Aroepurt Flip Stand Wallet Case and Tempered Glass Screen Protector User Manual

Model: Hot Pepper HPPL67A Compatible Case

1. PRODUCT OVERVIEW

This manual provides instructions for the Aroepurt Flip Stand Wallet Case and the accompanying Tempered Glass Screen Protector, designed for the Hot Pepper HPPL67A phone. This product offers comprehensive protection, convenient card storage, and a versatile viewing stand.



Image 1.1: Overview of the Aroepurt Flip Stand Wallet Case, displaying its closed, open, stand, and wallet functionalities. The case is blue and made of PU leather.

Package Contents:

- 1 x Aroepurt Flip Stand Wallet Case (YZW Blue)
- 1 x Tempered Glass Screen Protector

2. SETUP AND INSTALLATION

2.1. Installing the Phone Case:

1. Ensure your Hot Pepper HPPL67A phone is clean and free of dust or debris.

2. Gently align your phone with the TPU silicone fixed case inside the wallet case.
3. Press the phone firmly into the case, ensuring all corners and edges are securely seated within the silicone frame. Verify that all ports and buttons are accessible and aligned correctly.

2.2. Installing the Tempered Glass Screen Protector:

Proper installation of the screen protector is crucial for optimal performance and bubble-free application.




Image 2.1: Key features of the tempered glass screen protector, highlighting its durability, clarity, and user-friendly attributes.

1. **Clean the Screen:** Use a microfiber cloth to thoroughly clean your phone's screen. Ensure there are no dust particles, smudges, or fingerprints. For best results, use an alcohol wipe if available, then dry with the cloth.
2. **Align the Protector:** Carefully peel off the protective film from the adhesive side of the tempered glass. Align the screen protector with your phone's screen, paying close attention to the cutouts for the speaker, camera, and home button (if applicable).
3. **Apply and Smooth:** Once aligned, gently lower the protector onto the screen. The adhesive will begin to spread. Use your finger or a soft card to push out any air bubbles towards the edges.
4. **Final Check:** Inspect the screen for any remaining bubbles. Small bubbles typically disappear within 24-48 hours.



Scratch Proof

Scratch proof screen effectively avoids sharp objects scratching or abrasion



Image 2.2: Demonstration of the screen protector's scratch-proof capability, showing its resistance to impact.

3. OPERATING INSTRUCTIONS

3.1. Using the Flip Stand Feature:

The case is designed with a built-in kickstand function, allowing for hands-free viewing of media.



Stand Feature

Adjustable viewing angles to
read your e-book or watch videos

Image 3.1: The case configured as a stand, providing an adjustable viewing angle suitable for watching videos or reading.

1. Open the front flap of the case.
2. Fold the back of the case along the designated crease to form a triangular support.
3. Rest the phone (still in its inner silicone case) against the folded flap to create a stable viewing angle.

3.2. Utilizing the Wallet Function:

The case includes multiple slots for cards and a pocket for cash, combining your phone and wallet into one convenient accessory.

CARD STORAGE

- Carry 3 cards and cash
- Combines a wallet and phone case in one handy unit



Image 3.2: Close-up view of the wallet section, illustrating the capacity for multiple cards and a dedicated cash compartment.

- Insert credit cards, ID cards, or transit cards into the designated card slots. The case can typically hold up to 3 cards.
- Place folded banknotes into the larger pocket behind the card slots.

4. MAINTENANCE AND CARE

4.1. Cleaning the PU Leather Case:

- Wipe the exterior of the case with a soft, damp cloth. Avoid using harsh chemicals or abrasive cleaners, as these can damage the PU leather.
- For stubborn stains, a mild soap solution can be used, followed by wiping with a clean, damp cloth and then drying

thoroughly.

- Allow the case to air dry completely before reinserting your phone.

4.2. Caring for the Tempered Glass Screen Protector:

- Clean the screen protector regularly with a microfiber cloth to remove fingerprints and smudges.
- Avoid sharp objects coming into direct contact with the screen protector, although it is designed to be scratch-resistant.
- If the screen protector cracks or shatters due to impact, carefully remove it to prevent injury and replace it with a new one.

5. TROUBLESHOOTING

5.1. Screen Protector Bubbles:

- **Small Bubbles:** Often disappear on their own within 24-48 hours.
- **Large Bubbles/Dust:** If a large bubble persists or you see dust trapped underneath, gently lift the nearest corner of the screen protector and use a dust removal sticker (if available) or a piece of tape to remove the dust. Reapply the protector slowly.

5.2. Case Fit Issues:

- Ensure your phone model is indeed Hot Pepper HPPL67A. This case is specifically designed for this model.
- Verify that the phone is fully seated within the inner silicone tray of the case. Apply gentle pressure around the edges to ensure a snug fit.

6. SPECIFICATIONS

Feature	Detail
Product Type	Flip Stand Wallet Case with Tempered Glass Screen Protector
Compatible Phone Model	Hot Pepper HPPL67A
Brand	Aroepurt
Material (Case)	PU Leather (Exterior), TPU Silicone (Inner Tray)
Color	YZW Blue
Special Features	Card insertion, Thickened anti-drop, Stand function, Stash the change
Screen Protector Hardness	9H High Hardness
Item Weight	2.46 ounces
Product Dimensions	0.39 x 0.39 x 0.39 inches (approximate, as listed)

7. WARRANTY AND SUPPORT

Specific warranty details for this product are not provided in the available information. For any inquiries regarding product defects, installation assistance, or general support, please contact the manufacturer or seller directly through your purchase platform.

When contacting support, please have your purchase details and product model (Hot Pepper HPPL67A Compatible Case) readily available.

© 2024 Aroepurt. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Email

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Details

Submit question

Open the live page

<https://manuals.plus/asin/B0DMDHVT87>

More documents and user manuals: <https://manuals.plus/>