

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- › [Anker](#) /
- › [Anker Laptop Power Bank A1695 User Manual](#)

Anker A1695

Anker Laptop Power Bank A1695 User Manual

Model: A1695

Brand: Anker

INTRODUCTION

Thank you for choosing the Anker Laptop Power Bank A1695. This portable charger is designed to provide reliable and high-speed power for your laptops, smartphones, tablets, and other USB-powered devices. With its large capacity, multiple high-power ports, and convenient built-in cables, it is an ideal companion for travel, work, and daily use. Please read this manual carefully to ensure proper usage and maintenance of your device.



Image: The Anker Laptop Power Bank A1695, highlighting its sleek design and integrated features.

PRODUCT FEATURES

- **Triple 100W USB-C Ports for Multi-Device Charging:** Equipped with three USB-C ports, each capable of

delivering up to 100W, allowing simultaneous high-speed charging of multiple devices, including laptops.



3 USB-C Ports with 100W Max Power Each



Charge to **50%**

16" MacBook Pro (M3)	33 Min	iPhone 16	25 Min
MacBook Air (M3)	33 Min	Samsung S24	28 Min

Note: Data based on internal lab testing, actual performance may vary.

*Anker is the world's No. 1 mobile charging brand based on retail sales value for four consecutive years: 2020, 2021, 2022, and 2023.

Image: The power bank connected to a MacBook, iPhone, and Samsung device, demonstrating its multi-device charging capability with three 100W USB-C ports.

- **25,000mAh High Capacity:** A substantial 25,000mAh (90Wh) battery capacity provides extended power, supporting multiple charges for various devices. It complies with airline carry-on regulations for batteries under 100Wh.

Sleek and Powerful With 25,000mAh

Flight-Ready Power
for Long Adventures



Flight-Approved

1.3 Charges
MacBook Air (M3)

1.4 Charges
iPad Pro (M4)

4.5 Charges
iPhone 16

4.7 Charges
Samsung S23

Note: Data based on internal lab testing. Actual charging times may vary.

Image: A user on an airplane charging a laptop with the Anker Power Bank, illustrating its flight-approved design and high capacity for long journeys.

- **Dual Built-In Cables:** Features two integrated USB-C cables: one retractable cable extending up to 2.3 ft (tested for over 20,000 retractions) and another 0.98 ft cable that doubles as a durable carrying strap (tested for over 20,000 bends).

Charge Anywhere With Dual Built-In Cables

Adjustable Built-In USB-C
Cable for All Your Needs



Built-In USB-C Cable
Doubles as Carrying Strap



Tested for Over
20,000
Retractions



Designed for Over
20,000
Bends

Note: Data based on internal lab testing.

Image: A visual representation of the power bank's dual built-in USB-C cables, one retractable for convenience and the other serving as a robust carrying strap.

- **Charge 4 Devices Simultaneously:** In addition to the dual built-in USB-C cables, the power bank includes an additional USB-C port and a USB-A port, allowing you to charge up to four devices concurrently.

Power Up Four Devices At Once

Elegantly Powers Your Tech Collection



USB-C Cables:



MacBook Air / Pro Series



iPad Pro / Air / Mini Series



iPhone 16 / 15 Series



Samsung S24 / S23 Series

USB-C Port:



iPhone 16 / 15 / 14 / 13 / 12 / SE Series



AirPods Max



Steam Deck

USB-A Port:



AirPods

Note: For iPhone 14 Series and earlier models, use a USB-C to Lightning adapter or cable (not included).

Image: The power bank actively charging a pair of headphones, a tablet, a laptop, and a smartphone, demonstrating its ability to power four devices at once.

- **Real-Time Smart Display:** An intuitive digital display provides essential information such as battery temperature, output and input wattage for each port, battery health, and remaining recharge time.

Real-Time Smart Display



Battery Temperature



Output and Input
Wattage



Battery Health



Image: A detailed view of the power bank's smart display, illustrating its real-time data on battery status, charging wattage, and temperature for informed usage.

SETUP

What's in the Box:

- Anker Power Bank (25K, 165W, Built-In and Retractable Cables)
- Protective Pouch
- User Manual

Initial Charging:

Before first use, it is recommended to fully charge your Anker Laptop Power Bank. Connect the power bank to a compatible USB-C wall charger (not included) using one of the built-in USB-C cables or an external USB-C cable. The smart display will show the charging status and estimated time to full charge. The power bank supports 100W ultra-fast recharging, allowing it to reach 30% charge in approximately 22 minutes.

OPERATING INSTRUCTIONS

Charging the Power Bank:

1. Connect a USB-C wall charger (100W recommended for fastest charging) to any of the power bank's USB-C input ports.
2. The digital display will illuminate, showing the input wattage and the current battery percentage.
3. Once fully charged, the display will show 100%. Disconnect the charger.

Charging Your Devices:

The Anker Laptop Power Bank can charge up to four devices simultaneously using its various ports and built-in cables.

- **Using Built-In USB-C Cables:** Extend the retractable USB-C cable or use the fixed USB-C cable (which also serves as a strap) to connect directly to your USB-C compatible devices (e.g., MacBook, iPhone 15/16 series, Samsung S24/S23 series, iPad Pro/Air/Mini Series).
- **Using USB-C Ports:** For devices requiring a USB-C connection, use an external USB-C to USB-C cable to connect to the available USB-C port on the power bank.
- **Using USB-A Port:** For devices requiring a USB-A connection (e.g., older smartphones, AirPods, Steam Deck, certain drones), use an external USB-A to compatible cable to connect to the USB-A port.

The smart display will show the output wattage for each connected device, allowing you to monitor charging speeds in real-time.

MAINTENANCE

- **Cleaning:** Use a soft, dry cloth to clean the surface of the power bank. Avoid using harsh chemicals or abrasive materials.
- **Storage:** Store the power bank in a cool, dry place away from direct sunlight, extreme temperatures, and humidity. If storing for an extended period, charge it to approximately 50% every 3-6 months to preserve battery health.
- **Protection:** The power bank features Anker's ActiveShield™ 2.0 technology, which monitors temperature over 3,000,000 times per day for constant protection. Avoid dropping the device or subjecting it to strong impacts.
- **Cable Care:** Handle the built-in cables gently. Do not force the retractable cable or excessively bend the strap cable beyond its natural flexibility.

TROUBLESHOOTING

Power Bank Not Charging:

- Ensure the wall charger and cable are functioning correctly. Try a different charger or cable.

- Check if the charging cable is securely connected to both the power bank and the wall charger.

Devices Not Charging or Charging Slowly:

- Verify that the power bank has sufficient charge.
- Ensure the charging cable connecting the device to the power bank is not damaged and is securely connected.
- Check the smart display for output wattage. If it's lower than expected, the device might not be drawing maximum power, or the cable might be limiting it.
- Some devices require specific charging protocols. Ensure your device is compatible with USB Power Delivery (PD) for optimal charging speeds via USB-C.
- If charging multiple devices, the total output wattage is shared. Disconnect some devices to see if charging speed improves for a specific device.

Display Not Working:

- Try connecting the power bank to a charger or a device to activate the display.
- If the issue persists, contact customer support.

SPECIFICATIONS

Feature	Detail
Model Number	A1695
Product Dimensions	6.18 x 2.13 x 1.93 inches
Item Weight	1.31 pounds
Battery Capacity	25,000 mAh (90Wh)
Connector Type	USB-C*3 + USB-A*1
Max Output (Single Port)	100W (USB-C)
Max Output (Total)	165W
Max Input (Recharging)	100W (USB-C)
Special Features	Built-In Cables, Digital Display, Fast Charging, Flight-Approved

WARRANTY AND SUPPORT

Warranty Information:

The Anker Laptop Power Bank A1695 comes with an 18-month warranty from the date of purchase. This warranty covers manufacturing defects and issues arising from normal use. Please retain your proof of purchase for warranty claims.

Customer Service:

For further assistance, troubleshooting, or warranty inquiries, please visit the official Anker website or contact

their customer service team. You can also refer to the comprehensive [User Guide \(PDF\)](#) available online for more detailed information.

© 2025 Anker Innovations Limited. All rights reserved.