

[Manuals.plus](#) /

› [VASAGLE](#) /

› VASAGLE 7-Tier Slim Shoe Rack Instruction Manual - Model LBS200L01

VASAGLE LBS200L01

VASAGLE 7-Tier Slim Shoe Rack Instruction Manual

Brand: VASAGLE

Model: LBS200L01

INTRODUCTION

This manual provides detailed instructions for the assembly, operation, and maintenance of your new VASAGLE 7-Tier Slim Shoe Rack. Please read these instructions carefully before beginning assembly and retain this manual for future reference. Proper assembly and care will ensure the longevity and safe use of your product.

VASAGLE
by SONGMICS HOME



Figure 1: Assembled VASAGLE 7-Tier Slim Shoe Rack.

SAFETY INFORMATION

To prevent injury or damage to the product, observe the following safety guidelines:

- **Anti-Tipping Kit:** An anti-tipping kit is included. It is highly recommended to secure the shoe rack to a wall using this kit to prevent accidental tipping, especially in households with children or pets.
- **Weight Capacity:** Each shelf is designed to support a maximum weight of 10 kg (22 lbs). Do not exceed this limit to ensure stability and prevent structural damage. The top surface can support up to 5 kg (11 lbs).
- **Assembly:** Assemble the product on a soft, clean surface to avoid scratches. Ensure all screws and fasteners are securely tightened before use.
- **Placement:** Place the shoe rack on a flat, level surface. Uneven surfaces can compromise stability.
- **Material:** This product is made of engineered wood. Avoid exposure to excessive moisture or direct sunlight to prevent warping or discoloration.

Robuste et stable

Chaque niveau supporte jusqu'à 10 kg



Étagères avec rebord rehaussés



Kit anti-basculement

Figure 2: Weight capacity and anti-tipping kit.

PACKAGE CONTENTS

Before assembly, verify that all components are present and undamaged. Refer to the separate parts list and hardware pack included with your product for specific item identification. Typically, your package should contain:

- Wooden panels for shelves and frame
- Assembly hardware (screws, dowels, etc.)
- 2 x Hooks
- Anti-tipping kit
- Instruction manual (this document)

If any parts are missing or damaged, please contact customer support for assistance.

ASSEMBLY INSTRUCTIONS

Follow these steps to assemble your shoe rack. It is recommended to have two people for assembly.

1. **Unpack Components:** Carefully remove all parts from the packaging. Lay them out on a clean, soft surface to prevent scratches.
2. **Identify Parts:** Match each component with the corresponding labels in the included parts list.
3. **Assemble Frame:** Begin by attaching the side panels to the base and top panels using the provided screws and dowels. Ensure all connections are snug.
4. **Install Shelves:** Insert the 7 shelf panels into the designated slots on the side panels. Secure them with screws as indicated in the diagrams. Ensure the raised edges of the shelves are facing upwards to prevent items from sliding off.
5. **Attach Hooks:** The two included hooks can be attached to either side of the shoe rack. Choose your preferred side and secure them with the provided screws.
6. **Install Anti-Tipping Kit:** Locate a suitable wall stud or use appropriate wall anchors. Attach the anti-tipping bracket to the top rear of the shoe rack and secure it to the wall using the strap and screws. This step is crucial for safety.
7. **Final Check:** Verify that all screws are tightened and the shoe rack is stable.

For detailed visual guidance, refer to the assembly diagrams provided in the separate instruction leaflet.

USAGE GUIDELINES

The VASAGLE 7-Tier Slim Shoe Rack is designed for efficient shoe storage and organization in various spaces.

- **Shoe Storage:** Utilize the seven shelves to store various types of footwear, including flats, hiking shoes, and boots. The 17 cm (6.7 inches) spacing between shelves accommodates most shoe sizes.
- **Space-Saving Design:** Its slim profile (30 x 26.4 x 110.4 cm) makes it suitable for narrow spaces such as entryways, hallways, or corners.
- **Integrated Hooks:** Use the two adjustable hooks to hang keys, small bags, umbrellas, or other accessories for quick access. The hooks can be positioned on either the left or right side.
- **Top Surface:** The top shelf can be used for decorative items, small plants, or frequently used personal items, keeping in mind its 5 kg weight limit.



Distance de 17 cm entre les étagères

Parfaitement adaptée aux bottines

Figure 3: Space-saving design for narrow areas.

2 crochets inclus

Peuvent être fixés sur les côtés pour suspendre des sacs et vos petits objets



Figure 4: Shelf spacing for various shoe types.




Figure 5: Adjustable hooks for accessories.

MAINTENANCE

To maintain the appearance and integrity of your shoe rack:

- **Cleaning:** Wipe surfaces with a soft, damp cloth. Avoid using harsh chemicals or abrasive cleaners, which can damage the finish.
- **Spills:** Promptly clean any spills to prevent staining or water damage to the engineered wood.
- **Inspection:** Periodically check all screws and fasteners to ensure they remain tight. Re-tighten if necessary.
- **Protection:** Avoid placing hot items directly on the surface. Use coasters or protective pads if needed.

Panneaux d'aggloméré de qualité



Facile à nettoyer



Résistant à l'usure

Figure 6: Cleaning and durability of the engineered wood surface.

TROUBLESHOOTING

If you encounter issues with your shoe rack, consider the following common solutions:

- **Instability/Wobbling:** Ensure the shoe rack is placed on a level surface. Check all assembly screws and re-tighten them. Confirm the anti-tipping kit is properly installed and secured to the wall.
- **Parts Not Fitting:** Double-check the assembly instructions and diagrams to ensure you are using the correct parts for each step and that they are oriented correctly. Do not force parts together.
- **Damaged Parts:** If any part arrived damaged, do not proceed with assembly. Contact customer support for replacement parts.

SPECIFICATIONS

Feature	Detail
Model Number	LBS200L01
Dimensions (L x W x H)	30 cm x 26.4 cm x 110.4 cm (11.8" x 10.4" x 43.5")
Weight	7.7 kg (17 lbs)
Material	Engineered Wood
Number of Shelves	7
Shelf Spacing	17 cm (6.7 inches)
Weight Capacity per Shelf	10 kg (22 lbs)
Top Surface Weight Capacity	5 kg (11 lbs)
Color	Greige Chiné
Special Features	Space-saving design, 2 adjustable hooks, anti-tipping kit included, raised shelf edges

Gain de place

Rentre dans tous les petits coins



Figure 7: Product dimensions and weight limits.

WARRANTY AND SUPPORT

For warranty information or customer support, please refer to the contact details provided with your purchase documentation or visit the official VASAGLE website. Keep your proof of purchase for any warranty claims.

If you have questions regarding assembly, missing parts, or product functionality, please contact our customer service team for prompt assistance.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question