

## Gosvor LiteVac 800-GS

# Gosvor LiteVac 800-GS Wireless Robotic Pool Cleaner User Manual

Model: LiteVac 800-GS

## 1. INTRODUCTION

---

Thank you for choosing the Gosvor LiteVac 800-GS Wireless Robotic Pool Cleaner. This device is designed to provide efficient and hassle-free cleaning for your pool. Please read this manual thoroughly before operating the cleaner to ensure proper use and maintenance.

The LiteVac 800-GS is a wireless robotic pool cleaner engineered for deep cleaning of pool bottoms. It effectively removes sand, leaves, and fine debris through powerful suction and smooth navigation, ensuring comprehensive coverage without missed spots.

## 2. IMPORTANT SAFETY INFORMATION

---

- Read all instructions carefully before use.
- Do not operate the cleaner when people or pets are in the pool.
- Ensure the charging port is dry before connecting the charger.
- Use only the original charger provided with the device.
- Keep the cleaner out of reach of children.
- Do not attempt to disassemble or repair the unit yourself. Contact customer support for assistance.
- Store the cleaner in a cool, dry place when not in use.

## 3. PACKAGE CONTENTS

---

Verify that all items are present in the package:

- 1x Gosvor LiteVac 800-GS Robotic Pool Cleaner
- 1x Charger
- 1x User Manual
- 1x Retrieval Hook
- 2x Brushes



**1x Gosvor LiteVac800**  
**1x Chargeur**  
**1x Manuel de l'utilisateur**  
**1x Crochet de Récupération**  
**2x Brosses**

Image: The Gosvor LiteVac 800-GS robotic pool cleaner with its included accessories: charger, user manual, retrieval hook, and two brushes, arranged neatly by the poolside.

## 4. PRODUCT OVERVIEW

---

The Gosvor LiteVac 800-GS features a hydrodynamic design for enhanced stability and cleaning speed. It is equipped with a powerful cleaning system to ensure thorough debris removal.

### Key Features:

- **Powerful Suction:** 20W suction power.
- **Dual Cleaning:** Equipped with 2 brushes and 2 suction ports.
- **Long Runtime:** Up to 90 minutes of operation on a single charge.
- **Fast Charging:** Fully charges in approximately 3 hours.
- **Automatic Parking:** Returns to the pool edge when cleaning is complete or battery is low.
- **Easy to Clean:** Features a large 2L debris basket and a 180µm filter for easy maintenance.
- **Wireless Operation:** Completely cord-free for convenience.



Image: The underside of the Gosvor LiteVac 800-GS, highlighting its powerful suction system with two brushes and two suction ports, effectively collecting debris.



Image: The Gosvor LiteVac 800-GS in water, showcasing its hydrodynamic design which improves cleaning stability, speed, and battery life.

## 5. SETUP

---

### 5.1 Charging the Cleaner

1. Ensure the cleaner is completely dry before charging.
2. Connect the charger to the charging port on the cleaner.
3. Plug the charger into a power outlet. The indicator light on the charger will show charging status.
4. Allow approximately 3 hours for a full charge.



Image: The Gosvor LiteVac 800-GS connected to its charger, illustrating the fast charging process which takes 3 hours for a full battery.

### 5.2 Preparing for First Use

1. Ensure the filter basket is clean and properly installed.

2. Check that the brushes are securely attached.

## 6. OPERATING THE CLEANER

### 6.1 Starting a Cleaning Cycle

1. Place the Gosvor LiteVac 800-GS into the pool. Ensure it sinks to the bottom.
2. Press the power button on the cleaner to start the cleaning cycle. The cleaner will begin its automatic cleaning path.
3. The cleaner will operate for up to 90 minutes, covering an area of up to 80 m<sup>2</sup>.



### Nettoyage Facile de la Piscine par Simple Pression d'un Bouton

Image: A user initiating the cleaning process by pressing the single power button on the Gosvor LiteVac 800-GS, highlighting its ease of use.

### 6.2 Automatic Parking

Once the cleaning cycle is complete or the battery level is low, the LiteVac 800-GS will automatically navigate to the edge of the pool for easy retrieval.



Image: Two Gosvor LiteVac 800-GS units demonstrating their automatic parking function, returning to the pool edge after completing their cleaning tasks.

## 6.3 Retrieving the Cleaner

1. Use the provided retrieval hook to gently pull the cleaner to the pool edge.
2. Lift the cleaner out of the water using its handle.
3. The cleaner features a quick water release system to drain water rapidly upon removal from the pool.



**Libération  
Rapide de l'eau**

Image: A woman retrieving the Gosvor LiteVac 800-GS from the pool, demonstrating the quick water release mechanism that allows for easy and fast drainage.

## 7. MAINTENANCE

Regular maintenance ensures optimal performance and extends the lifespan of your Gosvor LiteVac 800-GS.

### 7.1 Cleaning the Filter Basket

1. After each cleaning cycle, remove the filter basket from the cleaner.
2. Rinse the filter basket thoroughly with a garden hose to remove all collected debris.
3. Ensure the filter is completely clean before reinstalling it.



**Grand Panier pour un  
Nettoyage Ininterrompu**

Filtre de **180µm**

Panier de **2L**

Image: An internal view of the Gosvor LiteVac 800-GS, illustrating its large 2L debris basket and 180µm filter designed for efficient and uninterrupted cleaning.

## Facile à Nettoyer



Image: Demonstrates the easy cleaning process: rinsing the filter basket and the main unit of the cleaner with a hose to remove debris.

### 7.2 Storage

When not in use for extended periods, ensure the cleaner is fully charged, cleaned, and stored in a cool, dry place away from direct sunlight.

## 8. TROUBLESHOOTING

Problem	Possible Cause	Solution
Cleaner does not start	Low battery; Power button not pressed correctly	Charge the cleaner fully; Ensure a firm press on the power button.
Poor cleaning performance	Clogged filter basket; Worn brushes; Large debris blocking suction	Clean the filter basket; Inspect and replace brushes if necessary; Remove large debris manually.
Cleaner gets stuck or moves erratically	Obstruction in the pool; Uneven pool surface	Remove any obstacles; The cleaner is designed for flat-bottom pools.
Battery drains quickly	Battery not fully charged; Old battery; Operating in very dirty conditions	Ensure full charge before use; Contact support for battery replacement; Pre-clean heavily soiled pools.

## 9. SPECIFICATIONS

Feature	Detail
Model Name	LiteVac 800-GS

Feature	Detail
Color	Black and Red
Product Dimensions (L x W x H)	28L x 17.5W x 34.3H cm
Power Source	Battery Powered
Special Feature	Lightweight
Assembly Required	No
Battery Type	1 Lithium-ion (included)
Battery Capacity	28.08 Watt-hours
Charging Time	3 hours
Operating Time	Up to 90 minutes
Max Cleaning Area	80 m <sup>2</sup>
Filter Type	180µm filter with 2L basket
Suction Power	20W
Suitable Pool Types	Above-ground pools and flat-bottom pools (up to 80m <sup>2</sup> )

## Pour les Piscines Hors Sol et les Piscines à Fond Plat





Image: Illustrates the compatibility of the Gosvor LiteVac 800-GS with various pool types, specifically above-ground and flat-bottom pools up to 80m<sup>2</sup>, while indicating unsuitability for pools over 80m<sup>2</sup> or with inclined bottoms.

## 10. WARRANTY AND SUPPORT

The Gosvor LiteVac 800-GS comes with an extended warranty. For specific warranty terms and conditions, please refer to the warranty card included in your package or contact Gosvor customer support.

### Customer Support:

If you encounter any issues or have questions regarding your product, please contact Gosvor customer support through the retailer's platform or the official Gosvor website. Please have your model number (LiteVac 800-GS) and purchase details ready when contacting support.