

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- › [SoBuy](#) /
- › [SoBuy NSR13 Corner Shelf Stand Instruction Manual](#)

SoBuy NSR13

SoBuy NSR13 Corner Shelf Stand Instruction Manual

Model: NSR13 | Brand: SoBuy

1. INTRODUCTION

This SoBuy NSR13 Corner Shelf Stand is designed to provide efficient storage and display solutions for various rooms, including living rooms, bedrooms, home offices, kitchens, hallways, balconies, and bathrooms. Its 90-degree right-angle design optimizes unused corner spaces, offering both open shelving and enclosed drawer storage.



The SoBuy NSR13 Corner Shelf Stand integrated into a kitchen environment, demonstrating its use for storing glassware, canisters, and coffee accessories.

2. SAFETY INSTRUCTIONS

Please read and understand all safety instructions before assembling and using this product. Failure to follow these instructions may result in injury or product damage.

- Read all instructions carefully before assembly and use.
- Keep small parts away from children during assembly.
- Ensure all fasteners are securely tightened before use.
- Do not overload shelves or drawers. Refer to the specifications for weight limits (if available in physical manual).
- Use the unit on a level and stable surface to prevent tipping.
- If anti-tip hardware is included, ensure it is properly installed to prevent accidental tipping, especially in households with children or pets.

3. PACKAGE CONTENTS

Before beginning assembly, verify that all components listed below are present and undamaged. If any

parts are missing or damaged, contact SoBuy customer support immediately.

- Shelf panels (Engineered Wood)
- Metal frame components
- Drawers and drawer slides
- Hardware pack (screws, dowels, cam locks, etc.)
- Casters (wheels)
- Assembly Instruction Manual (this document)

4. SETUP AND ASSEMBLY

Assembly of the SoBuy NSR13 Corner Shelf Stand requires basic tools (e.g., screwdriver, hammer). Follow these steps carefully. It is recommended to assemble the unit on a soft, clean surface to prevent scratches.

4.1. Prepare for Assembly

Carefully unpack all components and lay them out on a clean, soft surface. Identify each part by comparing it to the parts list (if provided in the physical manual). Ensure you have all necessary tools.





This diagram illustrates the overall dimensions of the assembled unit, including the height of the open shelves and the drawers. Refer to these measurements during assembly to ensure correct orientation.

4.2. Assemble the Base and Casters

Attach the casters to the bottom panel of the unit using the provided screws. Ensure they are securely fastened. If locking casters are present, ensure they can be locked and unlocked smoothly.





The image displays the caster wheels attached to the base of the unit. Note the lever for locking and unlocking the wheels, allowing for both mobility and stability.

4.3. Construct the Main Frame

Connect the side panels and shelves using the provided hardware (e.g., cam locks, dowels, screws). Pay close attention to the orientation of each panel as indicated in the detailed assembly diagrams (refer to physical manual). For the upper open shelving section, attach the metal frame components to the wooden shelves and side panels.

4.4. Assemble and Install Drawers

Assemble each drawer according to the instructions, ensuring the bottom panel is securely inserted. Install the drawer slides onto the main unit and the drawers, making sure they are correctly aligned. Carefully

insert the assembled drawers into their respective slots.



The image shows one of the drawers pulled open, demonstrating its storage capacity and the smooth operation of the drawer slides. Ensure drawer slides are properly aligned during installation.

4.5. Final Checks

Once assembled, gently move the unit to its desired location. Ensure all screws and fasteners are tight. If the unit includes anti-tip hardware, install it according to the separate instructions provided to secure the unit to a wall.

5. OPERATING AND USAGE

The SoBuy NSR13 Corner Shelf Stand is designed for versatile storage and display. Utilize the open shelves for decorative items, books, or frequently accessed kitchenware. The drawers provide concealed storage for various items.

- **Mobility:** To move the unit, unlock the casters. To secure it in place, lock the casters by pressing down on the lever on each wheel.
- **Weight Distribution:** Distribute weight evenly across shelves and drawers. Avoid placing excessively heavy items on the top shelves to maintain stability and prevent tipping.
- **Corner Placement:** Position the unit snugly into a 90-degree corner for optimal stability and space

utilization.

6. MAINTENANCE

To maintain the appearance and longevity of your SoBuy NSR13 Corner Shelf Stand, follow these simple maintenance guidelines:

- **Cleaning:** Wipe surfaces with a soft, damp cloth. Avoid abrasive cleaners, harsh chemicals, or excessive moisture, which can damage the engineered wood finish.
- **Spills:** For spills, clean immediately to prevent staining or water damage, especially on engineered wood surfaces.
- **Fasteners:** Periodically check all screws and fasteners and tighten if necessary to ensure the unit remains stable and secure.
- **Environment:** Avoid prolonged exposure to direct sunlight or extreme humidity, as these conditions can cause fading, warping, or other damage to the material.

7. TROUBLESHOOTING

If you encounter any issues with your SoBuy NSR13 Corner Shelf Stand, refer to the following troubleshooting tips:

- **Unit is wobbly:** Ensure all assembly screws are fully tightened. Verify the unit is on a level surface. Adjust casters if necessary to compensate for uneven floors.
- **Drawers do not slide smoothly:** Check that drawer slides are correctly installed and aligned. Ensure no obstructions are present in the drawer tracks. A small amount of silicone-based lubricant can be applied to the slides if needed.
- **Missing parts:** Review the package contents list and the assembly instructions carefully. If parts are genuinely missing, contact SoBuy customer support with your purchase details and the specific part numbers required.
- **Damage during assembly:** If a part is damaged during assembly, stop and contact customer support for replacement parts. Do not force damaged parts.

8. SPECIFICATIONS

Feature	Detail
Model	NSR13
Brand	SoBuy
Material	Engineered Wood
Dimensions (D x W x H)	20.1 x 39.9 x 169.9 cm
Weight	18.86 kg
Special Features	Shelves and Drawers, Casters
Mounting Type	Floor Mount

9. WARRANTY AND SUPPORT

For warranty information, technical support, or to order replacement parts, please refer to your purchase documentation or contact SoBuy customer service directly. Contact details can typically be found on the SoBuy official website or your retailer's support page.