

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

- › [Vente-unique](#) /
- › [Vente-unique ADEZIO Sloped Roof Cabinet with 2 Doors and 2 Shelves - White and Natural Instruction Manual](#)

Vente-unique ADEZIO

Vente-unique ADEZIO Sloped Roof Cabinet Instruction Manual

Model: ADEZIO

IMPORTANT SAFETY INFORMATION

Warning: During assembly and use, hazards such as pinching or sharp edges may occur. Ensure the cabinet is securely installed and fixed under the sloped roof to prevent injuries or damage.

PRODUCT OVERVIEW

The Vente-unique ADEZIO sloped roof cabinet is designed for efficient storage in spaces with inclined ceilings. It features two doors and two shelves, offering versatile storage solutions. The cabinet is constructed from particle board and wood derivatives, with a light natural wood and white finish.



Image 1: The ADEZIO cabinet integrated into a room with a sloped ceiling, showcasing its design and storage capacity.

SETUP AND ASSEMBLY

This cabinet requires assembly. It is recommended to have at least two people for assembly. Ensure all components from the installation kit are present before starting.

- 1. Unpack Components:** Carefully unpack all parts and hardware. Verify against the included parts list (not provided in this manual, refer to your product packaging).
- 2. Identify Panels:** Separate the side panels, back panels, shelves, and door panels. Note the specific angles for the sloped roof design.
- 3. Assemble Frame:** Begin by attaching the main structural panels. Use the provided screws and dowels. Do not overtighten screws initially.
- 4. Install Shelves:** Insert the shelves into their designated positions. Ensure they are level and secure.
- 5. Attach Doors:** Mount the two doors using the hinges provided. Adjust hinges to ensure proper alignment and smooth operation.
- 6. Secure to Wall/Roof:** Due to its design for sloped roofs, it is crucial to securely fix the cabinet to the wall or roof structure using appropriate fasteners (not always included, depending on wall material). This prevents tipping and ensures stability.
- 7. Final Tightening:** Once fully assembled and positioned, carefully tighten all screws.




Image 2: Dimensional diagram of the cabinet, indicating key measurements for installation planning.




Image 3: Front and side dimensional view, highlighting the 143-degree angle for sloped roof integration.

OPERATING INSTRUCTIONS

The ADEZIO cabinet is designed for general storage.

- **Door Operation:** The cabinet features two swinging doors. Open and close them gently using the handles. Avoid forcing the doors to prevent damage to hinges or the cabinet structure.
- **Shelf Usage:** The internal shelves provide space for various items. Distribute weight evenly across the shelves to maintain stability. Avoid placing excessively heavy items on any single shelf.
- **Storage Capacity:** Utilize the open and closed compartments for organizing files, folders, books, or other household items. The design is particularly suitable for office or entryway storage.



Image 4: Detailed view of the cabinet's storage compartments, including the two doors and open shelves.

MAINTENANCE

Proper care will extend the life and appearance of your cabinet.

- **Cleaning:** Wipe surfaces with a soft, damp cloth. Avoid abrasive cleaners, harsh chemicals, or excessive moisture, which can damage the wood finish.
- **Dusting:** Regularly dust with a dry, soft cloth.
- **Spills:** Clean spills immediately to prevent staining or damage to the wood.
- **Sunlight Exposure:** Avoid prolonged direct sunlight exposure, which can cause fading or discoloration.
- **Temperature and Humidity:** Maintain a stable room temperature and humidity level to prevent warping or cracking of

the wood.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Cabinet feels wobbly or unstable.	Screws are loose; cabinet not properly secured to the wall/roof.	Tighten all assembly screws. Ensure the cabinet is securely anchored to the wall or sloped roof structure.
Doors do not close properly or are misaligned.	Hinges are loose or require adjustment.	Adjust the door hinges according to the hinge manufacturer's instructions (usually involves adjusting screws on the hinge). Tighten any loose hinge screws.
Scratches or minor surface damage.	Accidental impact or abrasion.	For minor scratches, use a wood repair marker or furniture polish matching the cabinet's finish. For deeper damage, professional repair may be needed.

SPECIFICATIONS

Brand:

Vente-unique

Model:

ADEZIO

Color:

White and Natural

Material:

Particle board, wood derivatives

Product Dimensions (L x W x H):

50 cm (D) x 182.6 cm (W) x 110 cm (H)

Item Weight:

69 Kilograms

Special Feature:

Suitable for sloped roofs

Recommended Uses:

File and folder storage, general organization

Included Components:

Installation kit

Door Style:

Swinging

Mounting Type:

Floor Mount (with wall/roof anchoring)

WARRANTY AND SUPPORT

For information regarding warranty coverage or to obtain support for your Vente-unique ADEZIO cabinet, please refer to the documentation included with your purchase or visit the official Vente-unique website.

Online Support: You can often find FAQs, assembly videos, and contact information on the manufacturer's website.

Contact Information: If direct assistance is required, please use the customer service contact details provided by Vente-unique at the time of purchase.

© 2025 Vente-unique. All rights reserved.