#### Manuals+

Q & A | Deep Search | Upload

#### manuals.plus /

- Tecno /
- > Tecno Phantom V Fold 2 User Manual

## Tecno Phantom V Fold 2 (AE10)

# **Tecno Phantom V Fold 2 User Manual**

Model: AE10 Brand: Tecno

## INTRODUCTION

This manual provides essential information for the safe and efficient use of your Tecno Phantom V Fold 2 smartphone. Please read it carefully before using the device to ensure optimal performance and longevity.



Image: The Tecno Phantom V Fold 2 in its unfolded state, showcasing the large internal display and the accompanying stylus. The device is shown in Karst Green.

# WHAT'S IN THE BOX

Verify that all items are present in the package:

- Tecno Phantom V Fold 2 Smartphone
- Power Adapter
- USB Cable
- SIM Tray Ejector
- Phone Case

Note: The Stylus Pen is sold separately.

# SETUP

## 1. Inserting SIM Card

Locate the SIM tray on the side of the device. Use the provided SIM tray ejector tool to open the tray. Insert your Nano-SIM cards into the designated slots. Ensure the SIM cards are correctly oriented. Close the tray securely.

## 2. Initial Charge

Before first use, fully charge the device using the provided Power Adapter and USB Cable. Connect the USB cable to the phone's charging port and the adapter to a power outlet. The device supports 70W fast charging and 15W wireless charging.



Image: The Tecno Phantom V Fold 2 being charged with a cable, illustrating the large battery capacity and fast charging capability.

## 3. Powering On/Off

To power on, press and hold the Power button until the Tecno logo appears. To power off, press and hold the Power button, then select "Power off" from the options.

# **OPERATING INSTRUCTIONS**

# Folding and Unfolding

The Tecno Phantom V Fold 2 features an aerospace-grade hinge designed for durability. Gently fold or unfold the device to switch between the cover screen and the main flexible AMOLED display. Avoid applying excessive force.



Image: The Tecno Phantom V Fold 2 in its folded state, showing the rear camera module and the cover screen.

# **Display Usage**

The device features a 7.85" 120Hz LTPO Flexible AMOLED main screen and a 6.42" 3D Curved Cover Screen. The main screen is ideal for multitasking and immersive viewing, while the cover screen provides convenient access for quick tasks.




Image: A visual comparison of the Tecno Phantom V Fold 2's 3D Curved Outer Screen and the Ultra-Flat Foldable Mirror Screen, highlighting their respective sizes.

## **Camera System**

The Phantom V Fold 2 is equipped with an Ultra-HD Penta Camera Setup:

- 50MP OIS Primary Camera
- 50MP Ultra Wide Camera
- 50MP Portrait Camera
- 32MP Front Camera (Main Screen)
- 32MP Front Camera (Cover Screen)

To take photos or videos, open the Camera application. Select your desired mode (Photo, Video, Portrait, etc.) and tap the shutter button.



# 70W Wired + 15W

Wireless Charging




Image: An illustration detailing the Ultra HD Penta Lens Camera System of the Tecno Phantom V Fold 2, showing the rear and front camera configurations.

## **Al Features and Phantom V Pen Support**

The device integrates advanced AI tools powered by TECNO AI, including Circle to Search, AI Recording Summary, and AI Image Cutout. These features enhance productivity and creativity. The device also supports the Phantom V Pen (sold separately) for precise input and drawing.



# **Strongest** Fold Ever\*

- Aerospace Grade Reliable Hinge Design
- Pushed to the limits 4,00,000+ times
- Corning Gorilla Glass Victus 2

\*Source : Techarc Nov, 2024 | Damage possible under extreme stress

## **Connectivity**

The Phantom V Fold 2 supports Wi-Fi 6 for faster wireless internet, NFC for seamless payments, and advanced GNSS for precise positioning.

## MAINTENANCE

- Keep the device clean using a soft, dry cloth. Avoid abrasive materials.
- Protect the screen from scratches and impacts. The device features Corning Gorilla Glass Victus 2, but additional screen protection is recommended.
- Avoid exposing the device to extreme temperatures, direct sunlight, or liquids.
- Do not attempt to disassemble or repair the device yourself. Refer to authorized service centers for any repairs.
- · Regularly back up your data to prevent loss.

## **TROUBLESHOOTING**

## **Device Not Powering On**

Ensure the battery is sufficiently charged. Connect the device to the charger for at least 30 minutes before attempting to power on again. If the issue persists, contact customer support.

## **Screen Flickering or Unresponsive**

Restart the device. If the issue occurs after physical impact or repeated folding/unfolding, it may indicate hardware damage. Contact customer support for assistance.

## **Poor Battery Life**

Close unused applications running in the background. Reduce screen brightness. Disable Wi-Fi, Bluetooth, or GPS when not in use. Check for software updates.

## **Connectivity Issues**

For Wi-Fi, ensure you are within range of a known network and the password is correct. For mobile data, check your SIM card insertion and network settings. Restarting the device can often resolve minor connectivity problems.

# **S**PECIFICATIONS

Feature	Detail
Model	Phantom V Fold 2 (AE10)
Operating System	Android 14.0
Main Display	7.85" 120Hz LTPO Flexible AMOLED
Cover Display	6.42" 3D Curved
Processor	Flagship 9000+ Chipset
RAM	12GB (with 12GB Extended RAM)

Storage	512GB
Rear Camera	50MP OIS Primary, 50MP Ultra Wide, 50MP Portrait
Front Camera	32MP (Main), 32MP (Cover)
Battery	5750mAh
Charging	70W Wired, 15W Wireless
Connectivity	Wi-Fi 6, NFC, USB, GNSS
Dimensions	14 x 15.9 x 0.6 cm
Weight	249 g
Color	Karst Green

## WARRANTY AND SUPPORT

Your Tecno Phantom V Fold 2 comes with a standard manufacturer's warranty. For detailed warranty terms and conditions, please refer to the warranty card included in your product packaging or visit the official Tecno website.

For technical support, service, or inquiries, please contact Tecno customer service. You can find contact information on the official Tecno website or through the support section of your device's settings.

Consider purchasing additional protection plans such as Screen Damage Protection or an Extended Warranty Plan for enhanced coverage, if available.

© 2024 Tecno. All rights reserved.

#### Related Documents - Phantom V Fold 2 (AE10)

TECNO PHANTOM V2 Fold 5G User Manual - Features, Installation, and FCC Information
Comprehensive user manual for the TECNO PHANTOM V2 Fold 5G, covering device features, SIM card installation, charging instructions, and essential FCC compliance information.

TECNO SPARK 30C SS User Manual	TECNO SPARK 30C 5G User Manual: Setup, Features, and FCC Information  Comprehensive user manual for the TECNO SPARK 30C 5G smartphone, covering setup, SIM/SD card installation, charging, and FCC compliance information. Learn about your device's features and specifications.
Samsun to tasse  FIXT  Samsung Calculary Fold Teardown  Tasses of the same Calculary and the same and	Samsung Galaxy Fold Teardown: A Detailed Analysis of Durability and Components  Explore the Samsung Galaxy Fold teardown by iFixit. This guide details the revised hardware, component analysis, and repairability of Samsung's innovative foldable smartphone.
Know your phone  1. Troots are in the control of th	TECNO KG5ks User Manual: Setup, Charging, and FCC Compliance Comprehensive guide for the TECNO KG5ks smartphone, covering initial setup, SIM/SD card installation, charging, and important FCC compliance information including SAR guidelines.
AND ADMINISTRATION OF THE PROPERTY OF THE PROP	TECNO CB7 CAMON 11S User Manual User manual for the TECNO CB7 CAMON 11S mobile phone, covering its purpose, package contents, basic operation, official information, warranty, and usage guidelines.
TECNO BD4 User Manual	TECNO BD4 User Manual - Guide and Specifications Comprehensive user manual for the TECNO BD4 smartphone, detailing setup, operation, technical specifications, and regulatory compliance information including FCC and SAR guidelines.