

## FELTECHELECTR 1688AV3GWSQW213R2221P

# FELTECHELECTR 24pcs Disposable Paper Snack Boxes Instruction Manual

Model: 1688AV3GWSQW213R2221P


## 1. INTRODUCTION

This instruction manual provides essential information for the proper use and handling of your FELTECHELECTR 24pcs Disposable Paper Snack Boxes. These containers are designed for serving various snacks, including French fries, onion rings, and crackers, in a convenient and hygienic manner. Please read this manual thoroughly to ensure optimal performance and satisfaction.

## 2. PRODUCT OVERVIEW

The FELTECHELECTR Disposable Paper Snack Boxes are crafted from durable paperboard, featuring a greaseproof lining to prevent oil stains. They are designed for single-use convenience and are recyclable, contributing to environmental sustainability.

- **Quantity:** 24 individual snack boxes.
- **Material:** High-quality paperboard with a grease-resistant interior.
- **Design:** Stackable for easy storage and transport.
- **Purpose:** Ideal for serving fried foods and other dry snacks at parties, events, or casual dining.



*Figure 2.1: A set of empty FELTECHELECTR disposable paper snack boxes, showcasing their design and quantity.*

### 3. SETUP AND PREPARATION

---

These snack boxes are designed for quick and easy preparation. They arrive pre-folded and require minimal setup before use.

1. **Unpack:** Carefully remove the stack of snack boxes from their packaging.
2. **Unfold:** Gently press the sides of each box to expand it into its intended cup shape. The design allows for easy unfolding.
3. **Inspect:** Before filling, quickly inspect each box to ensure it is fully formed and free from any damage.



*Figure 3.1: Demonstrating how to hold and prepare an empty snack box for filling.*



*Figure 3.2: The snack box is ready to be filled with items like fried chicken or fries.*

#### **4. OPERATING INSTRUCTIONS**

---

These snack boxes are designed for serving a variety of dry and semi-dry foods. Follow these guidelines for optimal use:

1. **Fill with Snacks:** Place your desired snacks, such as French fries, onion rings, chicken tenders, or crackers, into the unfolded box.
2. **Avoid Liquids:** While the boxes have a greaseproof lining, they are not designed for liquids or excessively wet foods. Avoid filling with soups, sauces, or items that could saturate the paperboard.
3. **Serving:** The sturdy design allows guests to comfortably hold and carry their snacks.



*Figure 4.1: A snack box filled with French fries, ready for serving alongside other fried foods.*



*Figure 4.2: The snack box is suitable for individual portions of fries with meals.*



Figure 4.3: Snack boxes used for individual servings at a gathering or party.

## 5. MAINTENANCE AND DISPOSAL

These disposable snack boxes require no maintenance. After use, they should be disposed of responsibly.

- **Single Use:** These containers are designed for single use only. Do not wash and reuse.
- **Disposal:** The paperboard material is recyclable. Please dispose of used boxes in a designated recycling bin where facilities exist. If recycling is not available, dispose of them in general waste.

## 6. TROUBLESHOOTING

Given the simple nature of this product, extensive troubleshooting is generally not required. However, consider the following points:

- **Box Not Forming Correctly:** Ensure the box is fully unfolded by gently pressing the bottom and sides into shape.
- **Leakage:** These boxes are designed with a greaseproof lining for fried foods. They are not intended for liquids or very wet items. If leakage occurs, it may be due to excessive moisture content of the food.
- **Stability Issues:** Ensure the box is placed on a flat, stable surface when filled, especially if carrying. The design is sturdy for handheld use, but extreme tilting with heavy contents may cause spills.

## 7. SPECIFICATIONS

<b>Brand</b>	FELTECHELECTR
<b>Model Number</b>	1688AV3GWSQW213R2221P
<b>Material</b>	Paperboard
<b>Color</b>	White
<b>Product Dimensions (L x W x H)</b>	4.33 x 3.94 x 1.97 inches (11 x 10 x 5 cm)
<b>Item Weight</b>	4 ounces (for the set of 24)




Figure 7.1: Detailed dimensions of the FELTECHELECTR disposable paper snack box.

## 8. WARRANTY AND SUPPORT

As a disposable product, these paper snack boxes do not come with a traditional warranty. However, if you encounter any issues or have questions regarding the product, please contact FELTECHELECTR customer support through the retailer's platform where the purchase was made. Please provide your order details for assistance.

For further information or inquiries, please visit the official FELTECHELECTR store page on Amazon: [FELTECHELECTR Store](#)

