

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

> [VGR](#) /

> [VGR Professional Hair Clipper and Trimmer Set \(Models V-003 and V-906\) Instruction Manual](#)

VGR VGR-003+906

VGR Professional Hair Clipper and Trimmer Set (Models V-003 and V-906) Instruction Manual

Model: VGR-003+906

1. INTRODUCTION

This manual provides detailed instructions for the safe and effective use of your VGR Professional Hair Clipper (Model V-003) and T-Blade Trimmer (Model V-906) set. Please read all instructions carefully before initial use and retain this manual for future reference.

2. SAFETY INFORMATION

- Do not use this product on infants.
- Keep the devices away from water sources and do not immerse them in water.
- Follow all recommended cleaning and maintenance procedures as outlined in this manual.
- Avoid direct contact of blades with skin and eyes.
- Do not use the devices while they are charging.
- Ensure the devices are fully dry before charging or use.
- Keep out of reach of children.

3. PACKAGE CONTENTS

Verify that all items listed below are included in your package:



Image: The VGR Professional Hair Clipper and Trimmer Set, including both devices and all accompanying accessories, laid out for inspection.

- 1 x VGR 003 Professional Hair Clipper
- 1 x VGR 906 T-Blade Trimmer
- 6 x Guide Combs for Clipper (1.5mm, 3mm, 4.5mm, 6mm, 9mm, 12mm)
- 3 x Limiting Combs for Trimmer (1mm, 2mm, 3mm)
- 2 x USB Charging Cables
- 2 x Blade Protective Caps
- 2 x Cleaning Brushes
- 2 x Lubricant Oil Bottles
- 1 x Hair Comb
- 1 x Hair Cutting Cape

4. PRODUCT OVERVIEW AND FEATURES

4.1 VGR 003 Professional Hair Clipper



TAPER LEVER

Adjustable taper control cutting length



SHARPER AND MORE DURABLE

Stainless blade, friction between blades will make themselves sharper. Have a longer service life.



LONGER WORK TIME

Rechargeable Li-ion battery 5V 2500mAh



LED DISPLAY

The LED display show the power left status

Image: The VGR 003 Hair Clipper, illustrating its adjustable taper lever, durable blades, long work time, and LED display.

- **Blades:** Equipped with ceramic and powder metallurgy blades for long-lasting sharpness and reduced heat.
- **Motor:** Powerful motor with two speed adjustments, reaching up to 9000 RPM.
- **Taper Lever:** Adjustable taper lever allows for 5 cutting lengths, from 0.5mm to 2.5mm, without guide combs.
- **Battery:** 2500mAh battery provides up to 250 minutes of continuous use on a 3-hour charge.
- **Display:** Intuitive LED display shows real-time power level.
- **Charging:** USB charging for corded or cordless operation.

4.2 VGR 906 T-Blade Trimmer



CERAMIC BLADE

3 attachment guards for superior comfort and cut quality.



SHARPER AND MORE DURABLE

Stainless blade, friction between blades will make themselves sharper. Have a longer service life.



LONGER WORK TIME

Rechargeable Li-ion battery 5V 2000mAh



LED DISPLAY

The LED display show the power left status

Image: The VGR 906 T-Blade Trimmer, illustrating its DLC-coated blades, long work time, and LED display.

- **Blades:** Features DLC-coated T-blades with a zero-gap design for ultra-fine trimming and sharp lines.
- **Motor:** High-performance motor reaching 9000 RPM for smooth and delicate grooming.
- **Battery:** 2000mAh battery provides up to 240 minutes of continuous use on a 2.5-hour charge.
- **Display:** Intuitive LED display shows real-time power level.
- **Charging:** USB charging for corded or cordless operation.

5. CHARGING INSTRUCTIONS

5.1 Initial Charge

Before first use, fully charge both the hair clipper and trimmer. This typically takes 3 hours for the clipper and 2.5 hours for the trimmer.



Ceramic and powder metallurgical blade

3 Hours

Charge Time

250 Mins

Work Time



Image: The VGR 003 Clipper connected via USB for charging, indicating a 3-hour charge time for 250 minutes of work time.



DLC coating blade

2.5 Hours

Charge Time

240 Mins

Work Time



Image: The VGR 906 Trimmer connected via USB for charging, indicating a 2.5-hour charge time for 240 minutes of work time.

5.2 Charging Procedure

1. Ensure the device is turned off.
2. Insert the small end of the USB charging cable into the charging port on the bottom of the clipper/trimmer.
3. Connect the larger end of the USB cable to a compatible USB power adapter (not included) or a USB port on a computer.
4. The LED display will indicate the charging status. Once fully charged, the display will show 100% or a full battery icon.
5. Disconnect the device from the charger once charging is complete.

6. OPERATING INSTRUCTIONS

6.1 Attaching and Removing Guide Combs

1. **To Attach:** Align the guide comb with the blade and push it firmly until it clicks into place. Ensure it is securely fastened.
2. **To Remove:** Gently pull the guide comb upwards from the blade assembly.

6.2 Adjusting the Taper Lever (VGR 003 Clipper Only)

The VGR 003 Clipper features an adjustable taper lever on the side. This lever allows you to change the cutting length of the blade without attaching a guide comb, offering fine adjustments from 0.5mm to 2.5mm. Move the lever up for a shorter cut and down for a longer cut.

6.3 Powering On/Off

Press the power button located on the device to turn it on or off. The LED display will illuminate when the device is powered on.

6.4 Basic Hair Cutting and Trimming

- Ensure hair is clean and dry before cutting.
- Select the desired guide comb for the VGR 003 Clipper or use the taper lever for precise length adjustments. For the VGR 906 Trimmer, select a limiting comb for detailed work or use without a comb for zero-gap trimming.
- Hold the device firmly and move it against the direction of hair growth for an even cut.
- For detailed trimming with the VGR 906, use light pressure and short, controlled strokes.
- Regularly clear accumulated hair from the blades during use to maintain performance.

7. MAINTENANCE

7.1 Cleaning the Blades

1. Turn off the device and disconnect it from any power source.
2. Use the provided cleaning brush to remove loose hair from the blades and the area around them.
3. For a more thorough cleaning, the blades can be carefully detached (refer to specific blade removal instructions if provided in a separate diagram or video, otherwise proceed with caution). Rinse the blades under running water, ensuring the main body of the device does not get wet.
4. Allow blades to air dry completely before reattaching or lubricating.

7.2 Lubrication

After each cleaning or approximately every few uses, apply a small drop of the provided lubricant oil to the blades. Turn on the device for a few seconds to distribute the oil evenly. This helps maintain blade sharpness and smooth operation.

7.3 Storage

Store the devices in a cool, dry place, away from direct sunlight and moisture. Use the blade protective caps to prevent damage to the blades when not in use.

8. TROUBLESHOOTING

Problem	Possible Cause	Solution
Device does not turn on	Low battery; Device not charged	Charge the device fully.

Problem	Possible Cause	Solution
Blades pull hair or cut poorly	Blades are dull; Blades are dirty; Insufficient lubrication	Clean and lubricate the blades. If problem persists, blades may need replacement.
Device runs slowly	Low battery; Blades are dirty or clogged	Charge the device. Clean the blades thoroughly.
Excessive noise or vibration	Blades are misaligned; Foreign object in blades	Turn off and inspect blades for foreign objects. Ensure blades are properly aligned.

9. SPECIFICATIONS

Feature	VGR 003 Hair Clipper	VGR 906 T-Blade Trimmer
Model Number	VGR-003	VGR-906
Blade Material	Ceramic and Powder Metallurgy	DLC-Coated
Motor Speed	Up to 9000 RPM (2 speeds)	Up to 9000 RPM
Battery Capacity	2500mAh	2000mAh
Charging Time	3 Hours	2.5 Hours
Operating Time	250 Minutes	240 Minutes
Power Source	Battery Powered (USB Rechargeable)	
Item Weight	560 Grams (combined, approximate)	
Package Dimensions	11.38 x 9.76 x 3.54 inches	

10. WARRANTY AND SUPPORT

VGR products are designed for quality and performance. This product is covered by a **1-Year Warranty** from the date of purchase. For any inquiries, technical assistance, or warranty claims, please contact VGR customer support. We offer **24-hour support** to assist you with any issues.

Please refer to the contact information provided with your purchase or visit the official VGR website for support details.

	<p>VGR V-085 Professional Hair Trimmer Manual and Safety Instructions</p> <p>This document provides comprehensive safety instructions, components list, usage guidelines, cleaning and maintenance procedures, and technical specifications for the VGR V-085 Professional Hair Trimmer.</p>
	<p>VGR V-906 Professional Hair Trimmer User Manual</p> <p>Comprehensive user manual for the VGR V-906 electric hair trimmer, detailing features, operation, charging, maintenance, and troubleshooting for professional and home grooming.</p>
	<p>VGR V-282 Professional Hair Clipper User Manual and Specifications</p> <p>Comprehensive user manual for the VGR V-282 Voyager Professional Hair Clipper. Includes detailed information on components, safety instructions, usage, charging, maintenance, technical features, and disposal guidelines.</p>
	<p>VGR V-990 Cordless Hair Trimmer User Guide</p> <p>Comprehensive guide to using the VGR V-990 professional cordless hair trimmer, featuring 8000RPM, barber-grade performance, and easy hair cutting for men.</p>
	<p>VGR V-9821 Professional Hair Trimmer User Manual</p> <p>Comprehensive user guide for the VGR V-9821 Professional Hair Trimmer, covering components, safety instructions, usage, USB charging, cleaning, maintenance, and technical specifications.</p>
	<p>VGR V-930 Professional Hair Trimmer User Manual with AFA Endorsement</p> <p>Comprehensive user manual for the VGR V-930 Professional Hair Trimmer, featuring AFA endorsement with player imagery. Covers safety instructions, components, usage, charging, cleaning, maintenance, and technical specifications for this personal grooming device.</p>