



[Manuals.plus](#) /

› [Tek Styz](#) /

› Tek Styz Portable Bluetooth Speaker G2 Pro TWS User Manual

## Tek Styz G2 Pro TWS

# Tek Styz Portable Bluetooth Speaker G2 Pro TWS User Manual

Model: G2 Pro TWS

## INTRODUCTION

---

Thank you for choosing the Tek Styz Portable Bluetooth Speaker G2 Pro TWS. This manual provides essential information for the safe and efficient use of your new speaker. Please read it thoroughly before operating the device and retain it for future reference.

## PRODUCT OVERVIEW

---

The Tek Styz Portable Bluetooth Speaker G2 Pro TWS is a versatile wireless speaker designed for various environments. It features Bluetooth 4.2 connectivity, multiple playback modes, and a built-in microphone for hands-free calls. The speaker is constructed with durable ABS plastic and a stylish fabric cover.

# STYLISH & PORTABLE

Use wherever you go, whenever you go!



Image: The Tek Styz Portable Bluetooth Speaker is designed for portability, allowing use in various settings such as a park.



**COMPATIBLE WITH  
ANY BLUETOOTH DEVICE!**

Image: The speaker is compatible with any Bluetooth-enabled device, including smartphones.

## SETUP

### 1. Charging the Speaker

Before first use, fully charge the speaker. Use the provided MicroUSB charging cable with a compatible USB adapter (not included). The speaker has an 800mAh battery capacity, providing up to 6+ hours of runtime on a full charge.

1. Locate the MicroUSB charging port on the back of the speaker.
2. Connect the MicroUSB cable to the speaker and the USB end to a power source.
3. The charging indicator light will illuminate during charging and turn off when fully charged.

### 2. Powering On/Off

Press and hold the power button (often labeled 'ON/OFF' or indicated by a power symbol) on the speaker to turn it on or off.

### 3. Bluetooth Pairing

The speaker uses Bluetooth 4.2 for fast and stable connections.

1. Ensure the speaker is powered on and in Bluetooth pairing mode (indicated by a flashing LED light).
2. On your device (e.g., smartphone, tablet), go to Bluetooth settings and enable Bluetooth.
3. Search for available devices. The speaker will appear as "Tek Styz Speaker" or a similar name.
4. Select the speaker from the list to pair. A confirmation sound will indicate successful pairing.



Image: Detailed view of the speaker's rear panel, highlighting the U disk interface, TF card slot, charging interface, and the power switch. The top panel shows buttons for pause/playback, volume control, and mode switching.

## OPERATING INSTRUCTIONS

### 1. Basic Controls

- **Play/Pause:** Press the Play/Pause button (often indicated by a triangle or two vertical bars) to start or pause audio playback.
- **Volume Adjustment:** Use the '+' button for volume up and '-' button for volume down. Long press for continuous adjustment, short press for incremental changes.
- **Next/Previous Track:** Short press the '+' button to skip to the next track. Short press the '-' button to go to the previous track.
- **Mode Switching:** Press the 'M' (Mode) button to cycle through available playback modes (Bluetooth, USB, TF card, FM radio, Line input).

### 2. Hands-Free Calling

The speaker includes a built-in microphone for hands-free calls when connected via Bluetooth to your smartphone.

- **Answer Call:** Press the Play/Pause button to answer an incoming call.
- **End Call:** Press the Play/Pause button again to end an active call.
- **Reject Call:** Press and hold the Play/Pause button to reject an incoming call.

### 3. Multiple Playback Modes

In addition to Bluetooth, the speaker supports several other audio sources:

- **USB Disk:** Insert a USB flash drive into the U disk interface to play audio files.
- **TF Card (MicroSD):** Insert a TF card into the TF card slot to play audio files.
- **FM Radio:** Switch to FM mode to listen to local radio stations. The speaker will automatically scan and save available stations.
- **Line Input (AUX):** Connect an external audio device using a 3.5mm audio cable (not included) to the AUX port.

### 4. True Wireless Stereo (TWS) Pairing

You can pair two Tek Styz G2 Pro TWS speakers together for a stereo surround sound experience.

1. Ensure both speakers are powered off.
2. Turn on both speakers. They will enter Bluetooth pairing mode.
3. On one of the speakers, double-press the 'M' (Mode) button. You will hear a tone indicating TWS pairing mode.
4. The speakers will automatically connect to each other. A confirmation sound will indicate successful TWS pairing.
5. Once paired, connect your device to one of the speakers via Bluetooth as described in the 'Bluetooth Pairing' section. Audio will now play in stereo through both speakers.

# MULTIPLE COLOR OPTIONS!




Image: The speaker is available in multiple color options, and two units can be connected for a stereo sound experience.

## MAINTENANCE

---

Proper care ensures the longevity of your speaker.

- **Cleaning:** Use a soft, dry cloth to wipe the speaker's surface. Do not use abrasive cleaners, alcohol, or chemical solvents, as these may damage the finish.
- **Storage:** Store the speaker in a cool, dry place away from direct sunlight and extreme temperatures.
- **Water Resistance:** The speaker is not waterproof. Avoid exposure to water or excessive moisture.
- **Battery Care:** To maintain battery health, avoid fully discharging the battery frequently. Charge the speaker regularly, even if not in use for extended periods.

## TROUBLESHOOTING

---

Problem	Possible Cause	Solution
Speaker does not turn on.	Low battery.	Charge the speaker fully.
Cannot pair via Bluetooth.	Speaker not in pairing mode; device Bluetooth off; too far apart.	Ensure speaker is in pairing mode. Turn on device Bluetooth. Move devices closer (within 10 meters). Forget previous pairings on your device and try again.
No sound.	Volume too low; incorrect mode; device not playing.	Increase speaker and device volume. Ensure correct playback mode is selected. Check if audio is playing on your connected device.
Poor sound quality.	Interference; low battery; distance.	Move speaker closer to the device. Charge the speaker. Avoid obstacles between speaker and device.
TWS pairing fails.	Incorrect pairing procedure.	Ensure both speakers are powered off before starting TWS pairing. Follow TWS pairing steps precisely.

## SPECIFICATIONS

- **Brand:** Tek Styz
- **Model:** G2 Pro TWS
- **Wireless Communication Technology:** Bluetooth 4.2
- **Speaker Maximum Output Power:** 3 Watts
- **Frequency Response:** 48000 KHz
- **Impedance:** 4 Ohms
- **Battery Capacity:** 800mAh (up to 6+ hours playtime)
- **Charging Interface:** MicroUSB
- **Compatible Devices:** Android, HTC U23, iOS, Mac, Windows (Bluetooth-enabled devices)
- **Material:** ABS Plastic, Fabric
- **Product Dimensions:** 4.5 x 1.6 x 3 inches
- **Item Weight:** 4 ounces
- **Special Features:** Built-in Microphone, Multiple Playback Modes (Bluetooth, USB, TF Card, FM, Line-in), TWS Pairing

# UNIVERSAL MINI-SPEAKER

## Use with Multiple Devices and Items



Bluetooth 4.2



Handfree  
phone call



TF card



FM Radio



ABS+Fabric



Image: Visual representation of the speaker's universal features, including Bluetooth 4.2, hands-free calling, TF card support, FM radio, and durable ABS+Fabric construction.

## WARRANTY INFORMATION

Tek Styz products are covered by a limited warranty against manufacturing defects. For specific warranty terms and conditions, please refer to the documentation provided with your purchase or visit the official Tek Styz website. Keep your proof of purchase for warranty claims.

## CUSTOMER SUPPORT

If you encounter any issues or have questions regarding your Tek Styz Portable Bluetooth Speaker G2 Pro TWS, please contact our customer support team. You can typically find contact information on the manufacturer's website or through your retailer.

- **Online Support:** Visit the Tek Styz official website for FAQs and support resources.
- **Email Support:** Refer to your product packaging or the official website for an email contact address.