

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

> [uijino](#) /

> [uijino QP6552/90 USB Charger Instruction Manual for Philips Norelco OneBlade 360 Pro Trimmer](#)

uijino UJI-FLP-6552

uijino QP6552/90 USB Charger Instruction Manual

For Philips Norelco OneBlade 360 Pro Electric Beard Trimmer (Model QP6552/90)

1. PRODUCT OVERVIEW

This document provides instructions for the uijino QP6552/90 USB charger, designed as a replacement and compatible power solution for the Philips Norelco OneBlade 360 Pro electric beard trimmer. It offers a convenient and reliable way to charge your device using various USB power sources.



Image: The uijino QP6552/90 USB charger cable connected to a Philips Norelco OneBlade 360 Pro trimmer, illustrating compatibility.

2. COMPATIBLE MODELS

This charger cord is specifically designed for the Philips Norelco OneBlade 360 Pro face + body electric beard trimmer, latest version **QP6552/90**.



Image: A Philips Norelco OneBlade 360 Pro trimmer, indicating its compatibility with the QP6552/90 model.

3. IMPORTANT COMPATIBILITY NOTES

This is a **5V USB charging cable**. It is **NOT** compatible with 15V, 4.3V, or 8V chargers. Do not attempt to use this charger with models requiring different voltage specifications.

Incompatible Models:

- QP2520
- QP2630
- HQ8505
- HQ850
- HQ840
- QP6510
- QP6520



Image: A visual guide to plug types, highlighting the correct 5V plug and incompatible 4.3V, 8V, and 15V plugs.

4. FEATURES

- **Input:** AC 5V USB Type-A
- **Output:** DC 5V 1A 5W (maximum) 2-prong plug
- **Power Cord Length:** 3.3ft (1 meter)
- **Certifications:** Certified by FCC, CE, ETL, RoHS, ensuring safety and quality standards.
- **Included:** 1 cleaning brush for maintenance.



Image: A visual representation of the charger's USB Type-A input, 2-prong output, and 3.3ft cable length.

5. SETUP

Connecting the Charger

1. Ensure your Philips Norelco OneBlade 360 Pro trimmer (QP6552/90) is turned off.
2. Insert the 2-prong end of the uijino charger cable into the charging port of your trimmer.
3. Connect the USB Type-A end of the charger cable to a compatible 5V USB power source. This can include:
 - A computer or laptop USB port.
 - A power bank.
 - A USB wall adapter (e.g., a phone charger adapter).
4. Verify that the connection is secure.



Image: Examples of connecting the charger to various USB power sources: a wall adapter, a power bank, and a laptop.



Image: A Philips Norelco OneBlade trimmer charging from a wall outlet via the USB cable, emphasizing portability.

6. OPERATING INSTRUCTIONS

Charging Your Device

1. After connecting the charger as described in the Setup section, your Philips Norelco OneBlade 360 Pro trimmer should begin charging.
2. Refer to your trimmer's display or indicator lights to confirm that it is receiving power and charging correctly.
3. Once fully charged, disconnect the charger from both the power source and the trimmer.



Image: A Philips Norelco OneBlade trimmer being charged by connecting the USB cable to a laptop.

7. MAINTENANCE

Cleaning the Charger

- Ensure the charger is disconnected from all power sources before cleaning.
- Use the included cleaning brush or a soft, dry cloth to gently remove any dust or debris from the charger's connectors and cable.
- Do not use liquid cleaners or abrasive materials, as these can damage the charger.
- Store the charger in a clean, dry place when not in use.

8. SAFETY INFORMATION

The ujjino QP6552/90 USB charger is designed with safety in mind and is certified by multiple international standards:

- **FCC:** Federal Communications Commission compliance.
- **CE:** Conformité Européenne (European Conformity).
- **ETL:** Electrical Testing Laboratories certification.
- **RoHS:** Restriction of Hazardous Substances compliance.

Always use the charger in a dry environment. Avoid exposing the charger to water or excessive moisture. Do not attempt to modify or repair the charger yourself.



Image: The charger cable displayed alongside various safety certification logos, including CE, FCC, ETL, and RoHS.

9. TROUBLESHOOTING

Issue	Possible Cause	Solution
Trimmer not charging	Loose connection	Ensure both ends of the charger cable are securely plugged in.
Trimmer not charging	Incompatible power source	Verify the USB power source provides 5V output. Try a different USB port or adapter.

Issue	Possible Cause	Solution
Trimmer not charging	Trimmer issue	Test the charger with another compatible device if available, or consult your trimmer's manual.
Charger cable appears damaged	Physical damage	Discontinue use immediately and replace the charger.

10. SPECIFICATIONS

- **Model Number:** UJI-FLP-6552
- **Input:** AC 5V USB Type-A
- **Output:** DC 5V 1A 5W (max) 2-prong plug
- **Cable Length:** 3.3 ft / 1 m
- **Package Dimensions:** 4.41 x 1.81 x 0.91 inches
- **Item Weight:** 1.13 ounces
- **Manufacturer:** Shenzhenshiweijinchuangxinkejiyouxiangongsi

11. SUPPORT

For any questions or assistance regarding your uijino QP6552/90 USB charger, please contact our customer service. We are available to assist you and resolve any issues you may encounter.

Refer to your purchase platform for specific contact details or visit the [uijino Store on Amazon](#) for more information.