

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [Donner](#) /

› [Donner DED-300X Electronic Drum Set Instruction Manual](#)

## Donner DED-300X

# Donner DED-300X Electronic Drum Set Instruction Manual

Model: DED-300X

Brand: Donner

## INTRODUCTION

This manual provides comprehensive instructions for the setup, operation, maintenance, and troubleshooting of your Donner DED-300X Electronic Drum Set. Designed for drummers of all skill levels, the DED-300X offers an immersive and realistic drumming experience with advanced features and a professional configuration.

## KEY FEATURES

- Upgraded Sound Module:** Features 100 drum kits, over 900 sounds, and 50 demo songs. Includes a built-in mixer panel for simplified sound adjustments.
- Professional Setup:** Configured with 5 pads and 4 cymbals, including two 12" crash cymbals and two 10" Quiet-Mash pads for dynamic performance.
- Realistic Feedback:** Each tom drum includes edge-trigger functionality for authentic rim sounds.
- Customizable Sound Dynamics:** Allows adjustment of individual drum and cymbal volumes for realistic dynamic responses.
- Enhanced Playability and User Convenience:** Designed for all skill levels with additional configurations and user-friendly controls.
- Connectivity:** USB MIDI, Aux In, Headphone Out, Stereo Line Outs. Bluetooth connectivity for external devices.
- Learning Support:** Compatible with the DONNER PLAY app and other learning resources.

## SETUP AND ASSEMBLY

The Donner DED-300X Electronic Drum Set is designed for straightforward assembly. Follow these general steps for initial setup:

1. **Unpacking:** Carefully remove all components from the packaging. Ensure all parts listed in the packing list are present. The packaging is designed to protect components during transit.



Figure 1: Components are securely packaged for protection.

2. **Rack System Assembly:** Assemble the sturdy rack system. The clamps and arms are designed for easy adjustment and secure positioning.



**ONE SET WITH TWO  
12" CRASH CYMBALS**



**12"**  
**CRASH CYMBALS**

Provide more playful and  
professional drumming experience

Figure 2: The fully assembled drum set, ready for use.

3. **Pad and Cymbal Attachment:** Attach the drum pads and cymbals to the rack system. Ensure they are securely fastened and positioned for comfortable playing.

# FULFILL YOUR PASSION OF DRUMMING



Figure 3: Attaching a drum pad to the rack system.

4. **Pedal Connection:** Connect the kick pedal and hi-hat pedal to their respective inputs on the sound module.

# UPGRADED SOUND MODULE

Delivers a substantial sound enhancement with precise control over the sound of each pad and cymbal.

**900+**

Drum Sounds

**100**

Drum Kits

**50**

Demo Songs



Figure 4: The kick drum pad and pedal assembly.

5. **Sound Module Connection:** Connect all drum pads and cymbals to the sound module using the provided cables. Ensure all connections are firm.

# DONNER DED-300X

1 10" SNARE PAD	2 10" TOM *2	3 8" TOM *1	4 12" RIDE CYMBAL
5 12" CRASH CYMBAL*2	6 10" HI-HAT CYMBAL	7 KICK DRUM	8 KICK PEDAL
9 HI-HAT PEDAL	10 SOUND MODULE	11 IPAD PLACEMENT SLOT	



Figure 5: The DED-300X sound module with its intuitive controls.

6. **Power On:** Connect the power adapter and turn on the drum set.

## OPERATING INSTRUCTIONS

### Sound Module Overview

The DED-300X sound module is the central control unit for your drum set. It features 100 drum kits, over 900 sounds, and 50 demo songs. The built-in mixer panel allows for easy sound adjustments.

## Selecting Drum Kits and Sounds

Use the navigation buttons and rotary knob on the sound module to browse and select from 100 preset drum kits. You can also access over 900 individual sounds to customize your kits.



Figure 6: Navigating through various drum kits on the sound module.

## Customizing Sounds

The sound module allows for extensive customization. You can adjust individual pad settings such as voice, pitch, pan, and velocity. Reverb and chorus effects can also be applied to tailor the sound to your preference.

## Practice Features

- **Demo Songs:** Utilize the 50 built-in demo songs to practice timing and musicality across different genres and tempos.
- **Metronome:** An essential tool for practice, the metronome function allows you to adjust rhythm, beat, sound, and volume.
- **Recording Function:** Quickly record your drum parts directly to the module for self-evaluation or developing new ideas.

## Connectivity

The DED-300X offers various connectivity options:

- **USB MIDI Out:** Connect to your computer for recording or using with digital audio workstations (DAWs).
- **Auxiliary Input:** Plug in external devices like computers or phones to play along with your favorite music.
- **Headphone Out:** For silent practice sessions.
- **Stereo Line Outs:** Connect to an amplifier or mixer for live performance or louder practice.
- **Bluetooth:** Connect wirelessly to your iPad or phone to play along with songs or use learning apps.



**UNLOCK YOUR DRUMMING POTENTIAL**

- 🥁 New Powerful Drum Module
- ♫ 900+ Professionally Drum Sample
- ♯♯ All Mesh Pads with Dual-Zone Feedback
- 🎧 Wireless Audio
- 🔕 Super-Quiet Mesh
- 🎲 Donner APP Learning Support

Figure 7: Tablet integration with the sound module for enhanced learning.


## FEEL AND PLAYABILITY

The DED-300X is engineered to provide a realistic and comfortable drumming experience.

### Mesh Heads

All drum pads feature quiet mesh heads with dual-zone capabilities, offering accurate and dynamic feedback.

The mesh provides a realistic rebound, mimicking the feel of acoustic drums.



### More Diverse Sound Choices

The DED-300X is equipped with an upgraded sound module to ensure that all drummers can enjoy a richer variety of drum sounds

### Cymbals

The set includes two 12" crash cymbals, a 10" hi-hat cymbal, and a 12" ride cymbal. All cymbals are chokeable, adding realism and expressiveness to your playing. The crash and ride cymbals are dual-zone, providing both bow and edge sounds.

# NEW PLACEMENT SLOT FOR IPAD

Designed for maximum convenience in both learning and drumming simultaneously.



Figure 9: The 12-inch crash cymbal, designed for dynamic performance.

## Kick Drum

The kick drum features a responsive mesh pad with a separate kick pedal, allowing for a natural feel and accommodating double bass pedals for future upgrades.

## SPECIFICATIONS

Feature	Detail
Model Name	DED-300X
Brand	Donner
Drum Kits	100
Sounds	900+
Demo Songs	50
Pads	5 (Mesh, Dual-Zone Snare, Single-Zone Toms with Edge Trigger)
Cymbals	4 (Two 12" Crash, One 10" Hi-Hat, One 12" Ride - all chokeable, Crash/Ride Dual-Zone)
Connectivity	USB MIDI, Aux In, Headphone Out, Stereo Line Outs, Bluetooth
Included Components	Drum set, sticks, DONNER PLAY app access
Item Weight	58.3 pounds
Package Dimensions	33 x 24 x 11 inches
Material	Mesh, Metal, Plastic
Color	Red

## MAINTENANCE

Regular maintenance ensures the longevity and optimal performance of your Donner DED-300X Electronic Drum Set.

- **Cleaning:** Wipe down drum pads, cymbals, and the sound module with a soft, dry cloth. For stubborn dirt, a slightly damp cloth can be used, followed by immediate drying. Avoid abrasive cleaners or solvents.
- **Cable Management:** Keep all cables neatly organized and untangled to prevent damage and ensure reliable connections. Avoid sharp bends or kinks in cables.
- **Pad Care:** While mesh heads are durable, avoid excessive force or sharp objects that could puncture them.
- **Storage:** If storing the drum set for an extended period, disassemble it carefully and store components in their original packaging or a protective case in a dry, temperature-controlled environment.
- **Firmware Updates:** Check the official Donner website periodically for any available firmware updates for the sound module to ensure optimal performance and access to new features.

## TROUBLESHOOTING

This section addresses common issues you might encounter with your DED-300X drum set. For more complex problems, please refer to the official Donner support resources.

### No Sound from Pads/Cymbals

- **Check Connections:** Ensure all drum pads and cymbals are securely connected to the correct input jacks on the sound module.
- **Volume Levels:** Verify that the master volume on the sound module is turned up, and individual pad/cymbal volumes are not set to zero.
- **Headphones/Speakers:** Confirm that your headphones or external speakers are properly connected and powered on. Test with another audio source if possible.
- **Power:** Ensure the sound module is receiving power and is turned on.

### Inconsistent Pad Response

- **Sensitivity Settings:** Adjust the sensitivity settings for individual pads in the sound module's menu. Refer to the "Operating Instructions" section for guidance on customization.
- **Pad Condition:** Inspect the mesh heads for any damage or excessive wear.

### Bluetooth Connectivity Issues

- **Pairing Mode:** Ensure the drum module is in Bluetooth pairing mode.
- **Device Proximity:** Keep your Bluetooth device (phone, tablet) close to the drum module during pairing.
- **Interference:** Minimize interference from other wireless devices.

## WARRANTY AND SUPPORT

Donner provides customer support for its products. For detailed warranty information and technical assistance, please visit the official Donner website or contact their customer service.

- **Protection Plans:** Extended protection plans may be available for purchase to cover your product beyond the standard warranty.
- **Customer Support:** For any inquiries or issues, refer to the customer support options provided by Donner.
- **Returns:** The product typically comes with a 30-day easy returns policy.