

[manuals.plus](#) /

› [Philips](#) /

› [Philips OneBlade Pro 360 QP6552-15 Beard and Body Trimmer Instruction Manual](#)

Philips QP6552/15

Philips OneBlade Pro 360 QP6552-15 Beard and Body Trimmer Instruction Manual

Model: QP6552/15 | Brand: Philips

INTRODUCTION

Welcome to the Philips OneBlade Pro 360 QP6552-15 instruction manual. This versatile grooming tool is designed for trimming, edging, and shaving any length of hair on both your face and body. Its unique OneBlade technology and 360-degree blade ensure a comfortable and efficient experience. Please read this manual carefully before first use to ensure safe and optimal performance of your device.

KEY FEATURES

- **Exclusive OneBlade Technology:** Designed for trimming, edging, and shaving any length of hair.
- **Innovative 360-Degree Blade:** Pivots in all directions to maintain constant contact with skin, ensuring comfort and control even in difficult areas.
- **Dual Protection System:** Features a glide coating and rounded tips for a comfortable shave that protects your skin.
- **20 Length Settings Adjustable Comb:** Easily select and lock in your preferred trim length from 0.4mm to 10mm.
- **Rechargeable Lithium-Ion Battery:** Provides 120 minutes of constant power after a 1-hour charge.
- **Durable Stainless Steel Blade:** Designed to last up to 4 months for optimal performance.
- **Blade Wear Indicator:** An icon on the blade alerts you when it's time for a replacement.
- **Skin Guard for Body Grooming:** Provides an extra layer of protection for sensitive areas.

WHAT'S IN THE BOX

Your Philips OneBlade Pro 360 QP6552-15 package includes the following items:

- Philips OneBlade Pro 360 Handle (Model QP6552/15)
- OneBlade 360 Blade (pre-attached or separate)
- Adjustable Precision Comb (with 20 length settings)

- Skin Guard for Body
- Charging Cable (USB-A)
- Travel Cap
- User Manual
- Travel Pouch/Case



Image: Philips OneBlade Pro 360 QP6552-15 with its various attachments and charging cable.

SETUP

- 1. Initial Charge:** Before first use, fully charge your OneBlade Pro 360. Connect the charging cable to the device and a USB power adapter (not included). The LED display will show the charging progress. A full charge takes approximately 1 hour and provides 120 minutes of use.
- 2. Attaching the Blade:** Align the blade with the handle and push it until you hear a click. To remove, press the release button and slide the blade off.
- 3. Attaching the Adjustable Comb:** For beard trimming, slide the adjustable comb onto the blade until it clicks into place. Rotate the dial to select your desired hair length.
- 4. Attaching the Skin Guard:** For body grooming, slide the skin guard onto the blade until it clicks into place. This provides an extra layer of protection for sensitive areas.



20 ajustes de longitud

El peine ajustable no se atasca,
ni siquiera en el pelo largo y grueso

Image: Attaching the adjustable precision comb to the OneBlade Pro 360.

Batería recargable de litio

ofrece 120 minutos de potencia constante tras 1 hora de carga



Image: The Philips OneBlade Pro 360 charging via its USB cable.

OPERATING INSTRUCTIONS

General Use

- Press the power button to turn the device on or off.
- The OneBlade can be used wet or dry, with or without foam.
- For best results, move the blade against the grain of your hair.

Trimming Your Beard

1. Attach the adjustable precision comb.
2. Select your desired trim length using the dial (0.4mm to 10mm).
3. Hold the OneBlade flat against your skin and move it against the direction of hair growth.

Para la



Afeita



Recorta



Perfila

Image: The Philips OneBlade Pro 360 used for trimming, shaving, and profiling facial hair.

Edging and Shaping

- Remove any comb attachments.
- Hold the blade flat against your skin and use the tip to create sharp lines and edges.
- The dual-sided blade allows for precise edging in both directions.

Shaving

- Remove any comb attachments.
- Hold the blade flat against your skin and move it in long strokes against the grain of your hair.
- The OneBlade does not shave as close as a traditional blade, ensuring comfort and preventing skin irritation.

Body Grooming

1. Attach the skin guard for sensitive areas.
2. Move the OneBlade against the direction of hair growth.
3. The skin guard helps prevent nicks and cuts on delicate skin.



Para el cuerpo

Coloca el protector para la piel
para obtener una capa de
protección adicional en las áreas

Image: Body grooming with the Philips OneBlade Pro 360, highlighting the skin protector.

ADJUSTABLE COMB SETTINGS

The precision comb offers 20 different length settings, allowing you to achieve your desired stubble or beard style. Rotate the dial on the comb to select a length from 0.4mm to 10mm. The settings are clearly marked for easy selection.



20 ajustes de longitud

**El peine ajustable no se atasca,
ni siquiera en el pelo largo y grueso**

Image: The adjustable comb with 20 length settings, preventing snagging even on long, thick hair.

BLADE REPLACEMENT

The Philips OneBlade Pro 360 blade is designed for long-lasting performance, typically up to 4 months with average use (based on 2 full shaves per week). To ensure optimal performance and hygiene, replace the blade when the wear indicator appears.

Replacing the Blade:

1. Turn off the device.
2. Press the release button on the back of the blade and slide it forward to detach it from the handle.
3. Align the new blade with the handle and push it until you hear a click.

Cuchilla de acero inoxidable

que dura hasta 4 meses de uso para mantener esa sensación de frescura.



Image: Replacing the stainless steel blade, which lasts up to 4 months.



Indicador de desgaste de la hoja

El ícono de expulsión te avisa cuando es hora de cambiar la cuchilla.



Image: The blade wear indicator, showing an icon that signals when it's time to change the blade.

SMART FEATURES: PHILIPS GROOMTRIBE APP

Enhance your grooming experience by connecting your Philips OneBlade Pro 360 to the Philips GroomTribe app (available for compatible models). The app offers personalized guidance and styling tips.

- **Style Mirror:** Preview different beard styles in real-time using your phone's camera.
- **Symmetry Check:** Get guidance to ensure your beard or mustache style is symmetrical.
- **Speed Guidance:** Receive feedback on your shaving motion speed for optimal results.
- **Body Grooming Tips:** Access tips for trimming below the neck.
- **Face Grooming Tips:** Discover advice for various face styles.

Your browser does not support the video tag.

Video: Demonstrating the Philips GroomTribe app features, including Style Mirror and Symmetry Check, for personalized grooming guidance.

CHARGING AND BATTERY

The Philips OneBlade Pro 360 is equipped with a powerful rechargeable Lithium-Ion battery. A full charge takes approximately 1 hour and provides up to 120 minutes of cordless grooming. The LED display on the

handle indicates the battery percentage, allowing you to monitor the charge level.



Image: The rechargeable lithium battery provides 120 minutes of power after a 1-hour charge.

MAINTENANCE AND CLEANING

- **After Each Use:** Rinse the blade and any attachments under warm running water.
- **Cleaning the Handle:** Wipe the handle with a damp cloth. Do not use abrasive cleaning agents or harsh chemicals.
- **Drying:** Allow all parts to air dry completely before reassembling or storing.
- **Storage:** Store the OneBlade Pro 360 in its travel pouch or a dry, safe place.

TROUBLESHOOTING

- **Device Not Turning On:** Ensure the device is fully charged. If the battery is low, connect it to the charger.
- **Poor Trimming/Shaving Performance:** Check if the blade is worn out (refer to the wear indicator) and replace it if necessary. Ensure the blade is clean and free of hair buildup.
- **Skin Irritation:** Always use the OneBlade against the grain of your hair. For sensitive areas, use the skin guard attachment. Ensure your skin is clean before use.

- **Charging Issues:** Verify that the charging cable is properly connected to both the device and a working USB power source.

SPECIFICATIONS

Feature	Detail
Model Number	QP6552/15
Brand	Philips
Manufacturer	Philips
Battery Type	Rechargeable Lithium-Ion
Run Time	Up to 120 minutes
Charging Time	1 hour for full charge
Blade Life	Up to 4 months (average use)
Adjustable Comb Settings	20 length settings (0.4mm - 10mm)
Wet & Dry Use	Yes
Item Weight	0.1 Kilograms

SAFETY INFORMATION

- Keep the appliance dry.
- Do not use the appliance if it is damaged.
- Keep out of reach of children.
- Do not use on irritated or broken skin.
- Always check the blade before use. Do not use a damaged or broken blade.
- For hygienic reasons, do not share your OneBlade with others.

Legal Disclaimer: Statements regarding dietary supplements have not been evaluated by the FDA and are not intended to diagnose, treat, cure, or prevent any disease or health condition.

WARRANTY AND SUPPORT

Your Philips OneBlade Pro 360 QP6552-15 comes with a manufacturer's warranty. Please refer to the warranty card included in your package for specific terms and conditions. For product support, troubleshooting, or to purchase replacement parts, please visit the official Philips website or contact their customer service.

- **Protection Plans:** Additional protection plans (2-Year, 3-Year) may be available for purchase.
- **Online Support:** Visit the [Philips Store on Amazon](#) for more information and support resources.

