

[Manuals.plus](#) /

> [YOWMOFT](#) /

> YOWMOFT Wireless Cat Water Fountain with UV Light (Model YMW03) - Instruction Manual

## YOWMOFT YMW03

# YOWMOFT Wireless Cat Water Fountain with UV Light

INSTRUCTION MANUAL - MODEL YMW03

## Product Overview

---

This manual provides instructions for the YOWMOFT Wireless Cat Water Fountain, Model YMW03. This 3-liter capacity pet water dispenser features a built-in UV light for water purification, a quiet pump, multiple watering modes, a motion sensor, and a double power source for flexible placement.

### Key Features:

- **Dual Water Source Protection:** Integrated UV light and vertical filtration system for hygienic water.
- **Double Wall Inner Design:** Facilitates easy cleaning and helps maintain water temperature.
- **Three Watering Modes:** Sensing, Regular, and Continuous water discharge options.
- **Ultra-Quiet Operation:** Pump operates at approximately 23dB.
- **Double Power Source:** Operates via Type-C cable or wirelessly with a rechargeable battery.



*Image: The YOWMOFT Wireless Cat Water Fountain, showcasing its sleek black design and included filters.*

## Setup Instructions

---

- Unpack Components:** Carefully remove all parts from the packaging. Ensure you have the main fountain body, inner water tank, pump, filter, and power cable.
- Clean Before First Use:** Wash the inner water tank and all removable parts (excluding the pump and main body with electronics) with mild soap and water. Rinse thoroughly.
- Install Filter:** Place one of the provided filters into its designated slot within the inner water tank. Ensure it is seated correctly.
- Assemble Inner Tank:** Insert the clean inner water tank into the main fountain body. The double-wall design allows for easy placement.
- Fill with Water:** Fill the inner tank with clean water up to the maximum fill line. Do not overfill. The capacity is 3 liters (101oz).
- Connect Power:** Connect the Type-C cable to the fountain and a suitable power adapter (not included) or ensure the internal battery is charged for wireless operation.
- Initial Operation:** Press the power button to turn on the fountain. The pump will begin circulating

water.

# Wireless Cat Water Fountain with UV Light

keeping the water hygienic and safe for your pets



*Image: The YOWMOFT Cat Water Fountain placed in a home environment, demonstrating its compact size.*

## Operating Instructions

The YOWMOFT Cat Water Fountain offers three distinct watering modes to suit your pet's needs and conserve energy.

- **Sensing Water Outlet (Motion Sensor Mode):**

When the motion sensor detects movement from a living body, the fountain will discharge water continuously. If no movement is detected for 2 minutes, the water flow will stop. This mode conserves power and ensures fresh water when needed.

- **Regular Water Discharge (Timed Mode):**

In this mode, the fountain will discharge water for 2 minutes every hour. This provides periodic hydration without constant flow.

- **Continuous Water Discharge:**

The water will flow continuously in this mode, providing a constant stream of fresh water.

To switch between modes, refer to the control panel on the fountain. The UV light operates internally to

purify the water and may not be visibly illuminated from the exterior.



*Image: Visual representation of the three watering modes: Timed Mode (3 min waterflow every hour), Continuous Mode (water flows continuously), and Sensor Mode (water runs when cats approach).*

# No More Mess When Drinking

The water dispenser set at a 20° angle, which helps prevent water from splashing out



*Image: A cat drinking from the fountain, illustrating the 20-degree angled design that helps prevent water from splashing out.*

## Maintenance

---

Regular maintenance ensures the longevity and hygienic operation of your YOWMOFT Cat Water Fountain.

1. **Daily Water Check:** Ensure the water level is sufficient. Refill as needed.
2. **Weekly Cleaning (Inner Tank):** The double-wall inner design allows for easy cleaning. Simply lift out the inner tank, empty any remaining water, and wash it with mild soap and water. Rinse thoroughly to remove all soap residue.
3. **Monthly Cleaning (Entire Unit):** Disassemble the fountain completely. Clean the pump according to its specific instructions (usually involves disassembling and cleaning the impeller). Clean the main body and all other components.
4. **Filter Replacement:** Replace the filter every 2-4 weeks, or more frequently if you have multiple pets or notice reduced water flow/quality. Rinse new filters before installation.
5. **UV Light Maintenance:** The UV light is designed for long-term use. If you suspect an issue, refer to the troubleshooting section or contact customer support.

# Double Wall Inner

Just take out the inner tank to get everything done



Image: Demonstration of the double-wall inner design, showing how to easily remove the inner tank for cleaning without disassembling the entire unit.

## Troubleshooting

Problem	Possible Cause	Solution
Fountain not turning on	No power, low battery, or power button not pressed.	Ensure Type-C cable is securely connected or battery is charged. Press the power button.
No water flow or weak flow	Low water level, clogged filter, dirty pump, or incorrect mode.	Refill water. Replace filter. Clean pump. Check selected watering mode.
Fountain is noisy	Low water level, dirty pump, or improper assembly.	Ensure water level is adequate. Clean the pump and impeller. Reassemble components correctly.

Problem	Possible Cause	Solution
UV light not visible	UV light operates internally.	The UV light is designed for internal water purification and may not emit visible light from the exterior. This is normal operation. Ensure the fountain is powered.
Motion sensor not activating	Obstruction, sensor dirty, or pet not close enough.	Ensure sensor is clean and unobstructed. Pet needs to be within sensor range. Consider using Timed or Continuous mode if preferred.

## Specifications

Feature	Detail
Brand	YOWMOFT
Model Number	YMW03
Capacity	3 Liters (101 oz)
Material	Acrylonitrile Butadiene Styrene (ABS)
Color	Black
Product Dimensions	20.3L x 19.1W x 20.3H Centimeters
Item Weight	998 g (2.2 Pounds)
Power Source	Battery Powered (Rechargeable) / Type-C Cable
Indoor/Outdoor Usage	Indoor
Noise Level	Approximately 23dB
Included Components	Cat Water Fountain (main unit, inner tank, pump, filter)

## Warranty and Support

For warranty information, technical support, or any product-related inquiries, please contact YOWMOFT customer service directly. Refer to the product packaging or the official YOWMOFT website for contact details.