

manuals.plus /

› [HUABAO](#) /

› [HUABAO Smart Karaoke Machine with 14-inch Tablet \(Model A116\) - Instruction Manual](#)

HUABAO A116

HUABAO Smart Karaoke Machine with 14-inch Tablet (Model A116)

User Instruction Manual

1. INTRODUCTION

Thank you for choosing the HUABAO Smart Karaoke Machine, Model A116. This portable karaoke system is designed to provide an immersive audio and entertainment experience with its 14-inch HD touchscreen, powerful sound, wireless microphones, and versatile connectivity options. This manual provides essential information for safe and optimal use of your device. Please read it thoroughly before operation and retain it for future reference.



Image 1.1: HUABAO Smart Karaoke Machine (Model A116) with its 14-inch display and two wireless microphones.

2. PRODUCT OVERVIEW

2.1 Package Contents

Ensure all items listed below are present in your package:

- 1 x Karaoke Speaker with Screen
- 2 x Wireless Microphones
- 1 x Remote Control
- 1 x AUX Cable
- 1 x USB Charging Cable
- 1 x Power Adapter

WHAT'S IN THE BOX



Image 2.1: All components included in the HUABAO Smart Karaoke Machine package.

2.2 Key Features

- **14-inch HD Touchscreen:** Integrated display for easy navigation and lyric display.
- **Rotatable Tablet:** Screen rotates 360° horizontally and 180° vertically for flexible viewing and storage.
- **Seven-Speaker System:** Includes super tweeter, tweeter, mid-range speakers, and subwoofer for rich sound.
- **Dual Wireless Microphones:** For duet performances and enhanced mobility.
- **Multiple Connectivity:** Bluetooth, Wi-Fi, HDMI, USB, TF card, AUX, OTG, earphone, and musical instrument jacks.
- **Pre-installed Apps:** Access to streaming services and karaoke apps via Wi-Fi.
- **Colorful LED Lights:** Dynamic light strip with adjustable modes and brightness.
- **Professional Sound Controls:** Independent adjustments for microphone volume, treble, bass, and various sound effects.
- **Long-lasting Battery:** 9000mAh battery for extended portable use.

Built-in 14" Large Touchscreen Tablet

The built-in HD large screen can be used to display song lyrics when karaoke or view videos on YouTube after connecting Wi-Fi.



Image 2.2: The 14-inch HD touchscreen interface.

360° & 180° Rotation Tablet

The large touchscreen is rotatable and it is convenient for you both in use and storage.



Image 2.3: Tablet rotation capabilities (180° vertical, 360° horizontal).

Unmatched Sound Quality with Super Bass

The excellent combination of sound units perfectly contributes to an ideal audio experience.



Image 2.4: Internal speaker configuration for optimal sound quality.

3. SETUP

3.1 Initial Charging

1. Connect the provided power adapter to the DC 12V input port on the back of the karaoke machine.
2. Plug the adapter into a standard wall outlet.
3. Allow the unit to charge fully before first use. The charging indicator will show the battery status.

3.2 Powering On/Off

- To power on, press and hold the Power button located on the control panel until the screen illuminates.
- To power off, press and hold the Power button until the shutdown prompt appears on the screen, then confirm.

3.3 Microphone Setup

1. Insert 2 AA batteries (not included) into each wireless microphone, observing polarity.
2. Turn on the microphones using their respective power switches.

3. The microphones should automatically pair with the karaoke machine. If not, refer to the troubleshooting section.

3.4 Network Connection (Wi-Fi)

1. On the 14-inch touchscreen, tap the 'Settings' icon.
2. Navigate to 'Wi-Fi' and turn it on.
3. Select your desired Wi-Fi network from the list and enter the password if prompted.
4. Once connected, the Wi-Fi icon will indicate a successful connection.

3.5 External Device Connections



Image 3.1: Overview of available connectivity options.

- **Bluetooth:** Activate Bluetooth on the karaoke machine via 'Settings' and pair with your smartphone or other Bluetooth-enabled devices.
- **HDMI:** Connect an HDMI cable from the machine's HDMI output to an HDMI input on a television or monitor for a larger display.
- **USB/TF Card:** Insert a USB flash drive or TF card into the designated ports to play media files.
- **AUX:** Use the provided AUX cable to connect external audio sources to the AUX input.
- **OTG:** Connect compatible USB devices via the OTG port.

- **Earphone/Instrument:** Use the dedicated jacks for private listening or connecting musical instruments.

Multi-Connection Options

The machine can easily connect to TVs via HDMI. Enjoy the fun of simultaneous display.




Image 3.2: Connecting the karaoke machine to a TV via HDMI.

4. OPERATING INSTRUCTIONS

4.1 Control Methods

The HUABAO Smart Karaoke Machine can be operated using three methods:

3 Ways to Operate

Three operate ways to meet your needs on different occasions.



Image 4.1: Three ways to operate the karaoke machine.

- **Touchscreen:** Directly interact with the 14-inch display for app navigation, song selection, and settings adjustments.
- **Control Panel:** Utilize the physical buttons and knobs on the top panel for precise audio adjustments and function control.
- **Remote Control:** Use the included remote for convenient operation from a distance.

4.2 Karaoke Functions and Apps

1. Ensure the machine is connected to Wi-Fi (see Section 3.4).
2. From the home screen, tap on pre-installed apps such as YouTube, Netflix, or other karaoke applications.
3. Browse and select your desired karaoke songs or videos. Lyrics will typically display on the 14-inch

screen.




Image 4.2: Accessing endless songs and videos via pre-installed apps.

4.3 Sound Adjustments

The control panel offers comprehensive sound customization:



Image 4.3: Detailed view of the control panel for customized audio experience.

- **Microphone Volume (Mic Vol):** Adjust the volume of the wireless microphones.
- **Instrument Volume (Inst Vol):** Control the volume of connected musical instruments.
- **Microphone Treble/Bass (Mic Treble/Bass):** Fine-tune the high and low frequencies of the microphone audio.
- **Microphone Echo (Mic Echo):** Add an echo effect to the microphone sound.
- **Music Treble/Bass (Music Treble/Bass):** Adjust the high and low frequencies of the background music.
- **Music Volume (Music Vol):** Control the overall volume of the music.
- **Sound Effects (DSP SFX, Mic SFX):** Select from various pre-set sound effects for music and microphone.
- **Vocal Removal:** Activate this feature to reduce or remove vocals from certain tracks.

Large Selection of Sound Effects

There are many different sound effects built into the device to choose from depending on your distinct needs.



Image 4.4: On-screen equalizer for advanced sound adjustments.

4.4 LED Light Control

The integrated LED light strip enhances the ambiance:

Colorful Light Strip Design

The beautiful light strip can be adjusted in color, mode, and brightness. This design adds more vibe to your karaoke parties and gatherings.



Image 4.5: Customizable LED light strip design.

- Use the 'LED Mode/On/Off' button on the control panel or remote to cycle through different light modes or turn them off.
- Adjust the 'LED Brightness' knob to control the intensity of the lights.

5. MAINTENANCE

5.1 Cleaning

- Always power off and unplug the device before cleaning.
- Use a soft, dry cloth to wipe the exterior surfaces.
- For the touchscreen, use a microfiber cloth specifically designed for electronics. Avoid abrasive cleaners or sprays directly on the screen.
- Do not use liquid cleaners directly on the speaker grilles or control panel.

5.2 Battery Care

- To prolong battery life, avoid fully discharging the battery frequently.
- Charge the unit regularly, even if not in use for extended periods (e.g., once every 3 months).

- Store the device in a cool, dry place away from direct sunlight and extreme temperatures.

5.3 Storage

- When storing, ensure the tablet is folded down to protect the screen.
- Keep the device in its original packaging or a protective case to prevent dust and damage.

6. TROUBLESHOOTING

If you encounter issues with your HUABAO Smart Karaoke Machine, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
No power	Battery depleted; Power adapter not connected.	Charge the unit using the provided adapter; Ensure power adapter is securely connected to both the machine and a working outlet.
No sound from speaker	Volume too low; Mute activated; Incorrect input source.	Increase 'Music Vol' and 'Mic Vol'; Check if mute is active; Select the correct input source (Bluetooth, AUX, etc.).
Microphones not working	Microphones off; Low battery in microphones; Not paired.	Ensure microphones are powered on; Replace batteries in microphones; Power cycle microphones and machine to re-establish connection.
Wi-Fi connection issues	Incorrect password; Out of range; Router issues.	Verify Wi-Fi password; Move closer to the Wi-Fi router; Restart your Wi-Fi router.
Screen unresponsive	Software glitch; System freeze.	Restart the machine; If unresponsive, perform a hard reset (refer to specific instructions if available, or hold power button for 10-15 seconds).

7. SPECIFICATIONS

Detailed technical specifications for the HUABAO Smart Karaoke Machine (Model A116):

Feature	Specification
Model Number	A116
Item Weight	16.75 pounds
Product Dimensions	15.2 x 7 x 12.2 inches
Display	14-inch HD Touchscreen
Speaker Count	7 (Supertweeter, Tweeter, Mid-range, Subwoofer)
Battery Type	Lithium Ion
Battery Capacity	9000mAh

Feature	Specification
Voltage	12 Volts (DC)
Power Source	Battery Powered
Connectivity	Bluetooth, WiFi, HDMI, 3.5 mm Jack, USB, TF Card, OTG
Compatible Devices	Earphone, Musical Instruments, Smartphone, Tablet, Television
Special Features	Echo Effect, Light Up Speaker, Lyric Display, Rechargeable, Touch Screen
Color	Black
Media Format	AVI, Karaoke

8. WARRANTY AND SUPPORT

8.1 Warranty Information

HUABAO provides a one-year warranty for this product from the date of purchase. This warranty covers manufacturing defects and malfunctions under normal use. It does not cover damage caused by misuse, accidents, unauthorized modifications, or improper maintenance.

8.2 Technical Support

We offer lifetime technical support for the HUABAO Smart Karaoke Machine. If you have any questions, require assistance with setup, operation, or troubleshooting, please do not hesitate to contact us.

- **Contact Method:** Reach out to us via Amazon's messaging service or directly through our support email.
- **Response Time:** We aim to respond to all inquiries within 12 hours.



Image 8.1: HUABAO customer support and warranty details.